



Operating Instructions and Parts Manual Box and Pan Brake

Model BB-9612



Baileigh Industrial
P.O. Box 531
Manitowoc, WI 54221-0531
Ph.: 920-684-4990
Fax: 920-684-3944
Baileigh-Sales@jpwindustries.com

BA9-1000553
Edition 3 08/2026
Copyright ©2026 Baileigh Industrial

1.0 Table of Contents

Section	Page
1.0 Table of Contents	2
2.0 Safety Instructions	3
3.0 About This Manual	4
4.0 Product Identification	5
5.0 Specifications.....	6
5.1 Description.....	6
6.0 Setup and Assembly	7
6.1 Unpacking and Checking Contents	7
6.2 Cleaning	7
6.3 Transporting and Lifting	8
6.4 Installation	8
6.5 Assembly.....	9
7.0 Adjustments	11
7.1 Finger Alignment.....	11
7.2 Adjusting the Setback.....	11
7.3 Positioning the Stop Collar	12
7.4 Spacing the Fingers.....	12
7.5 Adjusting the Clamping Pressure	13
7.6 Counterweight Adjustments.....	13
7.7 Top Leaf Adjustment.....	13
7.8 Bending Leaf Edge Alignment	14
8.0 Operation	14
8.1 Bending Allowance	15
8.2 Bending Sheet Metal	15
8.3 Understanding Springback	15
9.0 Material Selection	15
9.1 Material Equivalency Chart.....	15
10.0 Lubrication and Maintenance.....	15
11.0 Troubleshooting	17
12.0 Replacement Parts	18
12.1.1 Basic Units Assembly – Exploded View	18
12.1.2 Basic Units Assembly – Parts List.....	18
12.1.3 Clamping Beam Adjusting Assembly – Exploded View	20
12.1.4 Clamping Beam Adjusting Assembly – Parts List.....	20
12.1.5 Finger Blade Assembly – Exploded View.....	21
12.1.6 Finger Blade Assembly – Parts List.....	21
13.0 Warranty and Service.....	22



2.0 Safety Instructions

⚠ WARNING

Failure to follow these rules may result in serious personal injury

1. FOR YOUR OWN SAFETY, READ INSTRUCTION MANUAL BEFORE OPERATING THE MACHINE. Learn the machine's application and limitations as well as the specific hazards.
2. Only trained and qualified personnel can operate this machine.
3. Make sure guards are in place and in proper working order before operating machinery.
4. Remove any adjusting tools. Before operating the machine, make sure any adjusting tools have been removed.
5. Keep work area clean. Cluttered areas invite injuries.
6. Overloading machine. By overloading the machine you may cause injury from flying parts. DO NOT exceed the specified machine capacities.
7. Dressing material edges. Always chamfer and deburr all sharp edges.
8. Do not force tool. Your machine will do a better and safer job if used as intended. DO NOT use inappropriate attachments in an attempt to exceed the machines rated capacity.
9. Use the right tool for the job. DO NOT attempt to force a small tool or attachment to do the work of a large industrial tool. DO NOT use a tool for a purpose for which it was not intended.
10. Dress appropriate. DO NOT wear loose fitting clothing or jewelry as they can be caught in moving machine parts. Protective clothing and steel toe shoes are recommended when using machinery. Wear a restrictive hair covering to contain long hair.
11. Use eye and ear protection. Always wear ISO approved impact safety goggles. Wear a full-face shield if you are producing metal filings.
12. Do not overreach. Maintain proper footing and balance at all times. DO NOT reach over or across a running machine.
13. Stay alert. Watch what you are doing and use common sense. DO NOT operate any tool or machine when you are tired.
14. Check for damaged parts. Before using any tool or machine, carefully check any part that appears damaged. Check for alignment and binding of moving parts that may affect proper machine operation.

15. Observe work area conditions. DO NOT use machines or power tools in damp or wet locations. Do not expose to rain. Keep work area well lighted. DO NOT use electrically powered tools in the presence of flammable gases or liquids.
16. Blade adjustments and maintenance. Always keep blades sharp and properly adjusted for optimum performance.
17. Keep children away. Children must never be allowed in the work area. DO NOT let them handle machines, tools, or extension cords.
18. Store idle equipment. When not in use, tools must be stored in a dry location to inhibit rust. Always lock up tools and keep them out of reach of children.
19. DO NOT operate machine if under the influence of alcohol or drugs. Read warning labels on prescriptions. If there is any doubt, DO NOT operate the machine.
20. Keep visitors a safe distance from the work area.

⚠ WARNING: This product can expose you to chemicals including titanium dioxide which is known to the State of California to cause cancer, and lead which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to <http://www.p65warnings.ca.gov>.

⚠ WARNING: Drilling, sawing, sanding or machining wood products generates wood dust and other substances known to the State of California to cause cancer. Avoid inhaling dust generated from wood products or use a dust mask or other safeguards for personal protection.

Wood products emit chemicals known to the State of California to cause birth defects or other reproductive harm. For more information, go to <http://www.p65warnings.ca.gov/wood>.

Familiarize yourself with the following safety notices used in this manual:

⚠ CAUTION

This means that if precautions are not heeded, it may result in minor injury and/or possible machine damage.

⚠ WARNING

This means that if precautions are not heeded, it may result in serious, or possibly even fatal, injury.

⚠ DANGER

This means that if precautions are not heeded, it will result in serious or fatal injury.

3.0 About This Manual

This manual is provided by Baileigh Industrial, covering the safe operation and maintenance procedures for a Baileigh Model BB-9612 Box and Pan Brake. This manual contains instructions on installation, safety precautions, general operating procedures, maintenance instructions and parts breakdown. Your machine has been designed and constructed to provide consistent, long-term operation if used in accordance with the instructions as set forth in this document.

Technical Support handles questions on setup, operation, schematics, warranty issues, and individual parts needed. Our Technical Support department can be reached at 920-684-4990.

If there are questions or comments, please contact your local supplier or Baileigh Industrial. We can also be reached at our website: www.baileigh.com.

Retain this manual for future reference. If the machine transfers ownership, the manual should accompany it.

⚠ WARNING

Read and understand the entire contents of this manual before attempting assembly or operation! Failure to comply may cause serious injury!

Register your product online -

<https://baileigh.com/product-registration>



4.0 Product Identification




Figure 4-1

Table 4-1

Item	Name	Description
A	Counterweight	Adjustable weights to assist in raising the bending leaf.
B	Clamping Leaf	Secures the piece part against the clamping block.
C	Finger Blade	The die that the piece part is bent against.
D	Clamping Handles	Used to raise, lower, and lock the damping leaf.
E	Bending Leaf	Raised by the operator to make the bend.
F	Operating handles	Used by the operator to raise the bending leaf.
G	Clamp Block	Lower jaw for clamping and holding the piece part.
H	Bending wing	Angle on bending leaf that presses piece part against finger.

5.0 Specifications

Table 5-1

Model Number	BB-9612
Stock Number	BA9-1000553
General Specifications	
Bend Length	96" (2438mm)
Bend Material Thickness	12ga. (2.65mm) mild steel* 16ga. (1.52mm) stainless steel**
Bend Angle	0 – 135 degrees
Beam Adjustment	1" (25.4mm)
Minimum Reverse Bend	.625" (16mm)
Box Depth	6" (152mm)
Finger Size	6 @ 3" (76mm) 4 @ 4" (102mm) 10 @ 5" (127mm) 2 @ 6" (152mm)
Floor Stand	2 pcs. Welded Steel
Weights and Dimensions	
Shipping Weight	3220 lbs. (1460 kg)
Shipping Dimensions (L x W x H)	123" x 34" x 46" (3124 x 864 x 1168mm)
Based on a material tensile strength of *64000 PSI – mild steel **100000 PSI – stainless steel	

5.1 Description

The Baileigh Model **BB-9612** Box and Pan Brake is hand operated and capable of bending up to 12ga. (2.65mm) mild steel and 16ga. (1.52mm) stainless x 96" (2438mm) long. The machine has 22 removable fingers and a 6" (152mm) box depth allowing it to fabricate pans, boxes, channels, angles, and other shapes. Adjustable counterweights allow the operator to balance the bending leaf to correspond to material thickness. An adjustable stop gauge is included to allow the operator to perform repeat bends.

⚠ WARNING

Read and understand the entire contents of this manual before attempting assembly or operation. Failure to comply may cause serious injury.

6.0 Setup and Assembly

6.1 Unpacking and Checking Contents

Your Baileigh machine is shipped complete. Separate all parts from the packing material and check each item carefully. Make certain all items are accounted for before discarding any packing material.

⚠ WARNING

SUFFOCATION HAZARD! Immediately discard any plastic bags and packing materials to eliminate choking and suffocation hazards to children and animals.

⚠ WARNING

If any parts are missing, DO NOT place the machine into service until the missing parts are obtained and installed correctly.

6.2 Cleaning

⚠ WARNING

DO NOT USE gasoline or other petroleum products to clean the machine. They have low flash points and can explode or cause fire.

⚠ CAUTION

When using cleaning solvents work in a well-ventilated area. Many cleaning solvents are toxic if inhaled.

Your machine may be shipped with a rustproof waxy coating and/or grease on the exposed unpainted metal surfaces. Fully and completely remove this protective coating using a degreaser or solvent cleaner. Moving items will need to be moved along their travel path to allow for cleaning the entire surface. For a more thorough cleaning, some parts will occasionally have to be removed. **DO NOT USE** acetone or brake cleaner as they may damage painted surfaces.

Follow manufacturer's label instructions when using any type of cleaning product. After cleaning, wipe unpainted metal surfaces with a light coating of quality oil or grease for protection.

IMPORTANT: This waxy coating is NOT a lubricant and will cause the machine to stick and lose performance as the coating continues to dry.

- Remove the top portion of the crate.
- Take off the nuts and remove the supports (1) from the pallet.
- Remove the loose parts and set aside.
- Remove the nuts securing the main body to the pallet.




Figure 6-1



Figure 6-2



Figure 6-3



Figure 6-4



Figure 6-5



Figure 6-6



Figure 6-7

Table 6-1

Item	Description	Qty.
	Brake Main Body	1
1	Supports	2
2	Counterweight Assemblies	2
3	Open End Wrench	1
4	Handles w/Bolts & Lockwashers	2
5	Stop Rod w/Cotter Pin	1
6	Hex Bolt 1/2-13x1.75" Long	6
	Lockwasher 1/2"	6
	Flatwasher	6
	Hex Nut 1/2-13	6

6.3 Transporting and Lifting

NOTICE

Lifting and carrying operations should be carried out by skilled workers, such as a truck operator, crane operator, etc. If a crane is used to lift the machine, attach the lifting chain carefully, making sure the machine is well balanced.

Follow these guidelines when lifting with truck or trolley:

- The lift truck must be able to lift at least 1.5 – 2 times the machines gross weight.
- Make sure the machine is balanced. While transporting, avoid rough or jerky motion, and maintain a safe clearance zone around the transport area.
- Use a fork lift with sufficient lifting capacity and forks that are long enough to reach the complete width of the machine.
- Remove the securing bolts that attach the machine to the pallet.
- Approaching the machine from the side, lift the machine on the frame taking care that there are no cables or pipes in the area of the forks.
- Move the machine to the required position and lower gently to the floor.
- Level the machine so that all the supporting feet are taking the weight of the machine and no rocking is taking place.




Figure 6-8

Follow these guidelines when lifting crane or hoist:

- Always lift and carry the machine with the lifting holes provided at the top of the machine.
- Use lift equipment such as straps, chains, capable of lifting 1.5 to 2 times the weight of the machine.
- Take proper precautions for handling and lifting.
- Check if the load is properly balanced by lifting it an inch or two.
- Lift the machine, avoiding sudden accelerations or quick changes of direction.
- Locate the machine where it is to be installed, and lower slowly until it touches the floor.

6.4 Installation

IMPORTANT:

Consider the following when looking for a suitable location to place the machine:

- Overall weight of the machine.

- Weight of material being processed.
- Sizes of material to be processed through the machine.
- Space needed for auxiliary stands, work tables, or other machinery.
- Clearance from walls and other obstacles.
- Maintain an adequate working area around the machine for safety.
- Have the work area well illuminated with proper lighting.
- Keep the floor free of oil and make sure it is not slippery.
- Remove scrap and waste materials regularly, and make sure the work area is free from obstructing objects.
- If long lengths of material are to be fed into the machine, make sure that they will not extend into any aisles.
- **LEVELING:** The machine should be sited on a level, concrete floor. Provisions for securing it should be in position prior to placing the machine. The accuracy of any machine depends on the precise placement of it to the mounting surface.
- **FLOOR:** This tool distributes a large amount of weight over a small area. Make certain that the floor is capable of supporting the weight of the machine, work stock, and the operator. The floor should also be a level surface. If the unit wobbles or rocks once in place, be sure to eliminate by using shims.
- **WORKING CLEARANCES:** Take into consideration the size of the material to be processed. Make sure that you allow enough space for you to operate the machine freely.

6.4.1 Anchoring the Machine

- Once positioned, anchor the machine to the floor, as shown in the diagram. Use bolts and expansion plugs or sunken tie rods that connect through and are sized for the holes in the base of the stand.
- This machine requires a solid floor such as concrete at a minimum of 4" (102mm) thick. 6" (153mm) minimum is preferred.




Figure 6-9

6.5 Assembly

6.5.1 Removing Finger Assemblies

To remove the finger block assemblies you must first raise the clamping leaf with the clamping handles. Now for each finger block, loosen the capscrew shown in (fig. 6-11) and slide the finger assembly off of the finger guide. After thoroughly cleaning each finger assembly, coat them with a metal protectant to prevent corrosion. When re-installing the finger assemblies follow the instructions to properly re-align the fingers.




Figure 6-10




Figure 6-11

6.5.2 Mounting Supports to the Main Body of the Brake

1. Pull back on the clamp handles to raise the clamping leaf.
2. When using a fork lift to raise the main body from the pallet, first spread the forks and take a measurement between them.
3. Transfer this measurement to the center of the clamping leaf and remove the fingers necessary to allow the forks through as in (fig. 6-12 & fig. 6-13).



Figure 6-12



Figure 6-13

⚠ WARNING

DO NOT position yourself under the main body at any time while attaching the supports.

4. Raise the main body from the pallet, avoiding sudden accelerations or quick changes of direction and carefully pull the pallet out of the way.
5. While the main body is being held securely by the fork lift, attach the supports with (6) 1/2-13 x 1-3/4" lg. hex bolts, flat washers, lock washers, and hex nuts as shown in (fig. 6-14). Tighten securely.



Figure 6-14

6. Carefully lower the brake, and set into position on the floor.

6.5.3 Attaching the Handles

1. Locate and secure the (2) handles to the backside of the bending plate with (4) M10 x 40mm lg. capscrews, flat washers, and lock washers as shown.



Figure 6-15

6.5.4 Installing the Counterweights

1. Loosen the (2) jam nuts and back out the hex bolts of each counterweight pocket for clearance.
2. Carefully lift the counterweight assembly (approx. 90#) and place into the pocket.
3. Tighten the (2) hex bolts against the shaft and finally secure the (2) jam nuts.
4. Repeat the above procedure for the other counterweight.

Note: DO NOT use the counterweight arms to raise the bending leaf or you may damage the hinges.




Figure 6-16

6.5.5 Mounting the Stop Rod

1. Loosen the (2) socket head bolts on the stop collar and remove from the stop rod.
2. Insert the stop rod into the rotating stop block.
3. Push the short end of the stop rod into the tab on the bending leaf and secure with the cotter pin (supplied).
4. Slide the stop block back onto the stop rod as shown in fig. 6-17.



Figure 6-17

7.0 Adjustments

7.1 Finger Alignment

After removing and cleaning the fingers they must be aligned correctly to assure a proper bend. They can be aligned either as a group or individually.

1. Make sure there is no downward pressure on the fingers by first disengaging the two clamping handles.
2. Lift up on the bending leaf until the bending wing is perpendicular to the fingers as in (fig. 7-1). Set the stop collar to hold the leaf in this position. The bending wing will now serve as a straightedge to help line up the fingers.

3. Using a 6mm wrench, loosen the allen head set screws on each end of the brake as shown in (fig. 7-2) to free the setback handwheel shaft.
4. Loosen the two socket capscrews (fig. 7-3) on all the fingers you are using, with a 10mm hex wrench. Rotating the setback knobs counterclockwise (ccw), adjust the fingers forward until there is a small amount of pressure from the fingers to the bending wing.
5. With the fingers now against the bending wing, tighten all of the socket head capscrews of the finger assemblies.




Figure 7-1



Figure 7-2




Figure 7-3

7.2 Adjusting the Setback

Setback is the distance from the front edge of the finger to the front edge of the clamp block as shown in (fig. 7-4). This distance is determined by the gauge (thickness) of the piece part and inside radius of the bend. The setback is typically 1.5 – 2 times the material thickness.




Figure 7-4

1. To adjust, make sure all the fingers are properly aligned to each other and the clamp leaf is not clamped in the down position.
2. Rotate the setback knobs counter-clock wise (**ccw**) to move the fingers toward the edge of the clamp block or clockwise (**cw**) to move them back. (fig. 7-5).
3. Re-tighten the 6mm setscrews which press a plastic insert against the shaft threads and help hold the shaft in place. (**DO NOT** overtighten).




Figure 7-5

Note 1: Always make sure the fingers are parallel with the edge of the clamp block to avoid any distortion of the bend.

Note 2: To avoid damaging the brake, include the thickness of folded edges when determining the setback distance.

4. To check clamp alignment from end to end, make a 90° test bend in each of two small sample pieces, placing them 4" (102mm) in from each end of the brake. Stack the bent strips on top of each other and check that they are bent to the same degree. If a strip is over bent, increase the setback on that side accordingly. Vice versa if it is under bent. Move the fingers past the desired set back point, and then forward towards the clamp block edge to remove any slack.

7.3 Positioning the Stop Collar

The stop collar is used for repeat bending when you want the bending leaf to stop at the same position each time.

1. Loosen the stop collar and make your bend, stopping at the top of the bend.
2. Slide the collar up to the stop hub and tighten.
3. The bending angle can now be repeated until reset by the operator.



Figure 7-6

7.4 Spacing the Fingers

When making boxes and pans, the fingers can be spaced apart and combined in various combinations of sizes.

1. Remove one of the fingers by loosening the capscrew as indicated in (fig. 7-8) and removing it from the front guide. (Use a 10mm hex wrench)
2. Loosen the capscrews of the other fingers you need to move and slide them over as necessary.
3. Before bending, align the fingers, and re-tighten the capscrews. (See 7.2 for the proper alignment procedure.)




Figure 7-7




Figure 7-8

7.5 Adjusting the Clamping Pressure

⚠ CAUTION

- Excessive clamping pressure can “pre load” and permanently distort the brake.
- **DO NOT** bend material heavier than the rated capacity, even in shorter lengths.
- Use material with square-sheared edges. (a rolled edge will cause bowing).
- Bending a round object will warp or nick the clamp edge.
- Adjust the clamp pressure accordingly for different metal gauges.
- **Do not use a pipe extension on the clamp bars to get more leverage.**

The clamping pressure may have to be adjusted as the thickness of the piece part changes. A suitable pressure should have a medium resistance when pulling back on the hold down handle(s). At the end of the stroke there should be a definite locking of the piece part under the clamping leaf. To adjust the pressure, move the nuts on the threaded link shaft (fig. 7-9) either up or down.




Figure 7-9

1. To adjust the clamping pressure, tighten both sides of the clamping leaf with a piece part in the brake.
 - a. If the clamping pressure seems light and the piece part is loose in the clamp, move the adjusting nuts **UP**.
 - b. If the clamping pressure seems hard and you can't lock the handles, move the adjusting nuts **DOWN**.
 - c. Once the pressure feels right, no further adjustments are necessary for this thickness piece part. (When changing thickness it may become necessary to adjust again.)
2. Remove the piece part from under the clamping leaf, lock down the leaf with the handles, and loosen pressure on the top nut.

3. Unlock the clamping leaf and turn the bottom nut ½ turn in the desired direction.
4. Lock the clamping leaf, re-tighten the top nut, and repeat Step 1 above until the desired pressure is reached.

7.6 Counterweight Adjustments

⚠ CAUTION

DO NOT allow the weight to free fall down the shaft or fall off the shaft where it might cause personal injury.

⚠ CAUTION

DO NOT lower the weights to a point where they restrict the motion of the locking clamp arms.

The counterweights provide added leverage when bending thicker piece parts. Position the weight **LOW** when bending 16ga. (1.52mm) and **HIGH** when bending 12ga. (2.65mm)

Adjust the counterweights by loosening the hex bolt and raising or lowering the position of the weight on the shaft. (One operator can tend to the bolt while the other operator positions the weight.)



Figure 7-10

7.7 Top Leaf Adjustment

IMPORTANT: The top leaf and bending leaf adjustments were made at the factory based upon full capacity (length and thickness) mild steel. Additional adjustments are generally not needed. Different materials and material strength and hardness variation may require adjusting the leaf to obtain a satisfactory bend.

Normal bending should provide a consistent bend angle (A) over the entire length of the material.

If the angle remains open (B) in the middle of the material, the leaf may need to be adjusted to reduce bend angle variation.




Figure 7-11

Note: The brake needs to be leveled and secured to the floor to provide consistent accurate results.

Crowning adjustment is made by tightening or loosening the center leaf nuts (C and D).

1. Move the clamp handles to the forward position.
2. If the bend is open on the middle as in example (B), evenly tighten the top leaf center truss nut (C) and the lower leaf center truss nut (D) 1/2 turn each and test the bend angle.
3. Repeat the test bend and continue to adjust until the bend is even over the entire length of the material.




Figure 7-12

7.8 Bending Leaf Edge Alignment

Bending accuracy is dependent on the top surface of the bending leaf and the attached bending wing being flush with the top face of the clamping block when the bending leaf is in the lowered position.

1. Adjust bending leaf center truss nut (E) up or down as needed until the center of the bending leaf is perfectly aligned (on the same plane) with the clamping leaf edge.
2. Loosen the hinge to leaf bolts (F) only slightly to allow for the leaf to move with the adjusting bolt (G).
3. Adjust bending leaf ends with hinge adjustment bolts (G) up or down as needed until the ends

of the bending leaf are perfectly aligned (on the same plane) with the clamping leaf edge.

4. Repeat these steps as needed until the entire length of the bending leaf is perfectly aligned (on the same plane) with the clamping leaf edge.
5. Tighten the hinge bolts (F) after adjustment.




Figure 7-13

8.0 Operation

⚠ CAUTION

Always wear proper eye protection with side shields, steel toe footwear, and leather gloves to protect from burrs and sharp edges.

⚠ CAUTION

Keep hands and fingers clear of the clamping beam. Stand off to the side of the machine to avoid getting hit with the bending apron as it comes up to bend.

⚠ CAUTION

When handling large heavy sheets make sure they are properly supported.

When performing basic bending operations it is important that the fingers of the brake are parallel with the edge of the clamping block. Also make sure you have the proper setback and clamping pressure set for the thickness material being bent.

8.1 Bending Allowance

In order to bend sheet metal accurately, you will need to consider the total length of each bend. This is referred to as bend allowance. Subtract the bend allowance from the sum of the outside dimensions of the piece part to obtain the actual overall length or width of the piece. Because of differences in sheet metal hardness, and whether the bend is made with the grain or against it, exact allowances must sometimes be made by trial and error. However bend allowances for general use can be obtained from metal working books or from the Internet.

8.2 Bending Sheet Metal

1. Lift the clamping handle(s) to open up the clamping leaf.
2. Insert the piece part between the clamping leaf and the brake fingers.
3. Align the fingers of the clamping leaf to the scribed bend line of the piece part and clamp in place by pulling the clamp handle(s) down. Note: **DO NOT** force the clamping handle(s). The holding pressure only needs to be tight enough to hold the sheet metal from moving when bending.
4. Pull up on the bending leaf handles until the piece part has reached the desired bend angle (fig. 8-1).




Figure 8-1

5. Lower the bending leaf, raise the clamping leaf, and remove the bent piece part. If you are doing box and pan bending, choose fingers that closely match the dimensions of the finished piece.

8.3 Understanding Springback

Spring back, also known as elastic recovery, is the result of the metal wanting to return to its original shape after undergoing compression and stretch. After the bending leaf is removed from the metal and the load is released, the piece part relaxes, forcing

the bent portion of the metal to return slightly to its original shape. The key to obtaining the correct bend angle is to over bend the metal a little and allow it to spring back to the desired angle. All metals exhibit a certain amount of spring back.

9.0 Material Selection

⚠ CAUTION

It must be determined by the customer that materials being processed through the machine are NOT potentially hazardous to operator or personnel working nearby.

When selecting materials keep these instructions in mind:

- Material must be clean and dry. (without oil)
- Material should have a smooth surface so it processes easily.
- Dimensional properties of material must be consistent and not exceed the machine capacity values.
- Chemical structure of material must be consistent.
- Buy certificated steel from the same vendor when possible.

9.1 Material Equivalency Chart

Mild Steel	14ga. (.075") (2mm)
Stainless Steel	18ga. (.048") (1.2mm)
Aluminum	200" (5mm)
Soft Brass	135" (3.4mm)
Annealed Phosphor Bronze	120" (3mm)
Soft Copper	135" (3.4mm)
Hard Copper	120" (3mm)
ABS Plastic	250" (6.3mm)

10.0 Lubrication and Maintenance

⚠ WARNING

Maintenance should be performed on a regular basis by qualified personnel.

⚠ WARNING

Always follow proper safety precautions when working on or around any machinery.

- Check daily for any unsafe conditions and fix immediately.
- Check that all nuts and bolts are properly tightened.
- On a weekly basis clean the machine and the area around it.
- Lubricate threaded components and sliding devices.

- Apply rust inhibitive lubricant to all non-painted surfaces.

Note: Proper maintenance can increase the life expectancy of your machine.

Using an oil can with a good quality #30W oil, apply 5-6 drops into each of the four ports. Repeat weekly or more often depending on usage. Wipe off any excess oil.




Figure 10-1

The threads on the setback knobs and the threads on the clamping pressure adjustment will need an occasional wiping down with white lithium grease. This will help to maintain smooth operation of each.



Figure 10-2


11.0 Troubleshooting

Table 11-1

Fault	Probable Cause	Remedy
INACCURATE BENDS	Fingers are not aligned.	Follow proper finger alignment procedure.
	Setback distance is not equal from one side to the other.	Accurately measure distance and set accordingly.
	Clamping leaf is not holding piece part securely.	Re-adjust the clamping pressure.
	Bending wing out of alignment with the top surface of the clamping block.	Please consult the Baileigh Service Department.
BENDING LEAF HARD TO LIFT AND BEND.	Exceeding the bending limits of the brake.	Do not bend material thicker than the machine was designed for.
	Counter weights are not adjusted properly.	Locate the weight lower for thin material and high for thicker material.

12.0 Replacement Parts

12.1.1 Basic Units Assembly – Exploded View




12.1.2 Basic Units Assembly – Parts List

Index No	Part No	Description	Size	Qty
101	BA9-1224910	Bending leaf.....		1
102	**	Bottom Base		1
103	**	Clamping Beam Assy.		1

Index No	Part No	Description	Size	Qty
02	**	Handle Bar		2
03	BA9-1004404H	Screw		4
05	**	Bottom Bar		1
06	**	Round Head Screw		
07	BA9-1000564	Angle Bar		1
08	BA9-1144435	Round Head Screw		11
09	BA9-1004454	Hinge (R.H.)	FTLG-09-Hinge (RH), 1-1/4"	1
09	BA1-10724	Hinge (R.H.)	32mm	1
10	BA9-1004455	Hinge (L.H.)	1-1/4"	1
10	BA1-10725	Hinge (L.H.)	32mm	1
11	BA9-1004456	Hinge Rod		2
12	**	Round Head Screw		2
13	**	Hex. Screw		10
14	**	Set Screw		4
15	**	Round Head Screw		2
16	BA9-1004411	Rod		2
17	BA9-1230367	Counter Weight Assy.		2
18	BA9-1004412	Stand Assy.		2
19	**	Hex cero. Screw		6
21	BA9-1000555	Bending Adjustable Rod Assy.		1
22	BA9-1000556	Box Adjustable Assy.		1
23	BA1-10726	Bushing		2
25	**	Clamping Beam Adjusting Assy.		
28	BA9-1004458	Swivel Pin Assy.		2
29	**	Toggle Assy. (R.H.)		1
30	**	Toggle Assy. (L.H.)		1
31	BA9-1004461	Clamp Handle (R.H.)		1
32	BA9-1000541	Clamp Handle (L.H.)		1
33	BA9-1019361E	Scale		1
35	**	Finger blade assembly		1
45	BA9-1004433	Spring Cover Assy.		2
47	**	Shaft, Clamp Handle		2
48	**	Set Screw		
49	**	Nut		4
50	**	Washer		4
60	**	Spring Washer		
61	BA1-10727	Bushing		1
62	**	Screw		2
63	**	Screw		2
64	**	Nut		2
65	**	Set Screw		4
66	**	Washer		2
67	**	Hex. Screw		
68	**	Nut		
69	**	Nut		2
72	**	Washer		
73	**	Nut		6
74	BA1-10728	Bushing		1
75	BA1-10729	Cotter Pin		1
	BA9-1019369G	Arrow Sticker for Scale		
	BA9-1000565	Degree Tape		
	BA9-1000566	Complete Finger		
	BA9-1004473	Oil Nozzle		
	BA9-1004463	Toggle Nut		
	BA9-1232564	Pressure Gauge		

** These parts are shown for reference only and are not available for order individually. Non-proprietary parts, such as fasteners, can usually be found at local hardware stores.

12.1.3 Clamping Beam Adjusting Assembly – Exploded View




12.1.4 Clamping Beam Adjusting Assembly – Parts List

Index No.	Part No.	Description	Size	Qty.
01	BA1-10730	Holder		1
02	**	Screw		2
03	**	Screw		2
04	BA1-10731	U Style Base		1
05	BA1-10732	Hand Wheel		1
06	**	Roll Pin		1
07	BA1-10733	Adjusting Screw		1
08	**	Shaft Filler Washer		1
09	**	Screw		1
10	BA1-10734	Adjusting Nut		1
11	BA1-10735	Bakelite Hand Knob		1
12	**	Washer		2
13	BA1-10736	Grease Fitting		1

** These parts are shown for reference only and are not available for order individually. Non-proprietary parts, such as fasteners, can usually be found at local hardware stores.

12.1.5 Finger Blade Assembly – Exploded View



Finger Blade Sizes INCH (mm)	3" (76)	4" (102)	5" (127)	6" (152)
Qty. of Fingers				

12.1.6 Finger Blade Assembly – Parts List

Index No.	Part No.	Description	Size	Qty.
01	BA9-1014605	Screw		1
02	BA9-1014606	Screw		2
03	BA9-1014582	Clamping Holder-Up (3")		
03	BA9-1014583	Clamping Holder-Up (4")		
03	BA9-1014584	Clamping Holder-Up (5")		
03	BA9-1014585	Clamping Holder-Up (6")		
04	BA9-1014607	Screw		1
05	BA1-10737	Upper Blade Base		1
06	BA9-1231912	Finger Blade (3")		
06	BA9-1231913	Finger Blade (4")		
06	BA9-1231914	Finger Blade (5")		
06	BA9-1231915	Finger Blade (6")		
07	**	Clamping Holder-Bottom (3")		
07	**	Clamping Holder-Bottom (4")		
07	**	Clamping Holder-Bottom (5")		
07	**	Clamping Holder-Bottom (6")		

** These parts are shown for reference only and are not available for order individually. Non-proprietary parts, such as fasteners, can usually be found at local hardware stores.

13.0 Warranty and Service

Thank you for your purchase of a machine from Baileigh Industrial. We hope that you find it productive and useful to you for a long time to come.

Inspection & Acceptance. Buyer shall inspect all Goods within ten (10) days after receipt thereof. Buyer's payment shall constitute final acceptance of the Goods and shall act as a waiver of the Buyer's rights to inspect or reject the Goods unless otherwise agreed. If Buyer rejects any merchandise, Buyer must first obtain a Returned Goods Authorization ("RGA") number before returning any Goods to Seller. Goods returned without an RGA will be refused. Seller will not be responsible for any freight costs, damages to Goods, or any other costs or liabilities pertaining to Goods returned without an RGA. Seller shall have the right to substitute a conforming tender. Buyer will be responsible for all freight costs to and from Buyer and repackaging costs, if any, if Buyer refuses to accept shipment. If Goods are returned in unsalable condition, Buyer shall be responsible for full value of the Goods. Buyer may not return any special-order Goods. Any Goods returned hereunder shall be subject to a restocking fee equal to 30% of the invoice price.

Specifications. Seller may, at its option, make changes in the designs, **specifications**, or components of the Goods to improve the safety of such Goods, or if in Seller's judgment, such changes will be beneficial to their operation or use. Buyer may not make any changes in the specifications for the Goods unless Seller approves of such changes in writing, in which event Seller may impose additional charges to implement such changes.

Limited Warranty. Seller warrants to the original end-user that the Goods manufactured or provided by Seller under this Agreement shall be free of defects in material or workmanship for a period of twelve (12) months from the date of purchase, provided that the Goods are installed, used, and maintained in accordance with any instruction manual or technical guidelines provided by the Seller or supplied with the Goods, if applicable. The original end-user must give written notice to Seller of any suspected defect in the Goods prior to the expiration of the warranty period. The original end-user must also obtain an RGA from Seller prior to returning any Goods to Seller for warranty service under this paragraph. Seller will not accept any responsibility for Goods returned without an RGA. The original end-user shall be responsible for all costs and expenses associated with returning the Goods to Seller for warranty service. In the event of a defect, Seller, at its sole option, shall repair or replace the defective Goods or refund to the original end-user the purchase price for such defective Goods. Goods are not eligible for replacement or return after a period of 10 days from date of receipt. The foregoing warranty is Seller's sole obligation, and the original end-user's exclusive remedy, with regard to any defective Goods. This limited warranty does not apply to: (a) die sets, tooling, and saw blades; (b) periodic or routine maintenance and setup, (c) repair or replacement of the Goods due to normal wear and tear, (d) defects or damage to the Goods resulting from misuse, abuse, neglect, or accidents, (f) defects or damage to the Goods resulting from improper or unauthorized alterations, modifications, or changes; and (f) any Goods that has not been installed and/or maintained in accordance with the instruction manual or technical guidelines provided by Seller.

EXCLUSION OF OTHER WARRANTIES. THE FOREGOING LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. ANY AND ALL OTHER EXPRESS, STATUTORY, OR IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE ARE EXPRESSLY DISCLAIMED. NO WARRANTY IS MADE WHICH EXTENDS BEYOND THAT WHICH IS EXPRESSLY CONTAINED HEREIN.

Limitation of Liability. IN NO EVENT SHALL SELLER BE LIABLE TO BUYER OR ANY OTHER PARTY FOR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES (INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR DOWN TIME) ARISING FROM OR IN MANNER CONNECTED WITH THE GOODS, ANY BREACH BY SELLER OR ITS AGENTS OF THIS AGREEMENT, OR ANY OTHER CAUSE WHATSOEVER, WHETHER BASED ON CONTRACT, TORT OR ANY OTHER THEORY OF LIABILITY. BUYER'S REMEDY WITH RESPECT TO ANY CLAIM ARISING UNDER THIS AGREEMENT IS STRICTLY LIMITED TO NO MORE THAN THE AMOUNT PAID BY THE BUYER FOR THE GOODS.

Force Majeure. Seller shall not be responsible for any delay in the delivery of, or failure to deliver, Goods due to causes beyond Seller's reasonable control including, without limitation, acts of God, acts of war or terrorism, enemy actions, hostilities, strikes, labor difficulties, embargoes, non-delivery or late delivery of materials, parts and equipment or transportation delays not caused by the fault of Seller, delays caused by civil authorities, governmental regulations or orders, fire, lightning, natural disasters or any other cause beyond Seller's reasonable control. In the event of any such delay, performance will be postponed by such length of time as may be reasonably necessary to compensate for the delay.

Installation. If Buyer purchases any Goods that require installation, Buyer shall, at its expense, make all arrangements and connections necessary to install and operate the Goods. Buyer shall install the Goods in accordance with any Seller instructions and shall indemnify Seller against any and all damages, demands, suits, causes of action, claims and expenses (including actual attorneys' fees and costs) arising directly or indirectly out of Buyer's failure to properly install the Goods.

Work By Others; Safety Devices. Unless agreed to in writing by Seller, Seller has no responsibility for labor or work performed by Buyer or others, of any nature, relating to design, manufacture, fabrication, use, installation, or provision of Goods. Buyer is solely responsible for furnishing and requiring its employees and customers to use all safety devices, guards and safe operating procedures required by law and/or as set forth in manuals and instruction sheets furnished by Seller. Buyer is responsible for consulting all operator manuals, ANSI or comparable safety standards, OSHA regulations and other sources of safety standards and regulations applicable to the use and operation of the Goods.

Remedies. Each of the rights and remedies of Seller under this Agreement is cumulative and in addition to any other or further remedies provided under this Agreement or at law or equity.

Attorney's Fees. In the event legal action is necessary to recover monies due from Buyer or to enforce any provision of this Agreement, Buyer shall be liable to Seller for all costs and expenses associated therewith, including Seller's actual attorney fees and costs.

Governing Law/Venue. This Agreement shall be construed and governed under the laws of the State of Wisconsin, without application of conflict of law principles. Each party agrees that all actions or proceedings arising out of or in connection with this Agreement shall be commenced, tried, and litigated only in the state courts sitting in Manitowoc County, Wisconsin or the U.S. Federal Court for the Eastern District of Wisconsin. Each party waives any right it may have to assert the doctrine of "forum non conveniens" or to object to venue to the extent that any proceeding is brought in accordance with this section. Each party consents to and waives any objection to the exercise of personal jurisdiction over it by courts described in this section. Each party waives to the fullest extent permitted by applicable law the right to a trial by jury.

Summary of Return Policy:

- 10 Day acceptance period from date of delivery. Damage claims and order discrepancies will not be accepted after this time.
- You must obtain a Baileigh Industrial issued RGA number PRIOR to returning any materials.
- Returned materials must be received at Baileigh Industrial in new condition and in original packaging.
- Altered items are not eligible for return.
- Buyer is responsible for all shipping charges.
- A 30% re-stocking fee applies to all returns.

Baileigh Industrial makes every effort to ensure that our posted specifications, images, pricing, and product availability are as correct and timely as possible. We apologize for any discrepancies that may occur. Baileigh Industrial reserves the right to make any and all changes deemed necessary in the course of business including but not limited to pricing, product specifications, quantities, and product availability.

For Customer Service & Technical Support:

Please contact one of our knowledgeable Sales and Service team members at:
(920) 684-4990 or e-mail us at Baileigh-Service@jpwindustries.com



BAILEIGH INDUSTRIAL

1625 DUFEK DRIVE MANITOWOC, WI 54220

PHONE: 920.684.4990 FAX: 920.684.3944

www.baileigh.com