




PARTS MANUAL

Book 2 of 2



HORIZONTAL BAND SAW MODEL: BS-24A

Baileigh Industrial, Inc.
P.O. Box 531
Manitowoc, WI 54221-0531
Phone: 920.684.4990
Fax: 920.684.3944
sales@baileighindustrial.com

REPRODUCTION OF THIS MANUAL IN ANY FORM WITHOUT WRITTEN APPROVAL OF BAILEIGH INDUSTRIAL, INC. IS PROHIBITED. Baileigh Industrial, Inc. does not assume and hereby disclaims any liability for any damage or loss caused by an omission or error in this Operator's Manual, resulting from accident, negligence, or other occurrence.




Table of Contents

PARTS DIAGRAM A	1
Parts List A	2
PARTS DIAGRAM B	3
Parts List B	4
PARTS DIAGRAM C	6
Parts List C	7
PARTS DIAGRAM D	11
Parts List D	12
PARTS DIAGRAM E	17
Parts List E	18
PARTS DIAGRAM F	22
Parts List F	23
PARTS DIAGRAM G	25
Parts List G	26



PARTS DIAGRAM A






Parts List A

Item	Description	Size No.	Qty.
A1	Set Screw	M12x25L	4
A2	Spring Pin	8x20L	2
A3	Hex. Socket Cap Screw	M12x45L	6
A4	Hex. Cap Bolt	M12x45L	2
A5	Nut	M12	2
A6	Set Screw	M10x20L	4
A7	Hex. Socket Cap Screw	M16x45L	4
A8	Set Screw	M12x25L	4
A9	Washer	M12	4
A10	Spring Washer	M12	4
A11	Hex. Socket Cap Screw	M12x45L	4



PARTS DIAGRAM B





Parts List B


Item	Description	Size No.	Qty.
B1	Button Head Socket Screw	M5x6L	4
B2	Upper Cover	461F3-01-I	1
B3	Button Head Socket Screw	M5x6L	4
B4	Left Cover	461F3-01-H	1
B5	Pressure Regulator Knob	L25A1-42	1
B6	Cutting Rate Knob	L25A2-01	1
B7	Flow Valve Panel	NPB-001	1
B8	Button Head Socket Screw	M5x8L	10
B9	Operation Panel	NPB-006	1
B10	Hex. Cap Bolt	M8x16L	4
B11	Spring Washer	M8	4
B12	Washer	M8	4
B13	Electrical Box Door	461F3-01-J	1
B14	Hex. Socket Cap Screw	M6x25L	2
B15	Nut	M8	4
B16	Supporting Bracket	461F3-01-C	1
B17	Hex. Cap Bolt	M10x16L	4
B18	Spring Washer	M10	4
B19	Electrical Box	461F3-01-B	1
B20	Button Head Socket Screw	M6x8L	4
B21	Inverter Cover	461F3-01-D	1
B22	Motor Inverter 5HP	ML0006	1
B23	Half Round Head Screw	M5x8L	4
B24	Machine Base	461F3-01	1
B25	Coolant Level Gauge	9160418	1
B26	Drain	3/8"PT	1
B27	Left Lateral Cover	461F3-03	1
B28	Button Head Socket Screw	M5x8L	2
B29	Right Lateral Cover	461F3-03-A	1
B30	Plastic Handle	9160502	1
B31	Big Round Head Screw	M6x12L	2
B32	Button Head Socket Screw	M6x8L	4
B33	Fixed Wires Plate	461F3-01-F	1



Item	Description	Size No.	Qty.
B34	Hydraulic Unit Cover (Left)	461F3-01-E	1
B35	Button Head Socket Screw	M6x8L	5
B36	Vise Pressure Valve		1
B37	Big Round Head Screw	M6x12L	2
B38	Plastic Handle	9160502	1
B39	Coolant Pump Cover	461F3-01-G	1
B40	Button Head Socket Screw	M6x8L	2
B41	Coolant Plate (RR)	461F3-23-A	1
B42	Wing Screw	M6x12L	2
B43	Hydraulic Unit Cover (Right)	461F3-01-E	1
B44	Button Head Socket Screw	M6x8L	5



PARTS DIAGRAM C





Parts List C

Item	Description	Size No.	Qty.
C1	Roller Cover	461F3-04	1
C2	Button Head Socket Screw	M6x12L	4
C3	Side Plate (Left)	461F2-04-C	1
C4	Roller Strengthen Bracket	461F3-04-A	2
C5	Flat Head Screw	M8x20L	4
C6	Roller Plate (Upper)	461F2-04-D	1
C7	Roller Plate (Front)	461F2-04	1
C8	Shaft Cover	S13802-07-C	12
C9	Shaft	6203	12
C10	Roller Shaft	461F2-10	6
C11	C Ring	R40	12
C12	Roller	461D2-04	6
C13	Roller Bracket	461F3-04-B	2
C14	Side Plate (Right)	461F2-04-B	1
C15	Flat Head Screw	M10x25L	6
C16	Flat Head Screw	M10x25L	4
C17	Spring Pin	8x20L	4
C18	Flat Head Screw	M10x25L	6
C19	Spring Pin	8x20L	4
C20	Flat Head Screw	M10x25L	6
C21	Flat Head Screw	M10x25L	6
C22	Hex. Socket Cap Screw	M4x20L	4
C23	Spring Pin	4x25L	3
C24	Rack Rod	S138F2-12	1
C25	Feeding Vise Fixing Bracket	461F1-09	1
C26	Spring Pin	10x30L	2
C27	Hex. Socket Cap Screw	M12x40L	6
C28	Oilless Bushing 6540	L25A5-09-1	2
C29	Upper Shaft	461F2-17-B	1
C30	Nut	M20x1.5	2
C31	O Ring P24	H36D4-20	1
C32	Cylinder Cover	461F2-17	1
C33	Hex. Socket Cap Screw	M8x25L	4



Item	Description	Size No.	Qty.
C34	O Ring P70	H36D4-22	1
C35	Hydraulic Piston	461F2-17-A	1
C36	Spring	S138F4-05	1
C37	Oilless Bushing 4015	S138F5-14	1
C38	Guide Plate	461F3-17	1
C39	Button Head Socket Screw	M8x12L	3
C39-1	Support Bracket	S138F3-34-D	1
C39-2	Hex. Socket Cap Screw	M6x12L	2
C39-3	Hex. Cap Bolt	M10x20L	1
C39-4	Nut	M10	1
C40	Spring Pin	10x30L	1
C41	Adjusting Block	461F2-21	1
C42	Feeding Vise Jaw	461F1-12	1
C43	Set Screw	M10x35L	3
C44	Nut	M10	3
C45	Hex. Socket Cap Screw	M14x40L	2
C46	Flat Head Screw	M8x20L	8
C47	Vise Steel Plate	461F2-08	1
C48	Vise Steel Plate	461F2-08	1
C49	Block Cover	461F2-23-A	1
C50	Upper Cover	461F2-23	1
C51	Hex. Socket Cap Screw	M12x30L	4
C52	Oil Nipple	1/8"PT	1
C53	Hex. Socket Cap Screw	M8x16L	4
C53-1	Nut	M8	4
C53-2	Set Screw	M8x25L	4
C54	Guide Shaft	461F2-01	2
C55	Guide Rod Bracket	461F3-12	1
C56	Cylinder Bracket	S138F1-03	1
C57	Hex. Socket Cap Screw	M10x25L	4
C58	Hex. Cap Steel Screw	M12x65L	1
C59	Nut	M12	1
C60	Dust Seal DKB75.89.8/11	L40N4-22	4
C61	Oilless Bushing 7540	L40N5-01	4
C62	Hex. Socket Cap Screw	M16x25L	1




Item	Description	Size No.	Qty.
C63	Hex. Socket Cap Screw	M14x25L	1
C64	Vise Jaw	461F1-11	1
C65	Adjusting Block	461F2-20	1
C66	Nut	M10	4
C67	Set Screw	M10x35L	4
C68	Spring Pin	10x30L	2
C69	Cylinder Bracket	461F3-10	1
C70-1	Hex. Socket Cap Screw	M6x16L	2
C70-2	Adjusting Bracket	461F3-15-A	1
C70-3	Sensor Plate	S138F3-21-C	1
C70-4	Button Head Socket Screw	M6x8L	2
C74	Hex. Socket Cap Screw	M12x45L	6
C75	Oilless Bushing 6040	S138F5-11	2
C76	Upper Shaft	461F2-03	1
C77	Vise Cylinder		1
C78	Hex. Socket Cap Screw	M10x35L	4
C79	Spring Washer	M10	4
C80	Spring Pin	10x30L	2
C81	Fixing Bracket	461F3-08	1
C82	Flat Head Screw	3/4"x1-1/4"L	2
C83	Hex. Cap Bolt	M12x30L	4
C84	Spring Washer	M12	4
C85	Set Screw	M10x16L	4
C86	Down Clamp Cylinder		1
C87	C Ring	S60	2
C88	Hex. Socket Cap Screw	M12x30L	6
C89	Hex. Socket Cap Screw	M8x16L	4
C90	Oil Nipple	1/8"PT	1
C90-1	Nut	M8	4
C90-2	Set Screw	M8x25L	4
C91	Upper Cover	461F2-22	1
C92	Adjusting Block	461F2-22-A	1
C93	Oilless Bushing 5540	461D5-10	2
C94	Guide Shaft	461F2-02	1
C95	Flat Head Screw	M12x35L	1



Item	Description	Size No.	Qty.
C96	Down Clamp Bracket	461F3-07	1
C97	PU		1
C98	Upper Slide Plate	461F2-19	1
C99	Hex. Socket Cap Screw	M12x40L	10
C100	Hex. Cap Steel Screw	M12x45L	1
C101	Nut	M12	1
C102	Roller Bracket (Rear)	461F2-04-A	1
C103	Shaft Washer	461F2-01-A	2
C104	Spring Washer	M16	2
C105	Hex. Socket Cap Screw	M16x40L	2
C106	Nut	M20	1
C107	Spring Washer	M20	1
C108	Washer	M20	1
C109	Vertical Roller Bracket	S138F3-23	1
C110	Hex. Cap Steel Screw	M10x25L	4
C111	Spring Washer	M10	4
C112	Roller Bush	S13802-18-2	1
C113	C Ring	R52	2
C114	Bearing	6205	2
C115	Vertical Roller	461D2-05	1
C116	Roller Shaft	461D2-05-A	1



PARTS DIAGRAM D





Parts List D

Item	Description	Size No.	Qty.
D1	Button Head Socket Screw	M8x25L	4
D2	Position Locker	460D3-27-4	1
D3	Spring		1
D4	Set Screw	M4x12L	2
D5	Threaded Sleeve	460D3-27-6	1
D6	Hex. Cap Bolt	M8x20L	2
D7	Spring Washer	M8	2
D8	Hex. Cap Bolt	M8x20L	1
D9	Fixing Bracket	460D3-27-2	1
D10	Threaded Sleeve	460D3-27-5	1
D11	Long Arm	460D3-27	1
D12	Short Arm	460D3-27-1	1
D13	Nut	M8	2
D14	Threaded Sleeve	460D3-27-3	1
D15	Hex. Socket Cap Screw	M4x30L	2
D16	Limit Switch AZD-S11	331D5-07	1
D17-1	Wheel Shaft	461F2-14-A	1
D18	Slider Seat	L46N1-10	1
D19	Blade Tension Cylinder		1
D20	Spring Washer	M12	4
D21	Hex. Socket Cap Screw	M12x155L	4
D22	Slider	L46N1-10-A	1
D23	Adjusting Plate	L46N2-28	2
D24	Washer	L46N2-22	1
D25	Spring Washer	M12	1
D26	Hex. Cap Steel Screw	M12x30L	1
D27	Hex. Socket Cap Screw	M8x25L	6
D28	Spring Washer	M8	6
D29	Hex. Cap Steel Screw	M14x55L	3
D30	Spring Washer	M14	3
D31	Threaded Sleeve	L46N2-12	3
D32	Blade Broken Sensor		1
D33	Hex. Socket Cap Screw	M4x35L	2



Item	Description	Size No.	Qty.
D34	Limit Switch ED-31	331D5-06-C	1
D35	Wire Fixing Plate	461F3-02-B	1
D36	Button Head Socket Screw	M5x6L	4
D37	Hex. Socket Cap Screw	M4x35L	2
D38	Limit Switch ED-1-3-32	H33D4-11	1
D39	C Ring	S-20	2
D40	Motor Bracket Shaft	530D2-06	1
D41	Adjusting Bolt	L46N2-10-A	1
D42	Key	4x4x10L	1
D43	Handle	L46N2-10-B	1
D44	Washer	M6	1
D45	Hex. Socket Cap Screw	M6x12L	1
D46	Motor 5HP	ML46D001	1
D47	Washer	M10	4
D48	Spring Washer	M10	4
D49	Hex. Cap Bolt	M10x30L	4
D50	Key	10x8x40	1
D51	Motor Supporter	461F3-13	1
D52	Hex. Socket Cap Screw	M8x20L	4
D53	Spring Washer	M8	4
D54	Motor Fixing Bracket	530D3-06	1
D55	Spring Pin	8x20L	2
D56	Reducer 120#1/40	460D4-15	1
D57	Key	14x9x50	1
D58	Wheel Box	461F3-05	1
D59	Button Head Socket Screw	M5x8L	2
D60	Belt	22-560	2
D61	Set Screw	M8x16L	2
D62	Motor Shaft Pulley	L33N1-56	1
D63	Belt Pulley	461F1-02	1
D64	Washer	S13802-26	1
D65	Spring Washer	M10	1
D66	Hex. Socket Cap Screw	M10x35L	1
D67	Cover	461F3-05-A	1
D68	Button Head Socket Screw	M5x8L	5



Item	Description	Size No.	Qty.
D69	Button Head Socket Screw	M5x8L	4
D70	Cover	461F3-05-B	1
D71	Hex. Socket Cap Screw	M6x90L	4
D72	Brush Motor		1
D73	Nut	M6	8
D74	Hex. Socket Cap Screw	M8x20L	2
D75	Spring Washer	M8	2
D76	Fixing Bracket	460D3-31-B	1
D77	Cover	460D3-31-C	1
D78	Button Head Socket Screw	M5x8L	2
D79	Universal Joint Bush	L25A4-02-1	2
D80	Set Screw	M5x6L	8
D81	Universal Joint	L25A4-02	2
D82	Key	4x4x15L	4
D83	Brush Shaft (Long)	460D2-59-2	1
D84	Nut	M20	1
D85	Brush Shaft (Short)	460D2-59-1	1
D86	Wing Screw	M6x10L	1
D87	Hex. Socket Cap Screw	M6x20L	1
D88	Spring Washer	M6	1
D89	Hex. Cap Bolt	M8x20L	2
D90	Spring Washer	M8	2
D91	Washer	M8	2
D92	Fixing Bracket	460D3-31-A	1
D93	Cover	460D3-31	1
D94	Shaft Bush	460D2-59	1
D95	Oilless Bushing 1212	L25A5-08	2
D96	Brush	331D4-08	1
D97	Washer	M6	1
D98	Spring Washer	M6	1
D99	Nut	M6	1
D100	Saw Bow	461F3-02	1
D101	Spring Washer	M12	4
D102	Hex. Cap Steel Screw	M12x45L	4
D103	Hex. Socket Cap Screw	M12x75L	4




Item	Description	Size No.	Qty.
D104	Fixing Block	461D2-08	2
D105	Oilless Bushing 4040	331D5-14	2
D106	Washer	331D2-01-A	1
D107	Bow Shaft	460D2-01	1
D108	C Ring	S20	2
D109	Bracket Shaft	460D2-38	1
D110	Eye Bearing	POS16	1
D111	Nut	M20xP1.5	1
D112	Hydraulic Cylinder		1
D113	Hex. Socket Cap Screw	M8x20L	2
D114	Lower Bracket	461F1-07	1
D115	Bracket Shaft	461F2-16	1
D116	C Ring	S20	2
D117	Hex. Socket Cap Screw	M8x40L	2
D118	Spring Washer	M8	2
D119	Blade Guide Block (POM)	460D2-55	1
D120	Steel Plate Bracket	460D1-08-A	2
D121	Washer	M10	4
D122	Spring Washer	M10	4
D123	Hex. Socket Cap Screw	M10x30L	4
D124	Shaft	460D2-11	2
D125	Blade Guide Wheel	460D2-10	2
D126	Bearing 6005	460D4-21	4
D127	C Ring	R42	2
D128	Washer	460D2-11-A	2
D129	Spring Washer	M12	2
D130	Hex. Socket Cap Screw	M12x60L	2
D131	Bearing 32009	460D4-20	2
D132	Idle Wheel	460D1-12	1
D133	Shaft Cover 32009AV	460D4-08	2
D134	Teeth Washer	AW09	1
D135	Shaft Nut	AN09	1
D136	Steel Plate	460D1-08	1
D137	Steel Scale		1
D138	Round Head Screw	M5x8L	5



Item	Description	Size No.	Qty.
D139	Position Plate	460D2-46	2
D140	Blade Protector	461D3-11	1
D141	Thumb Screw	M5x8L	1
D142	Spring Pin	4x12L	1
D143	Locking Handle M12x50L	331D4-39	2
D144	Hex. Socket Cap Screw	M10x35L	2
D145	Washer	M10	2
D146	Spring Washer	M10	2
D147	Button Head Socket Screw	M6x8L	2
D148	Fixing Block	460D2-44	2
D149	Button Head Socket Screw	M8x30	4
D150	Spring Pin	8x70L	2
D151	Button Head Socket Screw	M6x16L	4
D152	Bow Cover Locker	460D2-45	2
D153	Bow Cover	460D3-10-C	1
D154	Blade Protector	460D3-13-A	1
D155	Thumb Screw	M5x8L	1
D156	Spring Pin	4x12L	1
D157	Hex. Socket Cap Screw	M10x35L	2
D158	Washer	M10	2
D159	Spring Washer	M10	2
D160	Rear Bearing Bracket	460D1-07-A	1
D161	Front Bearing Bracket	460D1-07	1
D162	Set Screw	M8x16L	6
D163	Hex. Socket Cap Screw	M10x20L	4
D164	Set Screw	M10x16L	4
D165	Driver Wheel	460D1-13	1
D166	Washer	331D2-49	1
D167	Flat Head Screw	M12x25L	1
D168	Spring 9.0x56x54N	460D4-10	2
D169	Hex. Socket Cap Screw	M10x25L	3
D170	Spring Washer	M10	3
D171	Bracket	460D1-16	1
D172	Washer	1/2"	4
D173	Nut	1/2"	4



PARTS DIAGRAM E





Parts List E

Item	Description	Size No.	Qty.
E1	Vise Shaft	461F2-03-A	1
E2	Vise Cylinder		1
E3	Hex. Socket Cap Screw	M10x35L	4
E4	Spring Washer	M10	4
E9	Oilless Bushing	461F4	2
E10	Spring Pin	10x30L	2
E11	Hex. Cap Steel Screw	M12x40L	6
E12	Spring Washer	M12	6
E13	Oil Nipple	1/8"PT	1
E13-1	Set Screw	M10x25L	3
E13-2	Nut	M10	3
E13-3	Oil Nipple	1/8"PT	1
E14-1	Cylinder Bracket	461F3-09-A	1
E15-1	Vise Jaw	461F2-05-A	1
E16	Hex. Socket Cap Screw	M16x25L	1
E17	Hex. Socket Cap Screw	M14x25L	1
E18-1	Lateral Adjusting Plate	461F2-06-C	1
E18-2	Upper Slider Block	461F2-06	1
E18-3	Set Screw	M10x25L	2
E19	Zero Point Sensor		1
E20	Sensor Bracket	461F3-15	1
E21	Spring Washer	M8	2
E22	Hex. Socket Cap Screw	M8x16L	2
E26-1	Adjusting Plate	461F2-06-B	1
E26-2	Cover	461F2-06-A	1
E26-3	Hex. Socket Cap Screw	M6x20L	4
E26-4	Nut	M6	4
E26-5	Set Screw	M6x25L	4
E26-6	Oil Nipple	1/8"PT	1
E26-7	Hex. Socket Cap Screw	M10x25L	4
E26-8	Hex. Socket Cap Screw	M6x50L	2
E31	Flat Head Screw	3/4"x1-1/4"L	2
E32	Fixing Bracket	461F3-08	1



Item	Description	Size No.	Qty.
E33	Hex. Cap Bolt	M12x30L	4
E34	Spring Washer	M12	4
E35	Set Screw	M10x16L	4
E36	C Ring	S60	2
E37	Press Cylinder		1
E38	Oilless Bushing 5540	461D5-10	2
E39	Guide Shaft	461F2-02	1
E40	Outlet Plate	461F3-06	1
E41	Flat Head Screw	M12x35L	1
E42	PU		1
E43	O Ring P60	S138F5-01	2
E44	Tighten Plate	331D2-06-A	1
E45	Hex. Socket Cap Screw	M8x20L	8
E46	Set Screw	M6x25L	1
E47	Upper Cover	331D2-06	1
E48	Bearing 30312	331D5-12	2
E49	Swiveling Shaft	331D2-03	1
E50	Hex. Socket Cap Screw	M10x20L	5
E51	Angle Plate	461F1-05	1
E52	Spring Pin	8x20L	2
E53	C Ring S20		2
E54	Cylinder Support Rod	461F2-16	1
E55	Lower Bracket	461F1-07	1
E56	Nut	M20	1
E57	Hex. Cap Bolt	M20x65L	1
E58	Hex. Cap Bolt	M10x60L	1
E59	Nut	M10	1
E60	Swiveling Seat	460D1-06	1
E61	Lower Bracket	461D1-17	1
E62	Spring Washer	M8	4
E63	Hex. Socket Cap Screw	M8x25L	4
E64	Lower Cover	331D2-05	1
E65	Hex. Socket Cap Screw	M8x20L	8
E66	Button Head Socket Screw	M8x12L	3
E67-1	Guide Plate	461F3-16-A	1




Item	Description	Size No.	Qty.
E71-1	Rear Fixed Vise	461F1-10-A	1
E71-2	Rear Vise Steel Plate	461F2-07	2
E71-3	Flat Head Screw	M6x15L	16
E71-4	Plate	461F2-09	1
E71-5	Spring Pin	8x20L	2
E73-1	Hex. Socket Cap Screw	M12x45L	6
E74	Hex. Socket Cap Screw	M12x60L	1
E75	Upper Clamping Block	461F2-12	1
E76	Attached Plate	461F2-12-B	1
E77	Flat Head Screw	M6x12L	2
E78	Flat Head Screw	M6x12L	2
E79	Attached Plate	461F2-12-B	1
E80	Lower Clamping Block	461F2-12-A	1
E81	Hex. Cap Bolt	M12x50L	1
E82	Nut	M12	1
E83	0° Position Bracket	461D3-08	1
E84	Hex. Socket Cap Screw	M12x40L	2
E85	Hex. Socket Cap Screw	M8x70L	2
E86	Angle Lock Bracket	461F3-18	1
E87	Nut	M8	2
E88	Hex. Socket Cap Screw	M10x35L	4
E89	Seating Block	331D2-04	2
E90	Hex. Cap Steel Screw	M10x25L	2
E91	Spring Washer	M10	2
E92	Spring Pin	8x20L	2
E93	Spring Pin	8x20L	2
E94	Supporting Bracket	461D3-03-C	1
E95	Spring Pin	8x20L	2
E96	Cutting Plate	461F2-25	1
E97	Flat Head Screw	M8x16L	8
E98	Cutting Table	461F1-08	1
E99	Hex. Socket Cap Screw	M10x70L	6
E100	Cutting Table Seat	461F1-01	1
E101	Feeding Cylinder		1
E102	Spring Washer	M10x35L	4



Item	Description	Size No.	Qty.
E103	Hex. Socket Cap Screw	M10	4
E104	Lateral Plate	461F3-06-A	1
E105	Hex. Cap Bolt	M12x25L	2
E106	Spring Washer	M12	2
E107	Washer	M12	2
E108	Hex. Socket Cap Screw	M6x20L	2
E109	Spring Washer	M6	2
E110	Coolant Gun Holder	S138F3-20	1
E111	Retrieval Table	461F3-06	1
E112	Hex. Cap Bolt	M12x25L	4
E113	Spring Washer	M12	4
E114	Washer	M12	4
E115	Hex. Cap Bolt	M10x12L	1
E116	Spring Washer	M10	1
E117	Washer	M10	1
E118	Left Lateral Plate	461F3-14	1
E119	Set Screw	M8x6L	2
E120	Adjusting Shaft	461F2-11	1
E121	Position Bracket	S138F3-27-A	1
E122	Hex. Socket Cap Screw	M8x25L	4
E123	Bakelite Ball 2"x1/2"x12W	S1380403	1
E124	Lock Handle 3/8"W	9160504-1	1
E125	Position Screw	S20A2-01	1
E126	Adjusting Plate	S138F3-29	1
E127	POM Washer	S138F2-26-B	1
E128	Washer	S138F2-26-A	1
E129	Nylon Nut	M10	1



PARTS DIAGRAM F





Parts List F


Item	Description	Size No.	Qty.
F1	Button Head Socket Screw	M6x8L	8
F2	Cover	L25A3-09-A	1
F3	Rubber Seal	L25A5-38	1
F4	Set Screw	M6x6L	2
F5	Small Chain Wheel	L46N2-63-A	1
F6	Chain L25A5-30+	L25A5-30A	1
F7	Key	5x5x20L	2
F8	Small Chain Wheel Shaft	L25A2-63	1
F9	Oilless Bush 1625	L40N5-08-1	1
F10	Conveyer Base	L25A3-06-A	1
F11	Small Shaft Bush	L25A2-63-A	1
F12	O Ring P-32	S138F5-02	1
F13	Set Screw	M6x8L	8
F14	Rubber Cover SJD16	L46N5-31	2
F15	Drive Shaft	L25A2-64	1
F16	Universal Joint SJD16	L46N5-30	2
F17	Oil Seal 16x26x7	L46N4-11	1
F18	Hex. Socket Cap Screw	M6x12L	2
F19	C Ring	S-16	1
F20	Hex. Socket Cap Screw	M6x12L	3
F21	Hydraulic Motor		1
F22	Conveyer Screw	L25A2-53-A	1
F23	Hex. Socket Cap Screw	M8x55L	1
F24	Nut	M8	1
F25	Large Chain Wheel Shaft	L25A2-63-B	1
F26	Key	5x5x20L	1
F27	Oil Seal 16x26x7	L46N4-11	1
F28	O Ring P32	S138F5-02	1
F29	Shaft Bush	L25A2-63-C	1
F30	Hex. Socket Cap Screw	M6x8L	2
F31	Oilless Bush 1625	L40N5-08-1	1
F32	Large Chain Wheel	L46N2-63	1
F33	Set Screw	M6x6L	2



Item	Description	Size No.	Qty.
F34	Adjusting Bracket	S138F3-34-F	1
F35	Plate	461F3-11	1
F36	Encoder Plate	S138F3-34-E	1
F37	Hex. Socket Cap Screw	3/16"x3/8"L	4
F38	Spring Washer	1/4"	4
F39	Round Head Screw	1/4"x1/2"L	4
F40	Set Screw	M4x4L	2
F41	Small Gear	S138F2-11	1
F42	Oilless Bushing	608	1
F43	Round Head Screw	3/16"x1/4"L	3
F44	Fixed Plate	S138F3-34-B	1
F45	Steel Pin	6x30L	1
F46	Shaft Coupling	SWS-16C	1
F47	Encoder Bracket	S138F3-34	1
F48	Round Head Screw	3/16"x1/4"L	4
F49	Round Head Screw	3/16"x1/4"L	3
F50	Encoder		1
F51	Encoder Cover	S138F3-34-A	1



PARTS DIAGRAM G





Parts List G

Item	Description	Size No.	Qty.
G1	Bearing Long Shaft	L46N2-19	2
G2	Bearing 6201	L25A5-03	4
G3	Bearing Bush (Long)	460D2-63	1
G4	Bearing Bush (Short)	L46N2-19-A	1
G5	Spring Washer	M10	2
G6	Nut	M10	2
G7	Hex. Socket Cap Screw	M6x20L	2
G8	Adjusting Screw	L46N2-33	1
G9	Spring	460D4-11	1
G10	Guide Pin	3500210	1
G11	Hex. Socket Cap Screw	M8x40L	1
G12	Front Bearing Seat	460D1-09	1
G13	Bearing 6200	L25A5-01	2
G14	Bearing Bracket	460D1-22	1
G15	Bush	L46N2-51-1	1
G16	Shaft	L46N2-51-2	2
G17	Carbide Guide (Left front)	L46N2-34	1
G18	Carbide Guide (Left back)	L46N2-34-1	1
G19	Spring Pin	D5x12L	2
G20	Spring Pin	D5x12L	2
G21	Carbide Guide (Right back)	L46N2-34-3	1
G22	Carbide Guide (Right front)	L46N2-34-2	1
G23	Shaft	L46N2-51-1	2
G24	Bearing Bracket	460D1-22	1
G25	Bearing 6200	L25A5-01	2
G26	Bush	L46N2-51-2	1
G27	Hex. Socket Cap Screw	M6x20L	2
G28	Rear Bearing Seat	460D1-10	1
G29	Nut	M10	2
G30	Spring Washer	M10	2
G31	Bearing Bush (Long)	460D2-63	1
G32	Hex. Socket Cap Screw	M8x40L	1
G33	Guide Pin	3500210	1



Item	Description	Size No.	Qty.
G34	Spring	460D4-11	1
G35	Adjusting Screw	L46N2-33	1
G36	Bearing 6201	L25A5-03	4
G37	Bearing Long Shaft	L46N2-19	2
G38	Bearing Bush (Short)	L46N2-19-A	1



NOTES



NOTES



BAILEIGH INDUSTRIAL, INC. 1625 DUFEEK DRIVE MANITOWOC, WI 54220

PHONE: 920. 684. 4990 FAX: 920. 684. 3944

www.baileigh.com

BAILEIGH INDUSTRIAL, INC. 1455 S. CAMPUS AVENUE ONTARIO, CA 91761

PHONE: 920. 684. 4990 FAX: 920. 684. 3944

BAILEIGH INDUSTRIAL LTD. UNIT 1 FULLWOOD CLOSE

ALDERMANS GREEN INDUSTRIAL ESTATE

COVENTRY, CV2 2SS UNITED KINGDOM

PHONE: +44 (0)24 7661 9267 FAX: +44 (0)24 7661 9276

WWW.BAILEIGHINDUSTRIAL.CO.UK

BAILEIGH INDUSTRIAL GMBH HOFENER STRAßE 64

70736 FELLBACH

DEUTCHSLAND

WWW.BAILEIGHINDUSTRIAL.DE

BAILEIGH INDUSTRIAL PTY. LTD.

P.O Box 1573, 126 MELROSE DRIVE TULLAMARINE,

VIC 3043 AUSTRALIA

WWW.BAILEIGHINDUSTRIAL.COM.AU