



OPERATOR'S MANUAL

Metal Working



DUAL MITER HORIZONTAL BAND SAW MODEL: BS-350M

Baileigh Industrial Holdings LLC
P.O. Box 531
Manitowoc, WI 54221-0531
Phone: 920.684.4990
Fax: 920.684.3944
Baileigh-Sales@jpwindustries.com

REPRODUCTION OF THIS MANUAL IN ANY FORM WITHOUT WRITTEN APPROVAL OF BAILEIGH INDUSTRIAL HOLDINGS LLC IS PROHIBITED. Baileigh Industrial Holdings LLC, Inc. does not assume and hereby disclaims any liability for any damage or loss caused by an omission or error in this Operator's Manual, resulting from accident, negligence, or other occurrence.



Table of Contents

THANK YOU & WARRANTY	1
INTRODUCTION.....	3
GENERAL NOTES.....	3
SAFETY INSTRUCTIONS	4
SAFETY PRECAUTIONS	6
Dear Valued Customer:.....	6
TECHNICAL SPECIFICATIONS	9
TECHNICAL SUPPORT	9
UNPACKING AND CHECKING CONTENTS.....	10
TRANSPORTING AND LIFTING	11
INSTALLATION.....	11
Anchoring the Machine	12
OVERALL DIMENSIONS.....	13
GETTING TO KNOW YOUR MACHINE	14
Machine Base.....	17
Quick Clamp Vise	17
Positioning the Vise	18
Return Stroke Limiting Device	19
Spring Tension for Saw Bow	19
Support Roller.....	19
Stop Rod Assembly	19
ASSEMBLY AND SET UP	20
ELECTRICAL	22
ADJUSTING THE MACHINE	24
Replacing the Saw Blade	24
Setting Blade Tension	25
Blade Breakage	25
Adjusting the Blade Tracking.....	25
Adjusting the Blade Guide	26
Adjusting the angle stops	26
Blade Guide Bearing Adjustment.....	27
BEFORE EACH USE	28
Whenever Saw is Running	28
Breaking in a Band Saw Blade	29
Metal Chip Indicators.....	29
Blade Terminology.....	30
Width of Blade	30
Length of Blade	30
Blade structure	31
Blade type	31
SETS	32
BLADE CARE	33
CHOOSING A SAW BLADE	33



BLADE BREAKAGE.....	35
OPERATION.....	36
Manual Operation.....	36
Auto Mode Operation	37
MATERIAL SELECTION.....	38
LUBRICATION AND MAINTENANCE	39
Coolant System Maintenance.....	40
Oils for Lubricating Coolant	40
Storing Machine for Extended Period of Time	40
Gearbox Maintenance	41
Oil Disposal	41
PARTS IDENTIFICATION DRAWING A.....	42
PARTS IDENTIFICATION DRAWING B.....	43
PARTS IDENTIFICATION DRAWING C.....	44
PARTS IDENTIFICATION DRAWING D.....	45
Parts List A - D	46
ELECTRICAL SCHEMATIC.....	56
Inverter Fault Codes And Troubleshooting	57
TROUBLESHOOTING	59



THANK YOU & WARRANTY

Thank you for your purchase of a machine from Baileigh Industrial Holdings LLC. We hope that you find it productive and useful to you for a long time to come.

Inspection & Acceptance. Buyer shall inspect all Goods within ten (10) days after receipt thereof. Buyer's payment shall constitute final acceptance of the Goods and shall act as a waiver of the Buyer's rights to inspect or reject the goods unless otherwise agreed. If Buyer rejects any merchandise, Buyer must first obtain a Returned Goods Authorization ("RGA") number before returning any goods to Seller. Goods returned without an RGA will be refused. Seller will not be responsible for any freight costs, damages to goods, or any other costs or liabilities pertaining to goods returned without a RGA. Seller shall have the right to substitute a conforming tender. Buyer will be responsible for all freight costs to and from Buyer and repackaging costs, if any, if Buyer refuses to accept shipment. If Goods are returned in unsalable condition, Buyer shall be responsible for full value of the Goods. Buyer may not return any special-order Goods. Any Goods returned hereunder shall be subject to a restocking fee equal to 30% of the invoice price.

Specifications. Seller may, at its option, make changes in the designs, specifications or components of the Goods to improve the safety of such Goods, or if in Seller's judgment, such changes will be beneficial to their operation or use. Buyer may not make any changes in the specifications for the Goods unless Seller approves of such changes in writing, in which event Seller may impose additional charges to implement such changes.

Limited Warranty. Seller warrants to the original end-user that the Goods manufactured or provided by Seller under this Agreement shall be free of defects in material or workmanship for a period of twelve (12) months from the date of purchase, provided that the Goods are installed, used, and maintained in accordance with any instruction manual or technical guidelines provided by the Seller or supplied with the Goods, if applicable. The original end-user must give written notice to Seller of any suspected defect in the Goods prior to the expiration of the warranty period. The original end-user must also obtain a RGA from Seller prior to returning any Goods to Seller for warranty service under this paragraph. Seller will not accept any responsibility for Goods returned without a RGA. The original end-user shall be responsible for all costs and expenses associated with returning the Goods to Seller for warranty service. In the event of a defect, Seller, at its sole option, shall repair or replace the defective Goods or refund to the original end-user the purchase price for such defective Goods. Goods are not eligible for replacement or return after a period of 10 days from date of receipt. The foregoing warranty is Seller's sole obligation, and the original end-user's exclusive remedy, with regard to any defective Goods. This limited warranty does not apply to: (a) die sets, tooling, and saw blades; (b) periodic or routine maintenance and setup, (c) repair or replacement of the Goods due to normal wear and tear, (d) defects or damage to the Goods resulting from misuse, abuse, neglect, or accidents, (f) defects or damage to the Goods resulting from improper or unauthorized alterations, modifications, or changes; and (f) any Goods that has not been installed and/or maintained in accordance with the instruction manual or technical guidelines provided by Seller.

EXCLUSION OF OTHER WARRANTIES. THE FOREGOING LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. ANY AND ALL OTHER EXPRESS, STATUTORY OR IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE ARE EXPRESSLY DISCLAIMED. NO WARRANTY IS MADE WHICH EXTENDS BEYOND THAT WHICH IS EXPRESSLY CONTAINED HEREIN.

Limitation of Liability. IN NO EVENT SHALL SELLER BE LIABLE TO BUYER OR ANY OTHER PARTY FOR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES (INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR DOWN TIME) ARISING FROM OR IN MANNER CONNECTED WITH THE GOODS, ANY BREACH BY SELLER OR ITS AGENTS OF THIS AGREEMENT, OR ANY OTHER CAUSE WHATSOEVER, WHETHER BASED ON CONTRACT, TORT OR ANY OTHER THEORY OF LIABILITY. BUYER'S REMEDY WITH RESPECT TO ANY CLAIM ARISING UNDER THIS AGREEMENT IS STRICTLY LIMITED TO NO MORE THAN THE AMOUNT PAID BY THE BUYER FOR THE GOODS.



Force Majeure. Seller shall not be responsible for any delay in the delivery of, or failure to deliver, Goods due to causes beyond Seller's reasonable control including, without limitation, acts of God, acts of war or terrorism, enemy actions, hostilities, strikes, labor difficulties, embargoes, non-delivery or late delivery of materials, parts and equipment or transportation delays not caused by the fault of Seller, delays caused by civil authorities, governmental regulations or orders, fire, lightening, natural disasters or any other cause beyond Seller's reasonable control. In the event of any such delay, performance will be postponed by such length of time as may be reasonably necessary to compensate for the delay.

Installation. If Buyer purchases any Goods that require installation, Buyer shall, at its expense, make all arrangements and connections necessary to install and operate the Goods. Buyer shall install the Goods in accordance with any Seller instructions and shall indemnify Seller against any and all damages, demands, suits, causes of action, claims and expenses (including actual attorneys' fees and costs) arising directly or indirectly out of Buyer's failure to properly install the Goods.

Work By Others; Safety Devices. Unless agreed to in writing by Seller, Seller has no responsibility for labor or work performed by Buyer or others, of any nature, relating to design, manufacture, fabrication, use, installation or provision of Goods. Buyer is solely responsible for furnishing and requiring its employees and customers to use all safety devices, guards and safe operating procedures required by law and/or as set forth in manuals and instruction sheets furnished by Seller. Buyer is responsible for consulting all operator manuals, ANSI or comparable safety standards, OSHA regulations and other sources of safety standards and regulations applicable to the use and operation of the Goods.

Remedies. Each of the rights and remedies of Seller under this Agreement is cumulative and in addition to any other or further remedies provided under this Agreement or at law or equity.

Attorney's Fees. In the event legal action is necessary to recover monies due from Buyer or to enforce any provision of this Agreement, Buyer shall be liable to Seller for all costs and expenses associated therewith, including Seller's actual attorney fees and costs.

Governing Law/Venue. This Agreement shall be construed and governed under the laws of the State of Wisconsin, without application of conflict of law principles. Each party agrees that all actions or proceedings arising out of or in connection with this Agreement shall be commenced, tried, and litigated only in the state courts sitting in Manitowoc County, Wisconsin or the U.S. Federal Court for the Eastern District of Wisconsin. Each party waives any right it may have to assert the doctrine of "forum non conveniens" or to object to venue to the extent that any proceeding is brought in accordance with this section. Each party consents to and waives any objection to the exercise of personal jurisdiction over it by courts described in this section. Each party waives to the fullest extent permitted by applicable law the right to a trial by jury.

Summary of Return Policy.

- 10 Day acceptance period from date of delivery. Damage claims and order discrepancies will not be accepted after this time.
- You must obtain a Baileigh issued RGA number PRIOR to returning any materials.
- Returned materials must be received at Baileigh in new condition and in original packaging.
- Altered items are not eligible for return.
- Buyer is responsible for all shipping charges.
- A 30% re-stocking fee applies to all returns.

Baileigh Industrial Holdings LLC makes every effort to ensure that our posted specifications, images, pricing and product availability are as correct and timely as possible. We apologize for any discrepancies that may occur. Baileigh Industrial Holdings LLC reserves the right to make any and all changes deemed necessary in the course of business including but not limited to pricing, product specifications, quantities, and product availability.

For Customer Service & Technical Support:

Please contact one of our knowledgeable Sales and Service team members at:
(920) 684-4990 or e-mail us at Baileigh-Service@jpwindustries.com



INTRODUCTION

The quality and reliability of the components assembled on a Baileigh Industrial Holdings LLC machine guarantee near perfect functioning, free from problems, even under the most demanding working conditions. However, if a situation arises, refer to the manual first. If a solution cannot be found, contact the distributor where you purchased our product. Make sure you have the serial number and production year of the machine (stamped on the nameplate). For replacement parts refer to the assembly numbers on the parts list drawings.

Our technical staff will do their best to help you get your machine back in working order.

In this manual you will find: (when applicable)

- Safety procedures
- Correct installation guidelines
- Description of the functional parts of the machine
- Capacity charts
- Setup and start-up instructions
- Machine operation
- Scheduled maintenance
- Parts lists

GENERAL NOTES

After receiving your equipment remove the protective container. Do a complete visual inspection, and if damage is noted, **photograph it for insurance claims** and contact your carrier at once, requesting inspection. Also contact Baileigh Industrial Holdings LLC and inform them of the unexpected occurrence. Temporarily suspend installation.

Take necessary precautions while loading / unloading or moving the machine to avoid any injuries.

Your machine is designed and manufactured to work smoothly and efficiently. Following proper maintenance instructions will help ensure this. Try and use original spare parts, whenever possible, and most importantly; **DO NOT** overload the machine or make any modifications.




Note: This symbol refers to useful information throughout the manual.



IMPORTANT

PLEASE READ THIS OPERATORS MANUAL CAREFULLY

It contains important safety information, instructions, and necessary operating procedures. The continual observance of these procedures will help increase your production and extend the life of the equipment.



SAFETY INSTRUCTIONS

LEARN TO RECOGNIZE SAFETY INFORMATION

This is the safety alert symbol. When you see this symbol on your machine or in this manual, **BE ALERT TO THE POTENTIAL FOR PERSONAL INJURY!**



Follow recommended precautions and safe operating practices.

UNDERSTAND SIGNAL WORDS

A signal word – **DANGER**, **WARNING**, or **CAUTION** – is used with the safety alert symbol. **NOTICE**, which is not related to personal injury, is used without a symbol.

DANGER: Indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING: Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION: Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE: Indicates a situation which, if not avoided, could result in property damage.

DANGER

WARNING

CAUTION

NOTICE




SAVE THESE INSTRUCTIONS.
Refer to them often and use them to instruct others.




PROTECT EYES

Wear safety glasses or suitable eye protection when working on or around machinery.



PROTECT AGAINST NOISE

Prolonged exposure to loud noise can cause impairment or loss of hearing. Wear suitable hearing protective devices such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.




CALIFORNIA PROPOSITION 65

WARNING: Cancer and Reproductive Harm.
www.P65Warnings.ca.gov



BEWARE OF CUT AND PINCH POINTS

Moving saw blade may result in loss of fingers or limb. **DO NOT** operate with guard removed. **Follow lockout/tagout procedures before servicing.**




HIGH VOLTAGE

USE CAUTION IN HIGH VOLTAGE AREAS. DO NOT assume the power to be off.
FOLLOW PROPER LOCKOUT PROCEDURES.



EMERGENCY STOP BUTTON

In the event of incorrect operation or dangerous conditions, the machine can be stopped immediately by pressing the **E-STOP** button. Twist the emergency stop button clockwise (cw) to reset. Note: Resetting the E-Stop will not start the machine.





SAFETY PRECAUTIONS



Metal working can be dangerous if safe and proper operating procedures are not followed. As with all machinery, there are certain hazards involved with the operation of the product. Using the machine with respect and caution will considerably lessen the possibility of personal injury. However, if normal safety precautions are overlooked or ignored, personal injury may result. Safety equipment such as guards, hold-downs, safety glasses, dust masks and hearing protection can reduce your potential for injury. But even the best guard will not make up for poor judgment, carelessness or inattention. **Always use common sense** and exercise **caution** in the workshop. If a procedure feels dangerous, don't try it.

REMEMBER: Your personal safety is your responsibility.



**WARNING: FAILURE TO FOLLOW THESE RULES MAY RESULT IN
SERIOUS PERSONAL INJURY**

Dear Valued Customer:

- All Baileigh machines should be used only for their intended use.
- Baileigh does not recommend or endorse making any modifications or alterations to a Baileigh machine. Modifications or alterations to a machine may pose a substantial risk of injury to the operator or others and may do substantial damage to the machine.
- Any modifications or alterations to a Baileigh machine will invalidate the machine's warranty.

PLEASE ENJOY YOUR BAILEIGH MACHINE!PLEASE ENJOY IT SAFELY!

1. **FOR YOUR OWN SAFETY, READ INSTRUCTION MANUAL BEFORE OPERATING THE MACHINE.** Learn the machine's application and limitations as well as the specific hazards.
2. **Only trained and qualified personnel can operate this machine.**
3. **Make sure guards are in place and in proper working order before operating machinery.**
4. **Remove any adjusting tools.** Before operating the machine, make sure any adjusting tools have been removed.
5. **Keep work area clean.** Cluttered areas invite injuries.
6. **Overloading machine.** By overloading the machine, you may cause injury from flying parts. **DO NOT** exceed the specified machine capacities.
7. **Dressing material edges.** Always chamfer and deburr all sharp edges.
8. **Do not force tool.** Your machine will do a better and safer job if used as intended. **DO NOT** use inappropriate attachments in an attempt to exceed the machine's rated capacity.



9. **Use the right tool for the job. DO NOT** attempt to force a small tool or attachment to do the work of a large industrial tool. **DO NOT** use a tool for a purpose for which it was not intended.
10. **Dress appropriately. DO NOT** wear loose fitting clothing or jewelry as they can be caught in moving machine parts. Protective clothing and steel toe shoes are recommended when using machinery. Wear a restrictive hair covering to contain long hair.
11. **Use eye protection.** Always wear ISO approved protective eye wear when operating machinery. Wear a full-face shield if you are producing metal filings. Eye wear shall be impact resistant, protective safety glasses with side shields which comply with ANSI Z87.1 specification. Use of eye wear which does not comply with ANSI Z87.1 specification could result in severe injury from breakage of eye protection.
12. **Do not overreach.** Maintain proper footing and balance at all times. **DO NOT** reach over or across a running machine.
13. **Stay alert.** Watch what you are doing and use common sense. **DO NOT** operate any tool or machine when you are tired.
14. **Check for damaged parts.** Before using any tool or machine, carefully check any part that appears damaged. Check for alignment and binding of moving parts that may affect proper machine operation.
15. **Observe work area conditions. DO NOT** use machines or power tools in damp or wet locations. Do not expose to rain. Keep work area well lighted. **DO NOT** use electrically powered tools in the presence of flammable gases or liquids.
16. **Blade adjustments and maintenance.** Always keep blades sharp and properly adjusted for optimum performance.
17. **Keep children away.** Children must never be allowed in the work area. **DO NOT** let them handle machines, tools, or extension cords.
18. Keep visitors a safe distance from the work area.
19. **Store idle equipment.** When not in use, tools must be stored in a dry location to inhibit rust. Always lock up tools and keep them out of reach of children.
20. **DO NOT operate machine if under the influence of alcohol or drugs.** Read warning labels on prescriptions. If there is any doubt, **DO NOT** operate the machine.
21. **Turn off** power before checking, cleaning, or replacing any parts.
22. Be sure **all** equipment is properly installed and grounded according to national, state, and local codes.
23. Keep **all** cords dry, free from grease and oil, and protected from sparks and hot metal.
24. Inspect power and control cables periodically. Replace if damaged or bare wires are exposed. **Bare wiring can kill!** **DO NOT** touch live electrical components or parts.
25. **DO NOT** bypass or defeat any safety interlock systems.



WARNING: This product can expose you to chemicals including titanium dioxide which is known to the State of California to cause cancer, and lead which is known to the State of California to cause cancer and birth defects or other reproductive harm.

For more information go to <http://www.p65warnings.ca.gov>.



WARNING: Some dust, fumes and gases created by power sanding, sawing, grinding, drilling, welding, and other construction activities contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Some examples of these chemicals are:

- lead from lead-based paint.
- crystalline silica from bricks, cement, and other masonry products.
- arsenic and chromium from chemically treated lumber.

Your risk of exposure varies, depending on how often you do this type of work. To reduce your exposure to these chemicals, work in a well-ventilated area and work with approved safety equipment, such as dust masks that are specifically designed to filter out microscopic particles.

For more information go to <http://www.p65warnings.ca.gov/> and [http:// www.p65warnings. ca.gov/ wood](http://www.p65warnings.ca.gov/wood).



TECHNICAL SPECIFICATIONS

Capacity Rectangular 90°	13.5" x 8.5" (350 x 220mm)
Capacity Round 90° / 45° / 60° / 45°L	10.43" / 9.5" / 5.31" / 8" (265 / 240 / 135 / 210mm)
Capacity Square 90° / 45° / 60° / 45°L	10.25" / 5.9" / 3.54" / 6.29" (260 / 150 / 90 / 160mm)
Return	Manual
Miter Adjustment	Swivel Head
Miter Angle	0 - 60°R, 0 - 45°L
Blade Size (H x T x L)	1" x .035" x 124.5" (26 x .9 x 3160mm)
Blade Speed (fpm)	66 – 280fpm (20 – 85mpm) Variable
Blade Guide	Carbide x Roller
Table Height	33.85" (860mm)
Drive	Gear
Descent Control	Hydraulic
Power Input	220V, 60Hz, 1-Phase, 12A
Main Motor	220V, 60hz, 3Ph, 6.2A, 2hp (1.5kw), 1720rpm
Coolant Pump	220V, 60Hz, 1Ph, .40A, 32W, 2800rpm
Shipping Weight	902lbs (410kgs)
Shipping Dimensions (L x W x H)	72.5" x 29.5" x 43" (1841 x 749 x 1092mm)

TECHNICAL SUPPORT

Our technical support department can be reached at 920.684.4990 and asking for the support desk for purchased machines. Or (Baileigh-Service@jpwindustries.com) Tech Support handles questions on machine setup, schematics, warranty issues, and individual parts needs: (other than die sets and blades).

For specific application needs or future machine purchases contact the Sales Department at: Baileigh-Sales@jpwindustries.com, Phone: 920.684.4990, or Fax: 920.684.3944.



Note: The photos and illustrations used in this manual are representative only and may not depict the actual color, labeling or accessories and may be intended to illustrate technique only.



Note: The specifications and dimensions presented here are subject to change without prior notice due to improvements of our products.



UNPACKING AND CHECKING CONTENTS

Your Baileigh machine is shipped complete. Separate all parts from the packing material and check each item carefully. Make certain all items are accounted for before discarding any packing material.



WARNING: SUFFOCATION HAZARD! Immediately discard any plastic bags and packing materials to eliminate choking and suffocation hazards to children and animals.

If any parts are missing, **DO NOT** place the machine into service until the missing parts are obtained and installed correctly.

Cleaning



WARNING: DO NOT USE gasoline or other petroleum products to clean the machine. They have low flash points and can explode or cause fire.



CAUTION: When using cleaning solvents work in a well-ventilated area. Many cleaning solvents are toxic if inhaled.

Your machine may be shipped with a rustproof waxy coating and/or grease on the exposed unpainted metal surfaces. Fully and completely remove this protective coating using a degreaser or solvent cleaner. Moving items will need to be moved along their travel path to allow for cleaning the entire surface. For a more thorough cleaning, some parts will occasionally have to be removed. **DO NOT USE** acetone or brake cleaner as they may damage painted surfaces.

Follow manufacturer's label instructions when using any type of cleaning product. After cleaning, wipe unpainted metal surfaces with a light coating of quality oil or grease for protection.



Important: This waxy coating is **NOT** a lubricant and will cause the machine to stick and lose performance as the coating continues to dry.







TRANSPORTING AND LIFTING

NOTICE: *Lifting and carrying operations should be carried out by skilled workers, such as a truck operator, crane operator, etc. If a crane is used to lift the machine, attach the lifting chain carefully, making sure the machine is well balanced.*

Follow these guidelines when lifting with truck or trolley:

- The lift truck must be able to lift at least 1.5 – 2 times the machines gross weight.
- Make sure the machine is balanced. While transporting, avoid rough or jerky motion, and maintain a safe clearance zone around the transport area.
- Use a forklift with sufficient lifting capacity and forks that are long enough to reach the complete width of the machine.
- Remove the securing bolts that attach the machine to the pallet.
- Approaching the machine from the side, lift the machine on the frame taking care that there are no cables or pipes in the area of the forks.
- Move the machine to the required position and lower gently to the floor.
- Level the machine so that all the supporting feet are taking the weight of the machine and no rocking is taking place.



INSTALLATION

IMPORTANT:

Consider the following when looking for a suitable location to place the machine:


- Overall weight of the machine.
- Weight of material being processed.
- Sizes of material to be processed through the machine.
- Space needed for auxiliary stands, worktables, or other machinery.
- Clearance from walls and other obstacles.
- Maintain an adequate working area around the machine for safety.



- Have the work area well illuminated with proper lighting.
- Keep the floor free of oil and make sure it is not slippery.
- Remove scrap and waste materials regularly, and make sure the work area is free from obstructing objects.
- If long lengths of material are to be fed into the machine, make sure that they will not extend into any aisles.
- **LEVELING:** The machine should be sited on a level, concrete floor. Provisions for securing it should be in position prior to placing the machine. The accuracy of any machine depends on the precise placement of it to the mounting surface.
- **FLOOR:** This machine distributes a large amount of weight over a small area. Make certain that the floor is capable of supporting the weight of the machine, work stock, and the operator. The floor should also be a level surface. If the unit wobbles or rocks once in place, be sure to eliminate by using shims.
- **WORKING CLEARANCES:** Take into consideration the size of the material to be processed. Make sure that you allow enough space for you to operate the machine freely.
- **POWER SUPPLY PLACEMENT:** The power supply should be located close enough to the machine so that the power cord is not in an area where it would cause a tripping hazard. Be sure to observe all electrical codes if installing new circuits and/or outlets.



Anchoring the Machine

- Once positioned, anchor the machine to the floor, as shown in the diagram. Use bolts and expansion plugs or sunken tie rods that connect through and are sized for the holes in the base of the stand.
- This machine requires a solid floor such as concrete at a minimum of 4" (102mm) thick. 6" (153mm) minimum is preferred.






OVERALL DIMENSIONS





GETTING TO KNOW YOUR MACHINE





A	Vise Hand Wheel	Turning hand-wheel opens and closes vise
B	Vise Lever	To quickly clamp and unclamp material
C	Vise	Holds front and rear jaws for clamping
D	Blade Tension Hand Wheel	For applying and releasing blade tension
E	Blade Tension Gauge	Reads tension in Kgs/cm ²
F	Trigger Switch	For starting saw motor in manual mode
G	Blade Adjustment Assembly	Adjusts front end of blade
H	Blade Adjustment Assembly	Adjusts rear end of blade
I	Ball Valve	Starts and stops the blade descent
J	Control Box	Houses the operator controls
K	Motor/Gearbox	Drives the saw blade
L	Spring Adjustment Knob	Sets spring tension
M	Micro Switch – Bottom of Stroke	Shuts off saw when finished cutting
N	Coolant Pump	Recirculates blade coolant
O	Stop Rod Assembly	For setting the length of cut
P	Saw Stand	Supports the saw assembly
Q	Angle Indicator	Shows angular cutting degrees
R	Miter Lock Lever	Tightens and loosens table to set angles
S	Track Lock	Allows vise to slide forward or aft in tack.
T	Vise Slide Lock	Locks vise in slideways to be clear of blade for angle cuts.
U	Micro Switch – Blade Break	Shuts off saw if the saw blade breaks.



1. Power Indicator Light: (Lights “white” when power is on).
2. Start Pushbutton: (Starts saw motor in Auto mode).
3. E-Stop Pushbutton: (Saw can be stopped immediately by pressing the red mushroom cap button) Twist the button clockwise (cw) to reset. Resetting the E-Stop will not start the saw.
4. Speed Control: (Sets blade speed from 20-85 mpm) Has an OFF position to shut off power.
5. Main Disconnect Switch: (Turns power ON to the saw) Can be locked out in the OFF position for Safety or Security.
6. 2-Position Mode Switch: (Selects between auto mode, clockwise (cw) and trigger control, counterclockwise (ccw)).
7. Blade Speed Display: Indicates the approximate speed of the blade in MPM (meters per minute).




Machine Base

After assembly, the machine base becomes the structure that supports the saw bow, the vise, the coolant pump, the bar stop, the swing arm, and the roller for supporting material.



Quick Clamp Vise

Place the piece part between the vise jaws and have it rest next to the fixed vise jaw. Rotate the hand wheel (**A**) clockwise (**cw**) to close the front jaw onto the piece and tighten. Rotate the hand wheel counterclockwise (**ccw**) to release. Vise lever (**B**) can be used to quickly lock and release the piece part by allowing a small gap between the vise and part. Then rotate lever (**B**) counterclockwise (**ccw**) to lock and clockwise (**cw**) to release.



Swivel Saw Head


Angles can be cut up to 60° (Right) with vise left and 45° (Left) with vise right. Unlock the rotating saw head by pushing the miter lock lever (**R**) to the left and by retracting stop pin (**W**). Rotate the saw head to the desired angle as shown on the angle indicator (**Q**). Lock the saw head by pushing the lock lever (**R**) to the right (as shown).



Note: Pin (**W**) has stops at 0° & 45° (Right).



IMPORTANT: Check that the saw blade clears all parts of the vise assembly before cutting. The blade can strike parts of the assembly (especially during miter cuts) if not properly adjusted. Make sure saw bow is in a down or horizontal position when moving or mitering to avoid tipping over machine.





Positioning the Vise




To move the vise in either direction, it must be unlocked at two points.

- Release the track support by turning handle (S) counterclockwise (ccw).
- Release the vise by moving the lever (T) to the left.
- The vise (C) may now be moved to the left position or the right position by pushing it with one hand on the vise and the other hand on the track handle (S).




IMPORTANT: Do not attempt a 90° cut with vise in the Right position. You may damage the front jaw.

- Once in position, move the lever (T) to the right to lock the vise. If the lever is not between the vise/bed mounts and facing the operator, the vise will not be able to lock. If the vise lever has gone beyond or is obstructed by a mount, correct with the following procedure:
- Adjust lever (T) by grasping the pivot hub (V) and pulling down. Rotate the handle into a more suitable position. Some movement of the vise may be required.
- Release the lever hub and rotate the handle to the right to lock.
- Lock the track support handle (S) by turning clockwise (cw).



Left



Right



Return Stroke Limiting Device

A hydraulic cylinder is used to control the drop rate of the saw bow. The hydraulic cylinder is ideal when cutting thin walled or stainless steel sections as they require a constant drop rate to achieve a fine cut edge.



Spring Tension for Saw Bow

When set for auto mode the fork handle does not engage the sliding spring pin. Therefore there is limited spring assistance to the saw bow. When setting for manual mode the fork handle spring knob will drop into the pin hole. When manually lowering the saw bow the spring tension will now serve as a useful counterbalance for the operator.



Support Roller

A device that helps support longer sized material. The roller assists stock moving through the vise. It is adjustable by loosening (2) hex bolts.



Stop Rod Assembly

The stop rod is used when cutting duplicate parts thus eliminating the need to measure each piece.






ASSEMBLY AND SET UP



WARNING: For your own safety, **DO NOT** connect the machine to the power source until the machine is completely assembled and you read and understand the entire instruction manual.


1. Assemble the stand as shown. (Refer to Parts Identification Drawing for required fasteners.) Make sure all nuts and bolts are properly tightened.





2. Using the (4) lifting lugs, pick up the saw and carefully set it onto the stand and bolt together.
3. Set the coolant tank on the bottom shelf as shown and attach with hex bolts and flatwashers.
4. Place filter basket into hole and place drain hose into basket.

Filter Basket



5. Attach electrical control box to the pedestal with (4) hex socket capscrews.





ELECTRICAL



CAUTION: HAVE ELECTRICAL UTILITIES CONNECTED TO MACHINE BY A CERTIFIED ELECTRICIAN!

Check if the available power supply is the same as listed on the machine nameplate.



WARNING: Make sure the grounding wire (green) is properly connected to avoid electric shock. DO NOT switch the position of the green grounding wire if any electrical plug wires are switched during hookup.

Power Specifications

Your machine is wired for 220 volts, 60hz alternating current. Before connecting the machine to the power source, make sure the power source is OFF.

Before switching on the power, you must check the voltage and frequency of the power to see if they meet with the requirement, the allowed range for the voltage is $\pm 5\%$, and for the frequency is $\pm 1\%$.

Considerations

- Observe local electrical codes when connecting the machine.
- The circuit should be protected with a time delay fuse or circuit breaker with an amperage rating slightly higher than the full load current of machine.
- A separate electrical circuit should be used for your machines. Before connecting the motor to the power line, make sure the switch is in the "OFF" position and be sure that the electric current is of the same characteristics as indicated on the machine.
- All line connections should make good contact. Running on low voltage will damage the motor.
- In the event of a malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This machine is equipped with an electric cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into a matching outlet that is properly installed and grounded in accordance with all local codes and ordinances.



WARNING: In all cases, make certain the receptacle in question is properly grounded. If you are not sure, have a qualified electrician check the receptacle.



- Improper connection of the equipment-grounding conductor can result in risk of electric shock. The conductor with insulation having an outer surface that is green with or without yellow stripes is the equipment-grounding conductor. If repair or replacement of the electric cord or plug is necessary, do not connect the equipment-grounding conductor to a live terminal.
- Check with qualified electrician or service personnel if the grounding instructions are not completely understood, or if in doubt as to whether the machine is properly grounded.
- Repair or replace damaged or worn cord immediately.

Extension Cord Safety

Extension cord should be in good condition and meet the minimum wire gauge requirements listed below:

AMP RATING	LENGTH		
	25ft	50ft	100ft
1-12	16	16	14
13-16	14	12	12
17-20	12	12	10
21-30	10	10	No
WIRE GAUGE			

An undersized cord decreases line voltage, causing loss of power and overheating. All cords should use a ground wire and plug pin. Replace any damaged cords immediately.

Power cord connection:

1. Turn the main disconnect switch on the control panel to the OFF position.
2. Unwrap the power cord and route the cord away from the table toward the power supply.
 - a. Route the power cord so that it will NOT become entangled in the saw bow, saw blade, or counterbalance assembly in any way.
 - b. Route the cord to the power supply is a way that does NOT create a trip hazard.
3. Install a properly rated plug (customer supplied) onto the end of the power cord.
4. Connect the power cord to the power supply and check that the power cord has not been damaged during installation.
5. When the saw blade is clear of any obstruction and raised up off of the limit switch. The main disconnect may be turn ON to test the saw operation. Turn the main disconnect to OFF when the saw is not in operation.



ADJUSTING THE MACHINE



WARNING: Make sure the electrical disconnect is OFF before working on the machine.



Always follow proper safety precautions when working on or around any machinery.

Replacing the Saw Blade

Wear gloves when handling the saw blade.

1. Raise the saw bow.
2. Remove the front blade guard (X) and the (4) knobs (Y) holding on the main blade guard. (Carefully pull out the tongue from the safety interlock switch)
3. Loosen the saw blade with the tension hand wheel (D) and remove it from the flywheels and the blade guide blocks.
4. Assemble the new blade by placing it first between the guide blocks and then on the face of the flywheels. (note blade direction)
5. Tension the blade, making sure it seats properly on the flywheels.
6. Reassemble the front blade guide (X) and the main blade guard (Z), making sure the switch tongue engages the switch or the saw will not start.

BLADE DIRECTION OF TRAVEL





Setting Blade Tension


Blade tension is important to the proper operation of the saw. Correct blade tension is 140 kg/cm² as measured on the saws pressure tension gauge.

Turning the handwheel (**D**) clockwise (**cw**) will increase the tension. Counterclockwise (**ccw**) will decrease tension of the saw blade.



Blade Breakage



If the saw is running and the blade breaks, the micro-switch (**U**) will trip and shut down all machine functions. As long as the replacement blade duplicates the saws original blade specifications the switch should not have to be adjusted.



Adjusting the Blade Tracking

The flywheels alignment may need some adjustment to allow the saw blade to track correctly. Improper flywheel alignment can cause damage to the saw blade or cause it to ride off the blade wheel bearings.


1. Disconnect power from the saw.
2. Raise the saw bow to a usable work height.
3. Loosen the hex socket cap screws (AA, AB, & AC).
4. Use an allen wrench on setscrew (AD) to adjust the blade tracking to obtain 0.19" (4.8mm) of the blade (teeth) off of the blade wheel.
5. Turning the setscrew (AD) clockwise (cw) will tilt flywheel so that the blade will ride closer to the flange.
6. Turning the setscrew (AD) counterclockwise (ccw) will tilt the flywheel so that the blade will ride away from the flange. (If it rides too far away it will come off).
7. After the adjustment is finished, tighten the socket cap screws in this order: (**AA, AB, & AC**).





Adjusting the Blade Guide

1. Disconnect power from the saw
2. Release the extension bar for the blade guide block by loosening socket capscrew (AE) counterclockwise (ccw) and freeing up the clamping block (AF).
3. Hold the handle (AG) and slide the blade guide block as close as possible to the piece part without interfering with the cut.
4. Tighten socket screw (AE) clockwise (cw).



Adjusting the angle stops

Check the travel limits of the saw head. Verify that the left limit is set to give a cut of 45° and the right limit is set to give a cut of 60°. If not, adjust the stop bolt.







Blade Guide Bearing Adjustment



IMPORTANT: This is the most important adjustment on your saw. It is impossible to get satisfactory work from your saw if the blade guides are not properly adjusted. Your Baileigh Band Saw has been adjusted and power tested before leaving the factory to insure proper setting. If the guides do get out of adjustment, it is extremely important to re-adjust immediately. An improperly adjusted blade will not cut straight and serious blade damage may result. It is always best to try a new blade to see if this will correct poor cutting before beginning to adjust the blade guide bearings. If the blade becomes dull on one side and not the other, for example, it will begin cutting crooked. A blade change will correct this problem; the guide adjustment will not. If a new blade does not correct the problem, check the clearance between the blade and guides.

1. Disconnect power from the saw.
2. Loosen nut (AK), screw (AJ), and loosen dowel (AL) which widens the gap between the pads.
3. Loosen the nuts (AP) and the dowels (AQ) and then rotate the pins (AM) and (AO) to widen the gap between the bearings (AN).
4. To mount the new blade, place the pad (AI) on the blade. Loosen the dowel and allow a distance of .001" for the sliding of the blade. Lock the nut and screw (AJ). Rotate the pins (AM) and (AO) until the bearings rest against the blade as indicated in (figure 14) and then secure the dowels (AQ) and nuts (AP).
5. Make sure that between the blade and the upper teeth of the pad (AH) there is at least .008" - .011" (2-3mm) of play. If necessary, loosen the screws that fasten the blocks and adjust accordingly.





BEFORE EACH USE

- For dusty operations, wear a face shield along with safety goggles.
- It is important to choose the right blade for the material and the type of cutting you plan to do. This saw is equipped with a bi-metallic blade which can be used to cut stainless steel, steel, iron, brass, aluminum, wood, plastic.
- Make sure the direction of rotation arrow on the blade matches the direction arrow on the saw. The blade teeth should always point downward at the front of the saw.
- Make sure the blade is sharp, undamaged and properly aligned. With the saw unplugged, push the power-head all the way down. Rotate the blade by hand checking for clearance. If the blade hits anything, make the adjustments shown in the Maintaining Maximum Cutting Capacity section.
- Never cut freehand.
- Make sure the cut-off piece can move sideways after it is cut off. Otherwise, it could get wedged against the blade and thrown violently.
- Never turn the saw "ON" before clearing everything except the work piece beneath the blade.
- Never put lubricants on the blade while it is spinning.


Whenever Saw is Running

- Never confine the piece being cut out.
- Never hold it, clamp it, touch it, or use length stops against it. It must be free to move sideways. If confined, it could get wedged against the blade and thrown violently.
- Avoid awkward hand positions where a sudden slip could cause a hand to move into the blade.
- Let the blade reach full speed before cutting.
- Feed the saw into the work piece only fast enough to let the blade cut without bogging down or binding.
- Before freeing jammed material, turn the switch off and unplug the saw. Wait for all moving parts to stop.
- After finishing a cut, keep holding the saw bow down, release the switch, and wait for all moving parts to stop before moving your hands.



Breaking in a Band Saw Blade

Sharp cutting edges with extremely small edge radii are required for high cutting capacity. To achieve the optimal tool life we recommend breaking-in the blade accordingly. The correct cutting speed is determined by the material being cut and its dimensions. It is very important that the new blade is first used with only 50% of the determined feed rate. This will avoid micro-breakages of the blade because of too large chip thicknesses. New band saw blades may tend toward vibrations and vibration sounds. In this case a slight reduction of the cutting speed is helpful. With small workpiece dimensions approximately 300cm² of the material should be cut for breaking-in. If large work piece dimensions are to be cut we recommend a breaking-in period of about 15 minutes. After breaking-in you may slowly increase the feed rate up to the determined value.



Metal Chip Indicators


Chips are the best indicator of correct material feed force. Monitor chip information and adjust feed accordingly.

- Thin or Powdered Chips – increase feed rate or reduce saw speed
- Burned Chips – reduce feed rate and / or saw speed
- Curly Silvery and Warm Chips – optimum feed rate and saw speed

Baileigh Industrial offers a wide selection of tooth styles for various cutting applications. Please phone Baileigh Industrial at (920.684.4990) or fax to (920.684.3944) to have one of our technicians assist you in selecting the proper band saw blade for your cutting applications.



Blade Terminology



A	BLADE WIDTH	The widest part of the blade measured from the back edge of the blade to the tip of the tooth.
B	GULLET DEPTH	The distance from the tooth tip to the bottom of the curved area.
C	TOOTH RAKE	The angle of the tooth face from a line perpendicular to the length of the blade.
D	BLADE BACK	The distance between the back edge of the blade and the bottom of the gullet.
E	TOOTH PITCH	The distance between tooth tips.
F	TPI	The number of teeth per inch when measured from gullet to gullet.
G	GAUGE	The thickness of the blade.
H	TOOTH SET	The distance a tooth is bent from the blade.
I	KERF	The width of material that is removed by the blade when cutting.

Width of Blade

The blade width determines the largest and the smallest curve that can be cut. Usually the wider a blade is, the more accurate and straighter it will cut.

Length of Blade

The length of the band saw blade can be measured with a tape measure at it's circumference or by the formula below:

$$\text{Blade Length} = (2 \times A) + (3.14 \times B)$$

A = the distance in inches between the band saw pulley centers (when the upper pulley is midway in its adjustment range).

B = the band saw pulley diameter.



Blade structure

Bi-metal blades are the most commonly used. They consist of a silicon-steel blade backing by a laser welded high speed steel (HSS) cutting edge. The type of stocks are classified in M2, M42, M51 and differ from each other because of their major hardness due to the increasing percentage of Cobalt (Cc) and molybdenum (Mo) contained in the metal alloy.

Blade type

They differ essentially in their constructive characteristics, such as:

- Shape and cutting angle of tooth
- Pitch
- Set

Shape and angle of tooth

REGULAR TOOTH: 0° rake and constant pitch.




Most common form for transversal or inclined cutting of solid small and average cross-sections or pipes, in laminated mild steel and gray iron or general metal.

POSITIVE RAKE TOOTH: $9^\circ - 10^\circ$ positive rake and constant pitch.



Particular use for crosswise or inclined cuts in solid sections or large pipes, but above all harder materials (highly alloyed and stainless steels, special bronze and forge pig iron).


COMBO TOOTH: pitch varies between teeth and consequently varying teeth size and varying gullet depths. Pitch varies between teeth, which ensures a smoother, quieter cut and longer blade life owing to the lack of vibration.



Another advantage offered in the use of this type of blade is the fact that with an only blade it is possible to cut a wide range of different materials in size and type.




COMBO TOOTH: 9° - 10° positive rake.




This type of blade is the most suitable for the cutting of section bars and large and thick pipes as well as for the cutting of solid bars at maximum machine capacity. Available pitches: 3-4/4-6.

SETS

Saw teeth bent out of the plane of the saw body, resulting in a wide cut in the workpiece.



REGULAR OR RAKER SET: Cutting teeth right and left, alternated by a straight tooth.



Of general use for materials with dimensions superior to 5 mm. Used for the cutting of steel, castings and hard nonferrous materials.

WAVY SET: Set in smooth waves.



This set is associated with very fine teeth and it is mainly used for the cutting of pipes and thin section bars (from 1 to 3 mm).

ALTERNATE SET (IN GROUPS): Groups of cutting teeth right and left, alternated by a straight tooth.



This set is associated with very fine teeth and it is used for extremely thin materials (less than 1mm).

ALTERNATE SET (INDIVIDUAL TEETH): Cutting teeth right and left.



This set is used for the cutting of nonferrous soft materials, plastics and wood.



BLADE CARE

The bandsaw blade is subjected to a tremendous amount of strain. Make sure to always use the appropriate feed rate for the type material you are cutting.

Be sure to select a blade of the proper width, style, and pitch that will produce the best cut in your material. Choosing the wrong blade can produce excess heat that can adversely affect the life of the blade.

A clean blade performs much better than one that is dirty. Blades that are gummed up and dirty offer more resistance when cutting through the material. This in turn creates unnecessary heat in the blade.

CHOOSING A SAW BLADE

A general purpose blade is furnished with this band saw.

To achieve a quality, economical, and efficient saw cut, the following points must be taken into consideration:

- Type of material being cut (ferrous or non ferrous)
- Material hardness and physical dimensions
- Blade descent rate
- Longitudinal speed of blade
- Blade tooth profile

Choose a tooth pitch that is suitable for the workpiece. Thin walled profiles, including tubes and pipes require close toothing. At least 3-6 teeth should be in contact with the material while cutting. Large solid or transverse sections require widely spaced toothing to allow for greater volume of chips and better tooth penetration. Soft materials such as plastics, light alloys, mild bronze, Teflon, etc. require widely spaced toothing to avoid clogging.



S	Outer Diameter of the Tube (inch) / Tooth pitch																	
	Inches	0.787	1.574	2.362	3.15	4	4.724	6	7.873	11.811	15.75	19.685	23.621	27.5	31.5	35.5	39.5	59
0.079	14	14	14	14	14	14	14	10-14tpi	10-14tpi	8-12tpi	8-12tpi	6-10tpi	6-10tpi	5-8tpi	5-8tpi	5-8tpi	5-8tpi	5-8tpi
0.118	14	14	14	10-14tpi	10-14tpi	10-14tpi	10-14tpi	8-12tpi	8-12tpi	6-10tpi	6-10tpi	5-8tpi	5-8tpi	5-8tpi	4-6tpi	4-6tpi	4-6tpi	4-6tpi
0.157	14	14	14	10-14tpi	10-14tpi	10-14tpi	10-14tpi	8-12tpi	8-12tpi	5-8tpi	5-8tpi	4-6tpi	4-6tpi	4-6tpi	4-6tpi	4-6tpi	4-6tpi	4-6tpi
0.197	14	10-14tpi	10-14tpi	10-14tpi	10-14tpi	8-12tpi	8-12tpi	8-12tpi	6-10tpi	5-8tpi	5-8tpi	4-6tpi	4-6tpi	4-6tpi	4-6tpi	3-4tpi	3-4tpi	3-4tpi
0.236	14	10-14tpi	10-14tpi	10-14tpi	8-12tpi	8-12tpi	8-12tpi	8-12tpi	5-8tpi	5-8tpi	4-6tpi	4-6tpi	4-6tpi	3-4tpi	3-4tpi	3-4tpi	3-4tpi	3-4tpi
0.315	14	10-14tpi	8-12tpi	8-12tpi	8-12tpi	8-12tpi	6-10tpi	6-10tpi	5-8tpi	4-6tpi	4-6tpi	4-6tpi	3-4tpi	3-4tpi	3-4tpi	3-4tpi	2-3tpi	2-3tpi
0.394		8-12tpi	6-10tpi	6-10tpi	6-10tpi	6-10tpi	5-8tpi	5-8tpi	4-6tpi	4-6tpi	4-6tpi	3-4tpi	3-4tpi	3-4tpi	3-4tpi	2-3tpi	2-3tpi	2-3tpi
0.472		8-12tpi	6-10tpi	6-10tpi	6-10tpi	5-8tpi	5-8tpi	4-6tpi	4-6tpi	4-6tpi	3-4tpi	3-4tpi	3-4tpi	2-3tpi	2-3tpi	2-3tpi	2-3tpi	2-3tpi
0.591		8-12tpi	6-10tpi	6-10tpi	5-8tpi	5-8tpi	4-6tpi	4-6tpi	4-6tpi	3-4tpi	3-4tpi	3-4tpi	2-3tpi	2-3tpi	2-3tpi	2-3tpi	2-3tpi	2-3tpi
0.787			6-10tpi	5-8tpi	5-8tpi	4-6tpi	4-6tpi	4-6tpi	3-4tpi	3-4tpi	3-4tpi	2-3tpi	2-3tpi	2-3tpi	2-3tpi	2-3tpi	2-3tpi	2-3tpi
1.181					4-6tpi	4-6tpi	4-6tpi	3-4tpi	3-4tpi	2-3tpi	2-3tpi	2-3tpi	2-3tpi	2-3tpi	2-3tpi	2-3tpi	2-3tpi	1-4-2tpi
2							3-4tpi	3-4tpi	3-4tpi	2-3tpi	2-3tpi	2-3tpi	2-3tpi	2-3tpi	2-3tpi	1-4-2tpi	1-4-2tpi	1-4-2tpi
3									2-3tpi	2-3tpi	2-3tpi	2-3tpi	1-4-2tpi	1-4-2tpi	1-4-2tpi	1-4-2tpi	1-4-2tpi	1-4-2tpi
4										2-3tpi	2-3tpi	1-4-2tpi	1-4-2tpi	1-4-2tpi	1-4-2tpi	1-4-2tpi	1-4-2tpi	1-4-2tpi
6											2-3tpi	1-4-2tpi	1-4-2tpi	1-4-2tpi	1-1-4tpi	1-1-4tpi	1-1-4tpi	1-1-4tpi
7.873												1-4-2tpi	1-4-2tpi	1-4-2tpi	1-1-4tpi	1-1-4tpi	1-1-4tpi	7.5-1.25tpi
9.842															1-1-4tpi	1-1-4tpi	7.5-1.25tpi	7.5-1.25tpi
11.81													1-4-2tpi	1-1-4tpi	1-1-4tpi	7.5-1.25tpi	7.5-1.25tpi	7.5-1.25tpi
13.778														1-1-4tpi	1-1-4tpi	7.5-1.25tpi	7.5-1.25tpi	7-1.0tpi
15.747														1-1-4tpi	1-1-4tpi	7.5-1.25tpi	7.5-1.25tpi	7-1.0tpi
17.716																7.5-1.25tpi	7-1.0tpi	7-1.0tpi
19.685																		7-1.0tpi

S= Wall Thickness

If you have to cut two or more tubes lying side by side please use this table in consideration of the double wall thickness (S).



BLADE BREAKAGE

In some cases blade breakage is unavoidable due to the stresses that are imparted on the blade. Avoidable breakage is often the result of poor care, or poor operator judgment when it comes to adjusting or mounting the blade or blade guides.

Listed below are some of the more common reasons for blade breakage.

- Top blade guide assembly is set too high above the piece part.
- The blade is tensioned incorrectly.
- Piece part is fed into the blade too quickly.
- Blade teeth are dull or broken.
- Blade is not properly aligned with the guides.
- Forcing a large width blade to cut a small radius.
- Using a blade with an improperly finished weld joint.
- Allowing the blade to run when not in use. (**NEVER** leave an unattended blade running.)




OPERATION



CAUTION: Always wear proper eye protection with side shields, safety footwear, and leather gloves to protect from burrs and sharp edges. **NEVER** operate saw without blade guards in place.

Manual Operation

1. Close the handle on the hydraulic ball valve (I) by turning it counterclockwise (ccw).
2. Turn the flow control knob (AR) clockwise (cw) to shut off the hydraulic flow. This will prevent the saw bow from dropping when the ball valve is opened.
3. Reduce the bow weight: Lift the spring bolt (AS), rotate the fork handle (AT) clockwise (cw), and release the spring bolt into the hole. (Spring will now be tensioned.)
4. Load piece part and clamp securely.
5. Turn the main switch (5) to "ON". Check to see that the indicator light (1) is lit.
6. Set the blade speed with control knob (4)
7. Set switch (6) to manual mode for trigger operation.
8. While firmly holding the control handle of the saw bow, open ball valve (I) clockwise (cw).
9. Fully open the flow control knob (AR) counterclockwise (ccw).
10. Squeeze the start trigger to energize the blade motor and coolant pump. Lower saw bow to begin cutting.
11. When saw bow reaches bottom limit, the micro-switch (M) is actuated and shuts off the saw and pump motors.
12. Return the saw bow to its start position and close ball valve (I).
13. Unclamp and reset the piece part to continue the next cutting cycle.




IMPORTANT: If an emergency situation should occur: Press the emergency STOP button (3) to immediately shut off all functions of the saw. To release the stop button, rotate the mushroom head clockwise (cw) to reset. (Note: Resetting the E-STOP button will not start the machine.)



Auto Mode Operation

1. Close the handle on the hydraulic ball valve (I) by turning it counterclockwise (ccw).
2. Turn the flow control knob (AR) clockwise (cw) to shut off the hydraulic flow. This will prevent the saw bow from dropping when the ball valve is opened.
3. Increase the bow weight: Lift the spring bolt (AS), rotate the fork handle (AT) counterclockwise (ccw), and release the spring bolt. (Spring will not be tensioned.)
4. Load piece part and clamp securely.
5. Turn the main switch (5) to "ON". Check to see that indicator light (1) is lit.
6. Set the blade speed with control knob (4)
7. Set switch (6) clockwise (cw) to auto mode for hydraulic cylinder operation.
8. Press the green start button (2). The saw motor and the coolant pump motor should both start.
9. Open the ball valve (I) clockwise (cw).
10. Turn the flow control knob (AH) clockwise (cw) to slow down the descent or counterclockwise (ccw) to speed it up.
11. When saw bow reaches bottom limit, micro-switch (M) is actuated and shuts off the saw and pump motors.
12. Grasp the control handle and lift the saw bow to a height slightly above the piece part to minimize the next cut entry time.
13. Close ball valve (I).
14. Unclamp and reset the piece part to continue the next cutting cycle.




AS

AT



These examples below show ways to clamp a variety of cross sections. Always keep in mind the cutting capacity of the saw to achieve efficient saw cuts and long blade life. Do not use blades of a size different from that shown in the technical specification chart.



MATERIAL SELECTION



CAUTION: It must be determined by the customer that materials being processed through the machine are **NOT** potentially hazardous to operator or personnel working nearby.

When selecting materials keep these instructions in mind:

- Material must be clean and dry. (without oil)
- Material should have a smooth surface so it processes easily.
- Dimensional properties of material must be consistent and not exceed the machine capacity values.
- Chemical structure of material must be consistent.
- Buy certificated steel from the same vendor when possible.



LUBRICATION AND MAINTENANCE



WARNING: Make sure the electrical disconnect is OFF before working on the machine.

Maintenance should be performed on a regular basis by qualified personnel.

Always follow proper safety precautions when working on or around any machinery.

Daily Maintenance

- Check daily for any unsafe conditions and fix immediately.
- Check that all nuts and bolts are properly tightened.
- Do a general cleaning by removing dust and metal chips from the machine.
- Inspect the saw blade for wear.
- Clean the lubricating coolant drain screen.
- Top off the coolant tank.
- Check that the blade guards and emergency stop button are in good working order.
- When through using saw for the day, raise the bow to its up position and release some of the blade tension.

Weekly Maintenance

- On a weekly basis clean the machine and the area around it.
- Apply rust inhibitive lubricant to all non-painted surfaces.
- Wipe and grease the vise screw and sliding surfaces.
- Inspect blade brush and clean if needed.
- Clean coolant pump strainer basket.
- Remove chips from inside the guard housing for the saw blade.
- Use compressed air to clean the blade guides and guide bearings.



Monthly Maintenance

- Check the tightening of the motor flywheel screws.
- Check the blade guide bearings for wear. (replace if necessary).
- Tighten any loose bolts or screws on the gear motor, pump, and safety switches.
- Clean coolant tank.
- Grease saw head pivot.



Coolant System Maintenance

1. Disconnect Power From the Saw!
2. To clean the tank, first remove the vinyl hose (AU) from the strainer basket.
3. Remove the strainer basket and lift the cover off of the tank
4. Completely empty tank and use a vacuum cleaner to remove any chips and debris.
5. Thoroughly clean the pump and inlet.
6. Fill the tank with coolant to the full mark on the sight gauge (AV).
7. Replace the cover on the tank.
8. Drop in the strainer basket and reinsert the vinyl hose.
9. Removable drip tray (AW) shown in place.



Oils for Lubricating Coolant

Any 10:1 (water to coolant) solution will work, however we recommend Baileigh B-Cool 20:1 (water to coolant) biodegradable metal cutting fluid. It has excellent cooling and heat transfer characteristics, is non-flammable, and extends blade and machine life. Each gallon of concentrate makes 21 gallons of coolant.

Storing Machine for Extended Period of Time

If the Band Saw is to be inactive for a long period of time, prepare the machine as follows:



- Detach the plug from the electrical supply panel.
- Clean and grease the machine.
- Release tension on the blade or remove blade.
- Drain coolant
- Cover the machine




Gearbox Maintenance

The gearbox requires periodic changing of the oil. Complete the first change after the initial 6 months of operation and then change annually thereafter.

1. Disconnect Power From the Saw!
2. Raise the saw bow to a vertical position. Note: You may have to back off the upper travel adjusting bolt.
3. Remove the oil drain plug (AX) and drain the oil into a catch basin. Loosening oil fill plug (AY) will help oil to drain.
4. After draining, replace drain plug (AX).
5. Return the saw bow to a horizontal position.
6. Remove the fill plug (AY) and add .32 quart of gear oil. (For reference use SHELL type gear oil or Mobil gear oil #90).




Add grease
(monthly)



Oil Disposal


Used oil products must be disposed of in a proper manner following your local regulations.

PARTS IDENTIFICATION DRAWING A






PARTS IDENTIFICATION DRAWING C





PARTS IDENTIFICATION DRAWING D





Parts List A - D

Index No	Part No.	Description	Size	Qty.
1	BS350M-1	Base (Bottom Plate)		1
2	BS350M-2	Base (Left Part)		1
2-1	BS350M-2-1	Nut	M8	4
3	BS350M-3	Base (Right Part)		1
4	BS350M-4	Base (Front Part)		1
4-1	TS-1490021	Hex. Cap Bolt	M8x16	4
4-2	BS350M-4-2	Washer	M8	8
5	TS-1492041	Hex. Cap Bolt	M12x40	2
6	BS350M-6	Nut	M12	2
8	TS-1490021	Hex. Cap Bolt	M8x16	6
8-1	BS350M-8-1	Washer	M8x18x2	6
9	BS350M-9	Plate		1
10	TS-1502011	Hex. Socket Cap Screw	M5x8	4
11	BS350M-11	Coolant Tank		1
12	TS-1490021	Hex. Cap Bolt	M8x16	2
13	BS350M-13	Coolant Gauge		1
14	BS350M-14	Hex. Cap Bolt	3/16"	2
15	BS350M-15	Tank Cover		1
16	BS350M-16	Filter		1
17	BS350M-17	Pump		1
18	TS-1503061	Hex. Socket Cap Screw	M6x25	2
18-1	BS350M-18-1	Washer	M6x13x1	2
22	BS350M-22	Hose Clamp	13mm	1
23	BS350M-23	Hose	5/16"x235cm	1
23-1	BS350M-23-1	Hose	1"x45cm	1
24A	BS350M-24A	Coolant and Chip Tray		1
24-1	BS350M-24-1	Plate		4
24-2	TS-1491021	Hex. Cap Bolt	M10x20	4
24-3	BS350M-24-3	Nut	M10	4
24-4A	BS350M-24-4A	Block Plate		1
25	BS350M-25	Mounting Bracket		2
26	BS350M-26	Spring Washer	M10	4
27	TS-1505021	Hex. Socket Cap Screw	M10x20	4



Index No	Part No.	Description	Size	Qty.
28	BS350M-28	Washer	M10x21x2	4
29	TS-1491021	Hex. Cap Bolt	M10x20	4
29-1	BS350M-29-1	Washer	M10	4
30	TS-1492041	Hex. Cap Bolt	M12x40	2
31	BS350M-31	Nut	M12	2
37-1	BS350M-37-1	Hole Cover	HP-25	3
37-2	BS350M-37-2	Hole Cover	HP-19	1
38-1	BS350M-38-1	Hole Cover	HP-22	1
39	BS350M-39	Track		1
40	TS-1504071	Hex. Socket Cap Screw	M8x35	2
40-1	BS350M-40-1	Nut	M8	2
40-2	BS350M-40-2	Spring Washer	M8	2
41	TS-1523041	Set Screw	M6x12	4
42	BS350M-42	Washer		1
43	BS350M-43	Handle	M8x25	1
44	BS350M-44	Roller Stand		1
45	TS-1492011	Hex. Cap Bolt	M12x25	2
46	BS350M-46	Spring Washer	M12	2
46-1	BS350M-46-1	Washer	M12x28x3	2
47	BS350M-47	Roller		1
48	BB-6004ZZ	Ball Bearing	6004ZZ	2
48-1	BS350M-48-1	C-Ring	S-20	2
49	BS350M-49	Roller Shaft		1
50	TS-1505021	Hex. Socket Cap Screw	M10x20	2
61	BS350M-61	Handle		1
62	BS350M-62	Nut	M12	1
63	BS350M-63	Locking Lever		1
63-1	TS-1525031	Set Screw	M10x16	1
64	TS-1505051	Hex. Socket Cap Screw	M10x35	1
64-1	BS350M-64-1	Spring Washer	M10	1
65	BS350M-65	Shaft Nut		1
65-1	BS350M-65-1	Oil Seal		1
65-3	BS350M-65-3	Disk		1
65-4	BS350M-65-4	Spring Washer	M8	4
65-5	TS-1504071	Hex. Socket Cap Screw	M8x35	4



Index No	Part No.	Description	Size	Qty.
66A	BS350M-66A	Shaft		1
68	BS350M-68	Swivel Arm		1
68-1	TS-1491051	Hex. Cap Bolt	M10x35	1
69	BS350M-69	Scale	0-60°	1
69-1	BS350M-69-1	Scale	0-45°	1
70	BS350M-70	Rivet	2.3x4	4
71	BS350M-71	Pin		1
72	BS350M-72	Hollow Pin	2.5x16	1
73	BS350M-73	Spring		1
74	BS350M-74	Bushing		1
75	BS350M-75	Bracket		1
76	BS350M-76	Spring Washer	M8	2
77	TS-1504051	Hex. Socket Cap Screw	M8x25	2
78	BS350M-78	Knob		1
79	BS350M-79	Jam Nut	M40	1
80	BS350M-80	Star Washer	M40	1
81	BS350M-81	Anti-Dust Cover	M40	2
82	BB-32008	Ball Bearing	32008	2
83A	BS350M-83A	Shaft		1
84	TS-2210451	Hex. Cap Bolt	M10x45	1
85	BS350M-85	Nut	M10	2
86A	BS350M-86A	Pointer		2
87	TS-1502011	Hex. Socket Cap Screw	M5x8	2
88A	BS350M-88A	Cover		1
88-1	BS350M-88-1	Hollow Pin	6x20	2
88-2	TS-1524021	Set Screw	M8x10	1
89	TS-1504071	Hex. Socket Cap Screw	M8x35	5
89-1	BS350M-89-1	Spring Washer	M8	5
92A	BS350M-92A	Table		1
92-1	TS-1523041	Set Screw	M6x12	1
92-2	BS350M-92-2	Changeable Plate		1
92-3	TS-1504041	Hex. Socket Cap Screw	M8x20	4
94	BS350M-94	Bar-Stop-Rod		1
95A	BS350M-95A	Bar Bracket		1
95-1	BS350M-95-1	Nut	M8	2



Index No	Part No.	Description	Size	Qty.
95-2	TS-1504051	Hex. Socket Cap Screw	M8x25	1
95-3	BS350M-95-3	Knob	M8x30	1
95-4	BS350M-95-4	Stop Bar		1
97	BS350M-97	Scale		1
98	BS350M-98	Rivet		3
99	BS350M-99	Chip Gutter		1
100	TS-1503011	Hex. Socket Cap Screw	M6x8	2
102	BS350M-102	No-Burr Jaw		1
103	BS350M-103	Hex. Socket Cap Screw	M6x15	2
104	BS350M-104	Counter Vise Jaw		1
105	BS350M-105	Hex. Socket Cap Screw	M6x15	2
106	BS350M-106	Vise Jaw		1
107	BS350M-107	Flat Head Machine Screw	M6x15	2
108A	BS350M-108A	Vise		1
109	BS350M-109	Dovetail Plate		1
110	BS350M-110	Nut	M5	3
111	BS350M-111	Set Screw	M5x25	3
113	BS350M-113	Key	5x5x15	1
115	BS350M-115	Spring Washer	M8	4
116	TS-1504041	Hex. Socket Cap Screw	M8x20	4
117	BS350M-117	Hand Wheel		1
117-1	BS350M-117-1	Spring Washer	M6	1
117-2	TS-1503061	Hex. Socket Cap Screw	M6x25	1
117-3	BS350M-117-3	Bushing		1
118	TS-1524021	Set Screw	M8x10	1
120A	BS350M-120A	Vise Seat		1
122	BS350M-122	Vise Setting Plate		1
123	TS-1505041	Hex. Socket Cap Screw	M10x30	2
124	BS350M-124	Setting Washer		1
125	BS350M-125	Lock Lever Device		1
127	BS350M-127	Handle		1
128	BS350M-128	Setting Plate		1
129	BS350M-129	Bushing		1
130	TS-1504041	Hex. Socket Cap Screw	M8x20	2
130-1	BS350M-130-1	Spring Washer	M8	2



Index No	Part No.	Description	Size	Qty.
131	BS350M-131	Electric Box Holder		1
132	BS350M-132	Spring Washer	M8	4
133	TS-1504041	Hex. Socket Cap Screw	M8x20	4
135	TS-1505031	Hex. Socket Cap Screw	M10x25	2
136	BS350M-136	Spring Washer	M10	2
137	BS350M-137	Support		1
137-1	TS-1502011	Hex. Socket Cap Screw	M5x8	4
138	BS350M-138	Control Box Bottom Part		1
139	BS350M-139	Control Box Panel		1
139-1	BS350M-139-1	Blade Speed Indicator		1
139-2	BS350M-139-2	Hex. Socket Cap Screw	M4	2
139-3	BS350M-139-3	Round Head Screw	M5x8	4
140	BS350M-140	Manual/ Auto Selector		1
141	BS350M-141	Blade Speed Knob		1
142	BS350M-142	Emergency Switch		1
143	BS350M-143	Main Connect Switch		1
144	BS350M-144	Start Push Button		1
145	BS350M-145	Indicator Light		1
146	BS350M-146	Control Box Bottom Plate		1
146-1	BS350M-146-1	Inverter		1
146-2	BS350M-146-2	Transformer		1
146-3	BS350M-146-3	Fuse	1A	1
146-4	BS350M-146-4	Relay		1
146-5	BS350M-146-5	Terminal Connector		1
146-6	BS350M-146-6	Hex. Socket Cap Screw	M5	4
146-7	BS350M-146-7	Grounding Plate		1
147	TS-1502011	Hex. Socket Cap Screw	M5x8	4
148	BS350M-148	Control Box Cover		1
149	BS350M-149	Supporting Bracket		1
149-1	BS350M-149-1	Shaft		1
150	TS-1524021	Set Screw	M8x10	1
150-1	TS-1504041	Hex. Socket Cap Screw	M8x20	4
150-2	BS350M-150-2	Spring Washer	M8	4
151	BS350M-151	Reduction Unit		1
151-1	BS350M-151-1	Vent Screw		1



Index No	Part No.	Description	Size	Qty.
152	BS350M-152	Key	8x8x30	1
153	TS-1490041	Hex. Cap Bolt	M8x25	4
153-1	BS350M-153-1	Spring Washer	M8	4
154	BS350M-154	Motor		1
154-1	BS350M-154-1	Junction Box		1
155	BS350M-155	Key	8x7x35	1
186	TS-1505051	Hex. Socket Cap Screw	M10x35	4
186-1	BS350M-186-1	Spring Washer	M10	4
1938	BS350M-1938	Saw Arm		1
193-1	TS-1524021	Set Screw	M8x10	2
194	TS-1505051	Hex. Socket Cap Screw	M10x35	4
194-1	BS350M-194-1	Spring Washer	M10	4
195	BS350M-195	Limit Switch		1
195-1	BS350M-195-1	Switch Pin		1
196	TS-1501091	Hex. Socket Cap Screw	M4x35	2
197	TS-1505051	Hex. Socket Cap Screw	M10x35	4
197-1	BS350M-197-1	Spring Washer	M10	4
198A	BS350M-198A	T Connector		1
199	TS-1502041	Hex. Socket Cap Screw	M5x16	2
200	BS350M-200	Coolant Switch		2
201	BS350M-201	Hose Clamp	13mm	1
203	BS350M-203	Pipe Fitting	1/4Px5/16	1
204	BS350M-204	Hose	5/16"x40cm	1
205	BS350M-205	Hose	5/16"x90cm	1
206	BS350M-206	Drive Flywheel		1
207	BS350M-207	Washer		1
207-1	BS350M-207-1	Spring Washer	M10	1
208	TS-1491031	Hex. Cap Bolt	M10x25	1
209A	BS350M-209A	Idle Flywheel Shaft		1
210	BB-32007	Roller Bearing	32007	2
211	BS350M-211	Idle Flywheel		1
212	BS350M-212	Star Washer	M35	1
212-1	BS350M-212-1	Anti-dust Cover	M35	2
213	BS350M-213	Jam Nut	M35	1
214	BS350M-214	Oil Inlet	1/16	1



Index No	Part No.	Description	Size	Qty.
215A	BS350M-215A	Saw Blade		1
2168	BS350M-2168	Blade Cover		1
216A-1	BS350M-216A-1	Extension		1
216A-2	BS350M-216A-2	Round Head Screw	M6x8	2
217	BS350M-217	Plum Screw	M6x10	4
219	BS350M-219	Round Head Screw	M4x8	2
220	BS350M-220	Nut	M4	2
223	BS350M-223	Handle Wheel		1
223-1	BB-51103	Thrust Bearing	51103	1
223-2	BS350M-223-2	Blade Tension Gauge		1
223-3	BS350M-223-3	Plate		1
224	BS350M-224	Special Spring Washer		10
225	BS350M-225	Tension Shaft		1
229	BS350M-229	Plate		1
230	TS-1503031	Hex. Socket Cap Screw	M6x12	2
230-1	BS350M-230-1	Washer	M6	2
231	BS350M-231	Limit Switch		1
232	TS-1501071	Hex. Socket Cap Bolt	M4x25	2
239	TS-154010	Nut	M16x2.0	1
240A	BS350M-240A	Slide Bracket		1
240A-1	BS350M-240A-1	Spring Washer	M10	3
240A-2	TS-1505071	Hex. Socket Cap Screw	M10x45	3
240A-3	TS-1525051	Set Screw	M10x25	1
244	BS350M-244	Cover Plate		1
245	TS-1503011	Hex. Socket Cap Screw	M6x8	2
246	BS350M-246	Gib		2
247	BS350M-247	Spring Washer	M8	6
248	TS-1504041	Hex. Socket Cap Screw	M8x20	6
249	BS350M-249	Blade Guide Movable Rod		1
249-1	TS-1503011	Hex. Socket Cap Screw	M6x8	1
250	TS-1523041	Set Screw	M6x12	4
251	TS-1504041	Hex. Socket Cap Screw	M8x20	2
252	BS350M-252	Setting Bracket		1
253	TS-1506071	Hex. Socket Cap Screw	M12x50	1
254	BS350M-254	Handle		1



Index No	Part No.	Description	Size	Qty.
256	BS350M-256	Guide Bracket		1
259	BS350M-259	Bolt		2
260	TS-1503011	Hex. Socket Cap Screw	M6x8	1
261	BS350M-261	Blade Guard		1
262	TS-1523061	Set Screw	M6x20	2
263	BS350M-263	Nut	M6	2
264	BS350M-264	Centric Shaft		2
265	BB-608ZZ	Ball Bearing	608ZZ	8
265-1	BB-608ZZ	Ball Bearing	608ZZ	2
266	BS350M-266	E-Ring	E-7	4
267	BS350M-267	Blade Guide		2
268	TS-1503061	Hex. Socket Cap Screw	M6x25	2
269	BS350M-269	Eccentric Shaft		2
270	TS-1503011	Hex. Socket Cap Screw	M6x8	2
271	BS350M-271	Blade Guard		1
272	BS350M-272	Guide Bracket		1
272-1	TS-1503011	Hex. Socket Cap Screw	M6x8	2
273	BS350M-273	Pipe Fitting	1/4Px5/16	2
274	BS350M-274	Blade Guide		2
275	BS350M-275	Ball Bearing Bracket		1
276	TS-1523041	Set Screw	M6x12	4
277	TS-1491021	Hex. Socket Cap Screw	M10x20	2
279	TS-1504041	Hex. Socket Cap Screw	M8x20	2
280	BS350M-280	Brush		1
281	BS350M-281	Brush Clamp		1
282	BS350M-282	Set Screw	M5x5	1
283	BS350M-283	Set Bushing		1
284	TS-1482021	Hex. Cap Screw	M6x12	2
285	BS350M-285	Washer	M6x13x2	2
286A	BS350M-286A	Lead Screw		1
286-1	BS350M-286-1	Spring		1
286-2	TS-1504031	Hex. Socket Cap Screw	M8x16	1
286-3	BS350M-286-3	Washer	M8	1
287	BS350M-287	Setting Seat		1
288	BS350M-288	Lead Screw Seat		1



Index No	Part No.	Description	Size	Qty.
289	BS350M-289	Bearing Bushing		1
289-1	BB-51104	Ball Bearing	51104	1
289-2	BS350M-289-2	Nut		1
289-3	BS350M-289-3	Set Screw	M5x5	1
291	BS350M-291	Trigger Switch		1
292	BS350M-292	Pipe		1
292-1	BS350M-292-1	Nut	M16	1
293	BS350M-293	Nut	M12	1
294	BS350M-294	Spring Hook		1
295	BS350M-295	Spring		1
296	BS350M-296	Spring Seat		1
297	BS350M-297	Spring Bushing		1
298	BS350M-298	G-Ring	S-12	4
298-1	BS350M-298-1	Washer	M10	2
299	BS350M-299	Shaft		1
300	BS350M-300	Pin		1
301	BS350M-301	Hollow Pin	2.5x16	1
302	BS350M-302	Spring		1
303	BS350M-303	Fork		1
304	BS350M-304	Nut	M10	1
305	BS350M-305	Adjusting Bracket		1
306	BS350M-306	Shaft		1
307	BS350M-307	Knob		1
307-1	BS350M-307-1	Bushing		1
308	BS350M-308	Shaft		1
309	BS350M-309	Arm		1
310	BS350M-310	G-Ring	S-12	2
311	TS-1505031	Hex. Socket Cap Screw	M10x25	1
312	BS350M-312	Spring Washer	M10	1
313	BS350M-313	Post		1
314	TS-1525031	Set Screw	M10x16	3
315	BS350M-315	Hydraulic Cylinder Post		1
316	BS350M-316	Spring Washer	M8	4
317	TS-1504051	Hex. Socket Cap Screw	M8x25	4
318	TS-1533032	Round Head Screw	M5X10	2



Index No	Part No.	Description	Size	Qty.
319	BS350M-319	Limit Switch		1
320	TS-1503011	Hex. Socket Cap Screw	M6x8	2
320-1	BS350M-320-1	Washer	M6	2
321A	BS350M-321A	Adjusting Bracket		1
322A	BS350M-322A	Hydraulic Cylinder		1
323	TS-1505061	Hex. Socket Cap Screw	M10x40	1
324	BS350M-324	Nut	M10	1