



OPERATOR'S MANUAL



METAL LATHE MODEL: PL-1860

Baileigh Industrial, Inc.
P.O. Box 531
Manitowoc, WI 54221-0531
Phone: 920.684.4990
Fax: 920.684.3944
sales@baileighindustrial.com

Book 1 of 3

REPRODUCTION OF THIS MANUAL IN ANY FORM WITHOUT WRITTEN APPROVAL OF BAILEIGH INDUSTRIAL, INC. IS PROHIBITED. Baileigh Industrial, Inc. does not assume and hereby disclaims any liability for any damage or loss caused by an omission or error in this Operator's Manual, resulting from accident, negligence, or other occurrence.



Table of Contents

THANK YOU & WARRANTY	1
INTRODUCTION.....	3
GENERAL NOTES.....	3
SAFETY INSTRUCTIONS	4
SAFETY PRECAUTIONS	6
TECHNICAL SPECIFICATIONS	9
Machine Features.....	10
TECHNICAL SUPPORT	10
UNPACKING AND CHECKING CONTENTS.....	11
Cleaning	13
MACHINE LOCATION	13
TRANSPORTING AND LIFTING	14
INSTALLATION.....	16
Level Adjustment	18
OVERALL DIMENSIONS	19
ELECTRICAL	20
Power cord connection:	21
SAFETY FEATURES	22
GETTING TO KNOW YOUR MACHINE	23
Steady Rest.....	26
Follow Rest.....	26
Dead Center	27
Tailstock	27
Quick Change Tool Posts	28
LATHE SETUP.....	29
Chuck	29
Chuck Removal	30
Chuck Installation	31
To Install Cam lock Studs	31
Symbols for Operation	32
Coolant System	34
OPERATING CONTROLS	34
Spindle Speeds	35
Feed Direction	36
Feed Selector Knobs	37
Thread Cutting and Feed Chart.....	38
Thread Cutting and Feed Chart.....	39
Thread Cutting Operation	40
APRON	40
Threading	42
Thread Dial Indicator	42
Spindle Rotation Control.....	43



Micrometer Saddle Stop	43
Saddle – Cross Slide and Compound Rest	43
Cross6 Traverse Slide	44
Compound Rest.....	45
Half Nut	45
Lead Screw.....	46
Changing Gears for Thread Selection	46
TEST RUN	47
MACHINE ADJUSTMENTS	48
Lead Screw Adjustment.....	49
Half Nut Adjustment.....	49
Lathe Alignment.....	50
V-Belt Removal and Adjustment.....	51
Foot Brake Adjustment	52
Saddle Adjustment	53
Cross feed Screw / Nut Backlash Adjustment	54
Tapered Gib Adjustment.....	55
Feed Rod Adjustment.....	55
LUBRICATION AND MAINTENANCE	56
Daily Maintenance	56
Weekly Maintenance	56
3 Month Maintenance	56
Oil Disposal	57
Accessing and Cleaning the Coolant System	57
Oils for Lubricating Coolant	57
Headstock	58
Quick Change Gear Box.....	58
Compound Rest, Cross Slide, Feed Screw, & Nut	59
Lead screw, Feed Rod, and Half Nut.....	59
Apron.....	60
Bed Ways, Saddle, and Cross Slide.....	60
Quick Change Gears	60
Tail Stock.....	61
Storing Machine for Extended Period of Time	61



THANK YOU & WARRANTY

Thank you for your purchase of a machine from Baileigh Industrial. We hope that you find it productive and useful to you for a long time to come.

Inspection & Acceptance. Buyer shall inspect all Goods within ten (10) days after receipt thereof. Buyer's payment shall constitute final acceptance of the Goods and shall act as a waiver of the Buyer's rights to inspect or reject the goods unless otherwise agreed. If Buyer rejects any merchandise, Buyer must first obtain a Returned Goods Authorization ("RGA") number before returning any goods to Seller. Goods returned without a RGA will be refused. Seller will not be responsible for any freight costs, damages to goods, or any other costs or liabilities pertaining to goods returned without a RGA. Seller shall have the right to substitute a conforming tender. Buyer will be responsible for all freight costs to and from Buyer and repackaging costs, if any, if Buyer refuses to accept shipment. If Goods are returned in unsalable condition, Buyer shall be responsible for full value of the Goods. Buyer may not return any special order Goods. Any Goods returned hereunder shall be subject to a restocking fee equal to 30% of the invoice price.

Specifications. Seller may, at its option, make changes in the designs, specifications or components of the Goods to improve the safety of such Goods, or if in Seller's judgment, such changes will be beneficial to their operation or use. Buyer may not make any changes in the specifications for the Goods unless Seller approves of such changes in writing, in which event Seller may impose additional charges to implement such changes.

Limited Warranty. Seller warrants to the original end-user that the Goods manufactured or provided by Seller under this Agreement shall be free of defects in material or workmanship for a period of twelve (12) months from the date of purchase, provided that the Goods are installed, used, and maintained in accordance with any instruction manual or technical guidelines provided by the Seller or supplied with the Goods, if applicable. The original end-user must give written notice to Seller of any suspected defect in the Goods prior to the expiration of the warranty period. The original end-user must also obtain a RGA from Seller prior to returning any Goods to Seller for warranty service under this paragraph. Seller will not accept any responsibility for Goods returned without a RGA. The original end-user shall be responsible for all costs and expenses associated with returning the Goods to Seller for warranty service. In the event of a defect, Seller, at its sole option, shall repair or replace the defective Goods or refund to the original end-user the purchase price for such defective Goods. Goods are not eligible for replacement or return after a period of 30 days from date of receipt. The foregoing warranty is Seller's sole obligation, and the original end-user's exclusive remedy, with regard to any defective Goods. This limited warranty does not apply to: (a) die sets, tooling, and saw blades; (b) periodic or routine maintenance and setup, (c) repair or replacement of the Goods due to normal wear and tear, (d) defects or damage to the Goods resulting from misuse, abuse, neglect, or accidents, (e) defects or damage to the Goods resulting from improper or unauthorized alterations, modifications, or changes; and (f) any Goods that has not been installed and/or maintained in accordance with the instruction manual or technical guidelines provided by Seller.

EXCLUSION OF OTHER WARRANTIES. THE FOREGOING LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. ANY AND ALL OTHER EXPRESS, STATUTORY OR IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE ARE EXPRESSLY DISCLAIMED. NO WARRANTY IS MADE WHICH EXTENDS BEYOND THAT WHICH IS EXPRESSLY CONTAINED HEREIN.

Limitation of Liability. IN NO EVENT SHALL SELLER BE LIABLE TO BUYER OR ANY OTHER PARTY FOR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES (INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR DOWN TIME) ARISING FROM OR IN MANNER CONNECTED WITH THE GOODS, ANY BREACH BY SELLER OR ITS AGENTS OF THIS AGREEMENT, OR ANY OTHER CAUSE WHATSOEVER, WHETHER BASED ON CONTRACT, TORT OR ANY OTHER THEORY OF LIABILITY. BUYER'S REMEDY WITH RESPECT TO ANY CLAIM ARISING UNDER THIS AGREEMENT IS STRICTLY LIMITED TO NO MORE THAN THE AMOUNT PAID BY THE BUYER FOR THE GOODS.



Force Majeure. Seller shall not be responsible for any delay in the delivery of, or failure to deliver, Goods due to causes beyond Seller's reasonable control including, without limitation, acts of God, acts of war or terrorism, enemy actions, hostilities, strikes, labor difficulties, embargoes, non-delivery or late delivery of materials, parts and equipment or transportation delays not caused by the fault of Seller, delays caused by civil authorities, governmental regulations or orders, fire, lightening, natural disasters or any other cause beyond Seller's reasonable control. In the event of any such delay, performance will be postponed by such length of time as may be reasonably necessary to compensate for the delay.

Installation. If Buyer purchases any Goods that require installation, Buyer shall, at its expense, make all arrangements and connections necessary to install and operate the Goods. Buyer shall install the Goods in accordance with any Seller instructions and shall indemnify Seller against any and all damages, demands, suits, causes of action, claims and expenses (including actual attorneys' fees and costs) arising directly or indirectly out of Buyer's failure to properly install the Goods.

Work By Others; Safety Devices. Unless agreed to in writing by Seller, Seller has no responsibility for labor or work performed by Buyer or others, of any nature, relating to design, manufacture, fabrication, use, installation or provision of Goods. Buyer is solely responsible for furnishing, and requiring its employees and customers to use all safety devices, guards and safe operating procedures required by law and/or as set forth in manuals and instruction sheets furnished by Seller. Buyer is responsible for consulting all operator's manuals, ANSI or comparable safety standards, OSHA regulations and other sources of safety standards and regulations applicable to the use and operation of the Goods.

Remedies. Each of the rights and remedies of Seller under this Agreement is cumulative and in addition to any other or further remedies provided under this Agreement or at law or equity.

Attorney's Fees. In the event legal action is necessary to recover monies due from Buyer or to enforce any provision of this Agreement, Buyer shall be liable to Seller for all costs and expenses associated therewith, including Seller's actual attorneys' fees and costs.

Governing Law/Venue. This Agreement shall be construed and governed under the laws of the State of Wisconsin, without application of conflict of law principles. Each party agrees that all actions or proceedings arising out of or in connection with this Agreement shall be commenced, tried, and litigated only in the state courts sitting in Manitowoc County, Wisconsin or the U.S. Federal Court for the Eastern District of Wisconsin. Each party waives any right it may have to assert the doctrine of "forum non conveniens" or to object to venue to the extent that any proceeding is brought in accordance with this section. Each party consents to and waives any objection to the exercise of personal jurisdiction over it by courts described in this section. Each party waives to the fullest extent permitted by applicable law the right to a trial by jury.

Summary of Return Policy.

- 10 Day acceptance period from date of delivery. Damage claims and order discrepancies will not be accepted after this time.
- You must obtain a Baileigh issued RGA number PRIOR to returning any materials.
- Returned materials must be received at Baileigh in new condition and in original packaging.
- Altered items are not eligible for return.
- Buyer is responsible for all shipping charges.
- A 30% re-stocking fee applies to all returns.

Baileigh Industrial makes every effort to ensure that our posted specifications, images, pricing and product availability are as correct and timely as possible. We apologize for any discrepancies that may occur. Baileigh Industrial reserves the right to make any and all changes deemed necessary in the course of business including but not limited to pricing, product specifications, quantities, and product availability.

For Customer Service & Technical Support:

Please contact one of our knowledgeable Sales and Service team members at:
(920) 684-4990 or e-mail us at sales@baileighindustrial.com



INTRODUCTION

The quality and reliability of the components assembled on a Baileigh Industrial machine guarantee near perfect functioning, free from problems, even under the most demanding working conditions. However if a situation arises, refer to the manual first. If a solution cannot be found, contact the distributor where you purchased our product. Make sure you have the serial number and production year of the machine (stamped on the nameplate). For replacement parts refer to the assembly numbers on the parts list drawings.

Our technical staff will do their best to help you get your machine back in working order.

In this manual you will find: (when applicable)

- Safety procedures
- Correct installation guidelines
- Description of the functional parts of the machine
- Capacity charts
- Set-up and start-up instructions
- Machine operation
- Scheduled maintenance
- Parts lists

GENERAL NOTES

After receiving your equipment remove the protective container. Do a complete visual inspection, and if damage is noted, **photograph it for insurance claims** and contact your carrier at once, requesting inspection. Also contact Baileigh Industrial and inform them of the unexpected occurrence. Temporarily suspend installation.

Take necessary precautions while loading / unloading or moving the machine to avoid any injuries.

Your machine is designed and manufactured to work smoothly and efficiently. Following proper maintenance instructions will help ensure this. Try and use original spare parts, whenever possible, and most importantly; **DO NOT** overload the machine or make any unauthorized modifications.




Note: *This symbol refers to useful information throughout the manual.*



IMPORTANT

PLEASE READ THIS OPERATORS MANUAL CAREFULLY

It contains important safety information, instructions, and necessary operating procedures. The continual observance of these procedures will help increase your production and extend the life of the equipment.



SAFETY INSTRUCTIONS

LEARN TO RECOGNIZE SAFETY INFORMATION

This is the safety alert symbol. When you see this symbol on your machine or in this manual, **BE ALERT TO THE POTENTIAL FOR PERSONAL INJURY!**

Follow recommended precautions and safe operating practices.

UNDERSTAND SIGNAL WORDS

A signal word – **DANGER**, **WARNING**, or **CAUTION** is used with the safety alert symbol. **DANGER** identifies a hazard or unsafe practice that will result in severe **Injury or Death.**

Safety signs with signal word **DANGER** or **WARNING** are typically near specific hazards.

General precautions are listed on **CAUTION** safety signs. **CAUTION** also calls attention to safety messages in this manual.



DANGER



WARNING



CAUTION




SAVE THESE INSTRUCTIONS.
Refer to them often and use them to instruct others.




PROTECT EYES

Wear safety glasses or suitable eye protection when working on or around machinery.




PROTECT AGAINST NOISE

Prolonged exposure to loud noise can cause impairment or loss of hearing. Wear suitable hearing protective devices such as ear muffs or earplugs to protect against objectionable or uncomfortable loud noises.




DUST HAZARD

Wear appropriate dust mask. Dust created while using machinery can cause cancer, birth defects, and long term respiratory damage. Be aware of the dust hazards associated with all types of materials.



HIGH VOLTAGE

USE CAUTION IN HIGH VOLTAGE AREAS. DO NOT assume the power to be off.
FOLLOW PROPER LOCKOUT PROCEDURES.



ROTATING TOOL HAZARD


Keep hands and body clear while operating. Rotating chuck can cut, dismember, snag, and entrap. Flying chips, splinters, and other particles can cause serious injury or death.





ENTANGLEMENT HAZARD – ROTATING BLADES

Contain long hair, **DO NOT** wear jewelry or loose fitting clothing.



EMERGENCY STOP BUTTON

In the event of incorrect operation or dangerous conditions, the machine can be stopped immediately by pressing the **E-STOP** button. Twist the emergency stop button clockwise (cw) to reset.
Note: Resetting the E-Stop will not start the machine.



SAFETY PRECAUTIONS



Metal working can be dangerous if safe and proper operating procedures are not followed. As with all machinery, there are certain hazards involved with the operation of the product. Using the machine with respect and caution will considerably lessen the possibility of personal injury. However, if normal safety precautions are overlooked or ignored, personal injury to the operator may result.

Safety equipment such as guards, hold-downs, safety glasses, dust masks and hearing protection can reduce your potential for injury. But even the best guard won't make up for poor judgment, carelessness or inattention. **Always use common sense** and exercise **caution** in the workshop. If a procedure feels dangerous, don't try it.

REMEMBER: Your personal safety is your responsibility.



WARNING: FAILURE TO FOLLOW THESE RULES MAY RESULT IN SERIOUS PERSONAL INJURY

1. **Only trained and qualified personnel can operate this machine.** Untrained operators can be seriously injured. If the machine is not being used, disconnect and lockout the power to prevent unauthorized use of the machine.
2. **Make sure guards are in place and in proper working order before operating machinery.**



3. Make sure guarding does not prevent the operator from performing the necessary job tasks in a safe manner. Guards should not obscure the operator's view when extending beyond the depth of the chuck.
4. **DO NOT** bypass or defeat any safety interlock systems.
5. **Remove any adjusting tools.** Before operating the machine, make sure any adjusting tools have been removed. Never leave adjustment tools or lathe chuck wrenches in the chuck or near any moving part of the machine. They can become dangerous projectiles causing serious personal injury or death.
6. **Keep work area clean.** Cluttered areas invite injuries.
7. **Overloading machine.** By overloading the machine you may cause injury from flying parts. **DO NOT** exceed the specified machine capacities.
8. **Dressing material edges.** Always chamfer and deburr all sharp edges.
9. **Do not force tool.** Your machine will do a better and safer job if used as intended. **DO NOT** use inappropriate attachments in an attempt to exceed the machines rated capacity.
10. **Use the right tool for the job. DO NOT** attempt to force a small tool or attachment to do the work of a large industrial tool. **DO NOT** use a tool for a purpose for which it was not intended.
11. **Dress appropriate. DO NOT** wear loose fitting clothing or jewelry as they can be caught in moving machine parts. Protective clothing and steel toe shoes are recommended when using machinery. Wear a restrictive hair covering to contain long hair.
12. **Use eye and ear protection.** Always wear ISO approved impact safety goggles. Wear a full-face shield if you are producing metal filings.
13. **Do not overreach.** Maintain proper footing and balance at all times. **DO NOT** reach over or across a running machine.
14. **Stay alert.** Watch what you are doing and use common sense. **DO NOT** operate any tool or machine when you are tired.
15. **Check for damaged parts.** Before using any tool or machine, carefully check any part that appears damaged. Check for alignment and binding of moving parts that may affect proper machine operation.
16. **Observe work area conditions. DO NOT** use machines or power tools in damp or wet locations. Do not expose to rain. Keep work area well lighted. **DO NOT** use electrically powered tools in the presence of flammable gases or liquids.
17. **Blade adjustments and maintenance.** Always keep blades sharp and properly adjusted for optimum performance.
18. **Keep children away.** Children must never be allowed in the work area. **DO NOT** let them handle machines, tools, or extension cords.



19. **Store idle equipment.** When not in use, tools must be stored in a dry location to inhibit rust. Always lock up tools and keep them out of reach of children.
20. **DO NOT operate machine if under the influence of alcohol or drugs.** Read warning labels on prescriptions. If there is any doubt, **DO NOT** operate the machine.
21. **DO NOT** touch live electrical components or parts.
22. Always disconnect the lathe from the power supply before performing any service work, adjustments, or changing of tooling.
23. Be sure all equipment is properly installed and grounded according to national, state, and local codes.
24. Inspect power and control cables periodically. Replace if damaged or bare wires are exposed. **Bare wiring can kill!**
25. Keep visitors a safe distance from the work area.
26. Follow maintenance instructions and lubrication schedules to ensure the machine is in good working condition at all times.
27. Set up a scheduled machine inspection to look for damaged parts, loose hardware, misaligned components, or other conditions that will affect the safe operation of the machine.
28. Always inspect the chuck and piece part in the chuck. Be aware of any potential catch points capable of causing serious personal injury or death.
29. To avoid injuries during start-up, make sure the piece part, tooling, and tool post have adequate clearance. Always set correct RPM for the size part being turned. If the speed is set too high for a large piece part there is a chance it could be ejected from the chuck causing serious personal injury or death.
30. Always support the piece part as necessary when it extends from the chuck using a lathe center in the tail stock or by using either a steady rest or a follow rest.
31. When the chuck and piece part are in motion, **NEVER** reach over, under, or around the piece part to make an adjustment or to retrieve anything.
32. **ALWAYS STOP THE LATHE** when removing shavings or chips from the piece part or the tooling. **NEVER** use your bare hands.



TECHNICAL SPECIFICATIONS

Swing Over Bed – Maximum	18" (458mm)
Swing Over Cross Slide – Maximum	11.313" (288mm)
Swing In Gap Length – Maximum	6.125" (155mm)
Swing In Gap Diameter – Maximum	25.196" (640mm)
Spindle Speeds	12 @ 30 – 2000 rpm
Spindle Bore	2.375" (60mm)
Spindle Nose	D1-6"
Spindle Taper Sleeve	Morse #4
Spindle Taper Nose	Morse #6
Lead Screw Diameter	1.25" (32mm)
Lead Screw Thread Pitch	4 T.P.I. (6mm)
Threads Diametrical Qty./Speed	32 / 4–32 D.P.
Threads Imperial Qty./Speed	40 / 2–56 T.P.I.
Threads Metric Qty./Speed	53 / .4–14 mm pitch
Threads Module Qty./Speed	44 / .4–7 M.P.
Tailstock Quill Diameter	2.125" (54mm)
Tailstock Quill Taper	Morse #4
Tailstock Quill Travel	4.75" (120mm)
Compound Rest Travel	5.31" (135mm)
Distance Between Centers	60" (1524mm)
Center Height	9" (230mm)
Bed Width	11.81" (300mm)
Longitudinal Feeds Metric Qty./Speed	40 / .032 – .640 mm / rev.
Longitudinal Feeds Imperial Qty./Speed	40 / .0012" – .0252" / rev.
Cross Feeds Imperial Qty./Speed	40 / .0006" – .0126" / rev.
Cross Feeds Metric Qty./Speed	40 / .015 – .32 mm / rev.
Cross Slide Travel	9" (230mm)
Cross Slide Width	7.08" (180mm)
Power	220V / 3-phase / 60Hz
Main Motor	7.5hp (5.6kW)
Coolant Pump Motor	1/8hp (.09kW)
Shipping Weight	5060lbs. (2300kg)
Shipping Dimensions	112" x 65" x 44" (2854 x 1651 x 1118mm)



Machine Features

- 2-axis digital readout
- 8" (203mm) three jaw chuck
- 12-step spindle speed
- Integrated coolant system
- Steady rest
- Follow rest
- 4-way quick change tool post with guard
- Foot brake
- Headstock chuck guard with micro switch safety cut-off
- Heavy duty welded stand
- 220V three phase

TECHNICAL SUPPORT

Our technical support department can be reached at 920.684.4990, and asking for the support desk for purchased machines. Tech Support handles questions on machine setup, schematics, warranty issues, and individual parts needs: (other than die sets and blades).

For specific application needs or future machine purchases contact the Sales Department at: sales@baileighindustrial.com, Phone: 920.684.4990, or Fax: 920.684.3944.



Note: The photos illustrations using in this manual are representative only and may not depict the actual color, labeling or accessories and may be intended to illustrate technique only.



Note: The specifications and dimensions presented here are subject to change without prior notice due to improvements of our products.



UNPACKING AND CHECKING CONTENTS

Your Baileigh machine is shipped complete in one crate. Separate all parts from the packing material and check each item carefully. Make certain all items are accounted for before discarding any packing material.








WARNING: SUFFOCATION HAZARD! Immediately discard any plastic bags and packing materials to eliminate choking and suffocation hazards to children and animals.

If any parts are missing, do not plug in the power cable, or turn the power switch on until the missing parts are obtained and installed correctly.

Contents

Item	Description	Qty.
A	Tool Box	1
B	Lubricating Bottle	1
C	Tapered Sleeve	1
D	Reversing Jaws	3
E	Lathe Centers	2
F	Allen Wrenches (1.5 – 10mm)	1
G	Wheel Handle	1
H	Crescent Wrench	1
I	T-Handles	2
J	2-Pc T-Handle	1
K	Screw Drivers	2
L	Foot Pads	6
M	50 Amp Fuses	3
N	Change Gears – 31T, 41T	1ea.
O	5A Fuse (Attached to Tool Box Cover)	1
P	Brass Shear Pin (Attached to Tool Box Cover)	2





Cleaning

Your machine may be shipped with a rustproof waxy oil coating and grease on the exposed unpainted metal surfaces. To remove this protective coating, use a degreaser or solvent cleaner. For a more thorough cleaning, some parts will occasionally have to be removed. **DO NOT USE** acetone or brake cleaner as they may damage painted surfaces. Follow manufacturer's label instructions when using any type of cleaning product. After cleaning, wipe unpainted metal surfaces with a light coating of quality oil or grease for protection.



WARNING: DO NOT USE gasoline or other petroleum products to clean the machine. They have low flash points and can explode or cause fire.



CAUTION: When using cleaning solvents work in a well-ventilated area. Many cleaning solvents are toxic if inhaled.



MACHINE LOCATION

Know the weight of your machine. Be sure the surface where the lathe will be placed will support the weight of the machine. Also include the weight of any additional equipment that may be installed on the lathe, operator's weight, and weight of heaviest piece part that will be run.

Provide adequate work space around the machine, taking into consideration the largest piece part that will be processed. Keep areas open for access to electrical panel and other maintenance areas.

For best results, operate the lathe in a dry environment that is free from excessive moisture, airborne abrasives, and hazardous chemicals.

Place the machine near an existing power source. Protect the power cord from material handling traffic, and other potential hazards.



TRANSPORTING AND LIFTING

⚠ CAUTION: Lifting and carrying operations should be carried out by skilled workers, such as a truck operator, crane operator, etc. If a crane is used to lift the machine, attach the lifting chain carefully, making sure the machine is well balanced. Choose a location that will keep the machine free from vibration and dust from other machinery. Keep in mind that having a large clearance area around the machine is important for safe and efficient working conditions.

Follow these guidelines when lifting:

- Always lift and carry the machine with the lifting holes provided at the top of the machine.
- Use lift equipment such as straps, chains, capable of lifting 1.5 to 2 times the weight of the machine.
- Take proper precautions for handling and lifting.
- Check if the load is properly balanced by lifting it an inch or two.
- Lift the machine, avoiding sudden accelerations or quick changes of direction.
- Locate the machine where it is to be installed, and lower slowly until it touches the floor.





figure 3



- The lift truck must be able to lift at least 1.5 – 2 times the machines gross weight.
 - Make sure the machine is balanced. While transporting, avoid rough or jerky motion, and maintain a safe clearance zone around the transport area.
 - Use a fork lift with sufficient lifting capacity and forks that are long enough to reach the complete width of the machine.
 - Remove the securing bolts that attach the machine to the pallet.
 - Approaching the machine from the side, lift the machine on the frame taking care that there are no cables or pipes in the area of the forks.
 - Move the machine to the required position and lower gently to the floor.
 - Level the machine so that all the supporting feet are taking the weight of the machine and no rocking is taking place.
1. Unbolt the lathe from the shipping box pallet.
 2. Select a suitable location for the lathe that is dry, has adequate lighting, and enough room to be able to service the lathe on all four sides.
 3. Do not try and lift the lathe by the spindle.
 4. Use two solid steel bars 1-3/8" (35mm) diameter X 30" (760mm) long (min.) They should extend at least 4" (100mm) on each side of the lathe. Place and steady the bars, then sling as shown in (fig. 3).



Note: Make sure that by inserting the steel bars you are not damaging the DRO "Y" axis scale.

5. If using lift straps to raise the machine; make sure they are in good condition and each one capable of lifting 4500 lbs. (2052kgs.). Make sure the lift straps are routed in such a way as not to damage the lead screw, feed rod, or control rod.
6. Remember. The headstock carries most of the weight of the lathe. Double check the weight ratings and connections before doing the actual lift. Verify that the load is properly balanced by lifting it an inch or two. (25 – 50mm)
7. Avoid any sudden accelerations or change of direction while the lathe is lifted.
8. If you cannot lift the lathe using the two solid steel bars because of an interference issue, you may need to consult an equipment mover for assistance.




INSTALLATION

IMPORTANT:

Consider the following when looking for a suitable location to place the machine:

- Overall weight of the machine.
- Weight of material being processed.
- Sizes of material to be processed through the machine.
- Space needed for auxiliary stands, work tables, or other machinery.
- Clearance from walls and other obstacles.
- Maintain an adequate working area around the machine for safety.
- Have the work area well illuminated with proper lighting.
- Keep the floor free of oil and make sure it is not slippery.
- Remove scrap and waste materials regularly, and make sure the work area is free from obstructing objects.
- If long lengths of material are to be fed into the machine, make sure that they will not extend into any aisles.
- **LEVELING:** The machine should be sited on a level, concrete floor. Provisions for securing it should be in position prior to placing the machine. The accuracy of any machine depends on the precise placement of it to the mounting surface.
- **FLOOR:** This tool distributes a large amount of weight over a small area. Make certain that the floor is capable of supporting the weight of the machine, work stock, and the operator. The floor should also be a level surface. If the unit wobbles or rocks once in place, be sure to eliminate by using shims.
- **WORKING CLEARANCES:** Take into consideration the size of the material to be processed. Make sure that you allow enough space for you to operate the machine freely.
- **POWER SUPPLY PLACEMENT:** The power supply should be located close enough to the machine so that the power cord is not in an area where it would cause a tripping hazard. Be sure to observe all electrical codes if installing new circuits and/or outlets.
- To avoid any twisting to the bed, make sure the location where the lathe will be set is absolutely flat and level. Use a precision level on the bed ways both front to back and side to side. The leveling pads included in the tool box and the leveling screws in the pockets of the base will help to level the lathe. You will be able to obtain more accuracy with a lathe that is level.
- Place machine over (6) foundation bolts (previously located). Machine should be located allowing sufficient area for proper operation and maintenance (chip removal, etc.) Minimum 24" (610mm) from wall at back and tailstock end.



Pedestal Mounting Locations

tolerance: $\pm .12$ " on linear dimensions



Level Adjustment

Once the machine is located on the bolts, a machinist's level should be used alternately on the cross slide and slide ways of the lathe as shown in (fig. 5). Minute adjustments of adjusting bolts should be made until the machine is accurately leveled.

(a) Bed Level – Longitudinal Direction

When using precision level along bed, maximum reading to be within 0.0005" in 12" (0.04mm/m)

(b) Bed Level – Transverse Direction

When using precision level, all readings to be within 0.0005" in 12" (0.04mm/m)






figure 4



(b)

(a)

figure 5






figure 6



OVERALL DIMENSIONS





ELECTRICAL



WARNING: Baileigh Industrial is not responsible for any damage caused by wiring up to an alternative 3-phase power source other than direct 3-phase. If you are using an alternate power source, consult a certified electrician or contact Baileigh Industrial prior to energizing the machine.



CAUTION: HAVE ELECTRICAL UTILITIES CONNECTED TO MACHINE BY A CERTIFIED ELECTRICIAN!
Check if the available power supply is the same as listed on the machine nameplate.



WARNING: Make sure the grounding wire (green) is properly connected to avoid electric shock. DO NOT switch the position of the green grounding wire if any electrical plug wires are switched during hookup.

Motor Specifications

Your tool is wired for 220 volt, 60Hz alternating current. Before connecting the tool to the power source, make sure the machine is cut off from power source.

Considerations

- Observe local electrical codes when connecting the machine.
- The circuit should be protected with a time delay fuse or circuit breaker with a amperage rating slightly higher than the full load current of machine.
- A separate electrical circuit should be used for your tools. Before connecting the motor to the power line, make sure the switch is in the "OFF" position and be sure that the electric current is of the same characteristics as indicated on the tool.
- In the event of a malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This tool is equipped with an electric cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into a matching outlet that is properly installed and grounded in accordance with all local codes and ordinances.
- Improper connection of the equipment-grounding conductor can result in risk of electric shock. The conductor with insulation having an outer surface that is green with or without yellow stripes is the equipment-grounding conductor. If repair or replacement of the electric cord or plug is necessary, do not connect the equipment-grounding conductor to a live terminal.



⚠ WARNING: In all cases, make certain the receptacle in question is properly grounded. If you are not sure, have a qualified electrician check the receptacle.

- Check with a qualified electrician or service personnel if the grounding instructions are not completely understood, or if in doubt as to whether the tool is properly grounded.
- All line connections should make good contact. Running on low voltage will damage the motor.
- Repair or replace damaged or worn cord immediately.

Power cord connection:

⚠ WARNING: Failure to follow proper lockout / tagout procedures can result in **SERIOUS OPERATOR INJURY OR DEATH.**

1. Locate the junction box at the rear of the lathe and open the cover. (fig. 7)
2. Insert a fitting into the open hole at the bottom of the enclosure to grip the power cord (supplied by customer).
3. Connect the three power wires to the terminals labeled **R**, **S**, and **T**. Connect the ground wire (typically green) to the **E** ground terminal. (Check that the screws are securely tightened.)
4. Inspect the power cord for any damage incurred during installation.




figure 7



SAFETY FEATURES



Opening the chuck guard will stop machine functions.




With the gear cover off, the machine will not run.

Pressing the E-STOP (Emergency) button will stop machine functions.




Stepping on the foot pedal will stop machine functions.





GETTING TO KNOW YOUR MACHINE





Item	Description	Item	Description
1	Jog Button	23	2 Axis Digital Readout
2	E-Stop Button	24	Tailstock
3	Main Power Switch	25	Compound Rest
4	Power "ON" Pilot Lamp	26	Cone Clutch Adjuster
5	Coolant Power Switch	27	Thread Dial Indicator
6	Feed Selector Dial	28	Leadscrew
7	Feed Selection Knob	29	Feed Rod
8	Oil Sight Gauge	30	Feed Axis Selector
9	Feed Selection Knob	31	Adjustable Trip Dogs
10	Feed Selection Knob	32	Spindle Control Lever
11	Feed I/II Selection Knob	33	Half Nut Engage Lever
12	Feed Direction Knob	34	Trip Arm
13	Spindle Speed Lever	35	Feed Engage Lever
14	+/- Gear Shift Lever	36	Oil Sight Glass
15	H/L Gear Shift Lever	37	Brake Pedal
16	Chuck Guard	38	Apron Hand Wheel
17	Spindle and Chuck	39	One-Shot Oiler
18	Steady Rest	40	Cross Traverse Handle
19	Halogen Work Light	41	Cross Traverse Slide
20	Follow Rest	42	Micrometer Saddle Stop
21	Tool Post	43	Feed Stop Selection Wheel
22	Coolant Control Valve		



WARNING: Failure to follow proper lockout / tagout procedures can result in **SERIOUS OPERATOR INJURY OR DEATH.**



figure 8



figure 9

Remove (6) screws from the panel shown in (fig. 8) to gain access to the electrical panel.



figure 10




figure 11

Shown in (fig. 10) is the 1/8 Hp coolant pump. Remove the panel for access to the pump. (Fig. 11) shows the screen panel that can be removed to get access to the coolant sump.



figure 12 – Brake with switch



figure 13 – Chuck guard switch



Steady Rest

The steady rest on the **PL-1860** lathe is used to support long, small diameter stock that otherwise could not be turned. The steady rest can also be used in place of the tailstock when access to the cutting tool is required at the outboard end of the piece part. By loosening the nut in the base, the steady rest can be re-positioned along the slide rails.



figure 14

Follow Rest

The follow rest is typically used for small diameter stock to prevent the piece part from “springing” under pressure from the tool. The follow rests, which are opposite the tool post, act as supports to counter balance the force exerted on the piece part by the tool. The tool and the supports form a triangle around the part to help minimize vibration. The follow rest has two adjustable brass points to allow rotation of jobs without causing abrasive scratches. The soft points will need replacement when they wear out.



figure 15



Dead Center

A dead center is a one-piece center that does not rotate with the component it is mounted into. It is used to support long, slender piece parts. Use the dead center when the piece part does not rotate on the tip and does not generate friction.



WARNING: When using a center in the spindle to mount a work piece, the other end of the work piece **MUST** be supported by a center installed in the tailstock quill to safely hold the work piece in place during operation. If a center is not used the work piece can be ejected from the lathe when the spindle rotates. This could cause serious personal injury or property damage.



Note: To avoid wearing out the dead center prematurely or damaging the piece part, use low spindle speeds. Also keep the tip of the dead center mounted in the tailstock well lubricated with an anti-seize compound.

Tailstock

The tailstock consists of the base and the base lock handle, barrel and the barrel lock handle, hand wheel, body, and screw. The tailstock on a lathe has many functions including supporting the piece part opposite the headstock. It also has a barrel imprinted with graduations in millimeters and inches and a #3 Morse taper for securing drill bits, and centers. The tailstock can be easily set or adjusted for alignment or non-alignment with respect to the center of the spindle. By turning the tailstock handwheel you can advance or retract the barrel in the tailstock. Both live and dead centers have 60° conical points to fit center holes in the end of the cylindrical piece part.



figure 16

When mounting a long slender piece part that extends more than 2-1/2 times its diameter beyond the jaws of the chuck, mount a center in the tailstock to support it.



1. Before mounting a piece part onto the tailstock dead center, DISCONNECT POWER TO THE LATHE.
2. Thoroughly clean and dry the tapered surfaces of the tailstock quill bore and the point of the dead center. Apply a thin coat of light weight machine oil to the surfaces and wipe again to leave a minimal amount of oil on the mating surfaces.
3. Using the tailstock hand wheel, feed the quill out from the casting at least 1" (25.4mm) but not more than 2" (50.8mm).
4. Center drill the tailstock end of the piece part to match the tip of the dead center. This will help keep the piece part from slipping off the center tip.
5. Seat the dead center into the quill and position the tailstock so that the tip of the center presses against the piece part to hold it in place. Tighten the tailstock lock lever.
6. Rotate the tailstock hand wheel clockwise (cw) to press the center into the piece part until snug. Tighten the quill lock lever.
7. To remove the dead center from the quill, hold onto it with one hand and rotate the hand wheel counterclockwise (ccw) until the center falls out.

Quick Change Tool Posts

This lathe comes with a quick change four-way tool post. It is mounted on top of the compound slide and can be loaded with a maximum of four tools. Use a minimum of two bolts to secure the tooling.



figure 17



LATHE SETUP

⚠ WARNING: DO NOT start the lathe until all machine assembly has been completed and you have been properly trained and understand all control functions. When performing machine assembly make sure to follow proper lockout / tagout procedures. Failure to comply could result in accidental starting of the lathe resulting in **SERIOUS OPERATOR INJURY OR DEATH.**

Lubrication (Before operating this lathe, make the following important checks.)

- Fill the headstock to the level as indicated in the sight gauge window (1) with Shell Tellus #32 viscosity oil (or equivalent).
- Fill the gearbox to the level as indicated in the sight gauge window (2) with Shell Tellus #68 viscosity oil (or equivalent).
- Fill the carriage apron to the level as indicated in the sight gauge window (3) with Shell Tellus #68 viscosity oil (or equivalent).




figure 18




figure 19

Chuck

This lathe has a 8" (203mm) 3-jaw chuck already installed. This is a scroll- type chuck which means that all three jaws close together and are self-centering.

The 3-jaw chuck has cam lock mounting. Note that there are lines stamped on the cam and on the chuck (fig. 20). These indicate whether the cam is in a locked position or an unlocked position where the chuck can be removed.




figure 20



A chuck key is used to turn the locking cams as shown in (fig. 21).

⚠ WARNING: NEVER leave a chuck key in the chuck if the machine is not in use. If the lathe is accidentally started with the key in place, it can become a projectile and cause serious INJURY OR DEATH.



figure 21

Chuck Removal

1. Lay a piece of plywood on the lathe bed directly beneath the chuck. This will help protect the ways if the chuck should fall.

⚠ CAUTION: Use extreme care when installing or removing a chuck so that your hands do not become trapped between the chuck and the plywood.

2. Turn the first cam counterclockwise (ccw) using the chuck key until the line on the cam is aligned with the line on the spindle housing as shown in (fig. 22).
3. Rotate the spindle housing to access the remaining cams and turn each one counterclockwise (ccw) until the marks are aligned. Make sure to support the chuck with one hand as you turn the last cam. You should now be able to remove the chuck.
4. If the chuck is still tight on the spindle, tap the back of the chuck with a wooden or rubber mallet while supporting the bottom of the chuck with your other hand. If needed, rotate the chuck a bit, and tap again. Make sure all the marks on the cams and spindle are properly aligned.




figure 22



Chuck Installation

1. Lay a piece of plywood on the lathe bed directly beneath the spindle housing. This will help protect the ways if the chuck should fall.
2. Lift the chuck up to the spindle and insert the camlock pins into the face of the spindle.
3. While supporting the weight of the chuck, use the chuck key to turn one of the cams until the cam line is between the two "V" marks on the spindle as shown in (fig. 23).
4. Rotate the spindle and repeat step 3 for the rest of the cams.
5. Starting with the first cam, snug up the cams.
6. Finally go around and tighten all of the cams.




figure 23

To Install Cam lock Studs

1. Lay the chuck or faceplate upside down on a flat protected surface.
2. Screw in the three studs up to the depth mark as indicated in photo below.
3. Once the studs are properly positioned, secure them with the socket head cap screws.
4. To adjust the cam lock studs, remove the cap screw and rotate the stud 1 full turn in or out. Re-insert the cap screw and tighten.



figure 24



figure 25



Symbols for Operation

	Switch is on as long as button is pressed (Intermittent)		Metric Thread
	Electrical (DANGER)		Imperial thread
	Pilot Lamp		Module pitch thread
 RED GREEN	Coolant Green: ON Red: OFF		Diametral pitch thread
	Half nut closed	 	Longitudinal feeds Cross feeds half longitudinal values
	Half nut open		Engaged (Downward) Feed Disengaged (Upward)
	Do Not change speed while machine is running.	 Cross feed can be obtained by pushing in the knob (The first line). Thread cutting can be obtained by keeping the knob in neutral position (The second line). Longitudinal feed can be obtained by pulling out the knob (The third line).	



	Right hand thread and longitudinal feed towards the headstock side.		
	Left hand thread and longitudinal feed towards the tailstock side.		
mm / ins /	Auto feed per revolution in Metric. Auto feed per revolution in Imperial.		
	Lube pump; push button		
	Cone clutch; adjust clockwise	 	Lever Up - Engage Auto Traverse Lever Down - Engage Manual Traverse
	Main spindle reverse rotation (clockwise rotation; looking from tailstock)		
	Main spindle forward rotation (counterclockwise rotation; looking from tailstock)		
	Lube flow, adjust counterclockwise		Emergency Stop



Coolant System

The coolant system delivers the coolant to the nozzle which can be positioned where needed. The coolant pump is energized by turning on a two position switch as shown in (fig. at right) and the flow is controlled with the valve lever.




figure 26

OPERATING CONTROLS

- Pressing button (1) will jog the spindle to allow the feed selection knobs to engage at their desired position.
- Pressing the E-STOP button (2) will immediately stop the machine in the event of incorrect operation or a dangerous situation. Twist the emergency stop button clockwise (cw) to reset.
- Selector switch (3) when turned clockwise (cw) will supply power to the entire lathe.
- The two position coolant switch (4) is used to START or STOP the coolant pump.
- The white pilot light (5) when lit, indicates that the power selector switch has been turned to the ON position and the machine has power.




figure 27



Spindle Speeds

CAUTION: Never change spindle speeds while the motor or spindle is in motion.




figure 28

The speed of the spindle is set by the position of the three speed control handles as shown in (fig. 28). As an example they will be set for a speed of 95 RPMs. The selector handle (13) is rotated to the center position. Each of the three positions will click when the handle is properly rotated. The 95 RPM selection is in the blue area, so selection handle (14) should be in the minus (-) position as shown. To the right of the indicator arrow is the 95 RPM value. The (H) indicates high speed, whereas the 30 RPM value would be the low (L) speed setting. The selector handle (15) is therefore set to (H) for high speed. Spindle speed is measured in RPM (revolutions per minute). The following 12 spindle speeds are possible on this lathe: 30, 55, 70, 95, 160, 200, 325, 540, 700, 1000, 1600, and 2000 RPM.




Note: If any of the 3 handles offer resistance when shifting, briefly press the jog button (1) in (fig. 27) to line up the gears and allow the handle to shift.



Feed Direction

⚠ CAUTION: Never change spindle speeds while the motor or spindle is in motion.


This lathe can cut both left and right while feeding or threading, and across the ways when performing facing operations. The feed direction is controlled with the selection knob (12) as shown in (fig. 29). When rotated to the right position the apron will move to the left along the bed, as indicated by the arrow, or the cross feed will travel away from the operator.



Rotating the handle to the left will reverse the direction of the feeding or threading.

The quick relieving and smooth fine feeding (quick change over from roughing to fine feeding) can be obtained by operating the two step feed change gears as explained below:

1. Stop the spindle by putting the spindle control lever (32) into NEUTRAL stop position.
2. Rotate the feed I / II selection knob (11) from position I to II for quick relieving (rough feed).
3. Rotate the feed I / II selection knob (11) from position II to I for smooth fine feeding.
4. Start the spindle by putting the spindle control lever (32) in either the forward or reverse position.



Note: Never force any of the selection handles or knobs on the lathe. If a handle will not engage, rotate the chuck carefully using the jog button (1), while applying light pressure to the selector handle or knob. As the chuck rotates, the gears will align, allowing the selector handle or knob to engage.



Feed Selector Knobs

The three knobs as shown in (fig. 30) are used to change the feed rate or number of threads-per-inch. This part of the lathe is commonly referred to as the Quick Change Gear Box. It has been designed to handle both inch (imperial) and metric (mm). The knob on the left (10) A, B, & C, the center knob (9) D, E, & F, and the right knob (7) R, S, T, & U are set to a selected value from the chart on the following page. The feed selector dial (6) will be set to a numerical value from the chart. (This chart is also located on the front of the headstock gear cover.)



IMPORTANT: DO NOT shift quick change gears at speeds above 325 rpm.



Note: DO NOT force the selection knobs into position. If they do not engage, carefully rotate the chuck by pressing the jog button (1). As the chuck is rotated, it aligns the gears, and the selector knob will engage.




figure 30



Thread Cutting and Feed Chart

As an example, 24 threads per inch has been selected as shown in red.

The change gears (V) will be 24T, 57T, and 64T.

The areas in yellow will be the settings of the knobs as shown below.




figure 32



LEAD SCREW 4 T.P.I.		64T		24T		64T		41T	
		(V)		57T		(W)		31T	
 T/1"	LEVER	1	2	3	4	5	6	7	8
	I CRY	32	36	40	44	46	48	52	56
	I CSY	16	18	20	22	23	24	26	28
	I CTY	8	9	10	11	11½	12	13	14
	II CSY	4	4½	5	5½	5¾	6	6½	7
(V)	II CTY	2	2¼	2½	2¾	2⅞	3	3¼	3½
 mm	I ATW	0.4	0.45	0.5	0.55		0.6	0.65	0.7
	I BTW	0.5					0.75		
	I ASW	0.8	0.9	1.0	1.1	1.15	1.2	1.3	1.4
	I BSW	1.0		1.25			1.5		1.75
	I ARW	1.6	1.8	2.0	2.2	2.3	2.4	2.6	2.8
(V)	I BRW	2.0	2.25	2.5	2.75		3.0	3.25	3.5
 DP	II BSW	4.0	4.5	5.0	5.5	5.75	6.0	6.5	7.0
	II BRW	8.0	9.0	10	11	11.5	12	13	14
	I CRY	32	36	40	44	46	48	52	56
	I CSY	16	18	20	22	23	24	26	28
	I CTY	8	9	10	11	11½	12	13	14
(W)	II CSY	4	4½	5	5½	5¾	6	6½	7
 MP	I ATW	0.4	0.45	0.5	0.55		0.6	0.65	0.7
	I BTW	0.5					0.65		
	I ASW	0.8	0.9	1.0	1.1	1.15	1.2	1.3	1.4
	I BSW	1.0		1.25			1.5		1.75
	I ARW	1.6	1.8	2.0	2.2	2.3	2.4	2.6	2.8
(W)	I BRW	2.0	2.25	2.5	2.75		3.0	3.25	3.5
 in/C	II BSW	4.0	4.5	5.0	5.5	5.75	6.0	6.5	7.0
	LEVER	1	2	3	4	5	6	7	8
	I ATX	.0012	.0014	.0015	.0016	.0017	.0018	.0020	.0022
	I ASX	.0024	.0028	.0030	.0032	.0034	.0036	.0040	.0044
	I ARX	.0048	.0056	.0060	.0064	.0068	.0072	.0080	.0088
(V)	II ASX	.0096	.0112	.0120	.0128	.0136	.0144	.0160	.0176
	II ARX	.0192	.0224	.0240	.0256	.0272	.0288	.0320	.0252

figure 31



Thread Cutting and Feed Chart

All threads and feeds available on this lathe are displayed in the chart on the previous page and on the front of the headstock gear cover.

To obtain the desired thread or feed required, all change gears must be correctly installed as shown in this chart. This lathe can be set to the following thread sizes and feeds:

Threads:

- 40 Imperial pitches from 2 to 56 T.P.I. (threads per inch) – (see chart on following page)
- 52 Metric pitches from 0.4 to 14mm – (see chart on following page).
- 32 Diametral pitches from 4 to 32 D.P. (diametral pitch) – (see chart on following page)
- 44 Module pitches from 0.4 to 7 M.P. (module pitch) – (see chart on following page)

Feeds: longitudinal

- 40 Imperial from .0012" to .0252" / rev. (with 4 T.P.I. lead screw)
- 40 Metric from 0.032 to .640mm / rev. (with 6mm lead screw)

Feeds: Cross Feeds (1/2 of the longitudinal feed)

- 40 Imperial from .0006" to .0126" / rev. (with 4 T.P.I. lead screw)
- 40 Metric from .015 to .320mm / rev. (with metric lead screw)



Thread Cutting Operation

1. Feed:

- Set the desired feed rate (from chart on front of gear cover)
- With spindle running at desired RPM, engage the feed lever (35) on the apron.

The distance the saddle travels during one revolution of the spindle is called feed and will be established as explained above.

2. Thread pitch / lead:

- Set desired pitch (lead), T.P.I. (threads per inch)
- With spindle running at the desired RPM, engage the half nut lever (33).

The distance the saddle travels during one revolution of the spindle is called lead or pitch. The number of revolutions the spindle makes while the saddle (tool) travels 1" (25.4mm) is equal to T.P.I. (threads per inch).



Note: In normal turning / facing operations it is recommended that the "lead screw" be disengaged to avoid any possible wear.

APRON

The apron houses controls for automatic feeding and threading with a positive interlock between the two to prevent simultaneous engagement. It provides an oil reservoir to supply oil to all of its moving parts. It also has a "one shot" oiler pump (39) to distribute lubricant to the saddle ways that contact the bed ways and cross slide ways.

Feeds – manual: The apron hand wheel (38) may be used to traverse the saddle left or right (longitudinal) either in a rapid motion or as a slow manual feed mechanism.

Feeds – power: Either longitudinal or cross travel are selected by positioning the feed axis selector (30) "IN" (on the first line) for cross feed or "OUT" (on the third line) for longitudinal feed. (fig. 33) To engage the feed; (once direction has been established) push feed engage lever (36) downward until fully engaged (fig. 34). To dis-engage, lift feed engage lever (35).






figure 33

Cone Clutch - The cone clutch adjuster (26) is a safety overload clutch mechanism for the feed system. The adjustment screw increases or decreases the clutch pressure. (See Adjustment Section in this manual.)



Feed Disengagement – The automatic feed disengagement system operates when the adjustable trip dogs (31) come in contact with the trip arm (34) as the apron is moving longitudinally. The four trip dogs are controlled / engaged by rotating the dogs to the frontward position with the selection wheel (43) located at the headstock end of the rod.



Threading

The half nut engagement lever (33) engages / disengages the half nut and lead screw. The feed axis selector (30) must be in neutral (on the second line) in order to engage the half nut. The spindle should be rotating at a relatively low speed to properly engage the half nut, especially for coarse threads.




figure 36

Thread Dial Indicator

The threading dial indicator (27) shown in (fig. 37) is located on the left hand side of the apron. It is used when cutting imperial threads and tells you when to engage the half nut to begin the threading process. The indicator face has eight lines and four numbers printed on the dial. An indicator pin is located at the bottom of the rim. The dial is mounted to a shaft that has a small gear mounted at the opposite end. By loosening a socket capscrew you can pivot the housing to either engage or disengage from the leadscrew. When engaged, the dial will turn as the spindle rotates. If the dial does not turn, re-adjust the housing position.




figure 37

When the half nut is disengaged the dial stops turning. By carefully engaging the half nut as the correct number or line passes by the indicator mark, a thread can be established and the lead maintained through multiple passes, until the required depth is reached.

As an example, to cut 20 threads per inch using the chart in (fig. 38), engage the half nut on any number or line at the indicator mark. You must determine how long you want the thread to be. When you reach that length, disengage the half nut. Return the carriage to the beginning of the cut. Watch the dial and when any number or line comes around to the indicator mark, engage the half nut. Repeat the procedure until you have reached the desired depth of thread required.

The other scale values from the chart are as follows:

- 1 = Engage only on 1
- 1, 5 = Engage on 1 or 5
- 1, 3, 5, 7 = Engage on 1, 3, 5, or 7
- 1 – 8 = Engage on any number or line

INDICATOR TABLE									
2	1-8	7	13,5,7	18	1-8				
2 1/4	1	8	1-8	19	13,5,7				
2 1/2	1,5	9	13,5,7	20	1-8				
3	13,5,7	9 1/2	1,5	23	13,5,7				
3 1/4	1	10	1-8	24	1-8				
3 1/2	1,5	11	13,5,7	28	1-8				
4	1-8	11 1/2	1,5	32	1-8				
4 1/2	1,5	12	1-8	36	1-8				
5	13,5,7	13	13,5,7	40	1-8				
5 1/2	1,5	14	1-8	44	1-8				
6	1-8	15	1-8	48	1-8				

figure 38




WARNING: Before powering up machine, make sure Fwd/Rev. handle is in the center (neutral) position (fig. 39).

All machinery poses a potential for danger when being operated. Accidents result from lack of machine knowledge and failure to pay attention. Always be cautious and alert to the potential for serious injury. Follow safety rules and precautions to lessen the chances of an accident.

Spindle Rotation Control

Spindle rotation is controlled from the handle on the right hand side of the apron as indicated in (fig. 39). Move the handle down and the spindle will rotate in a counterclockwise (ccw) direction. Move the handle up and the spindle will rotate in a clockwise (cw) direction. The middle (neutral) position stops the motor.



Pin will engage hole when in neutral position.




figure 39

Micrometer Saddle Stop

The saddle stop (fig. 40) can be locked to the carriage rail at any point where you want the carriage to stop by tightening the two socket cap screws indicated by the arrows. The saddle stop is used primarily for turning, facing, or boring duplicate parts, as it eliminates taking repeated measurements of the same dimension. To use the stop, just before the carriage reaches the stopping point, shut off the automatic feed and manually run the carriage up against the stop. Use the knob to accurately set the required distance in millimeters. Use the thumbwheel knob to lock the barrel in position.



figure 44

Saddle – Cross Slide and Compound Rest

The lathe saddle is solidly supported and accurately guided by the “V” bed-way in the front and the flat bed-way at the rear. Large “dovetail” ways support and guide both the cross traverse slide (41) and top slide/compound rest (25) to offer smooth movement and solid support for the tool.



Manual Operation:

The carriage (saddle) can be moved manually (longitudinally) either left or right by turning the apron hand wheel (438). To manually feed, a slow even motion is required.



IMPORTANT: Feed axis selector (30) must be in the neutral position.

Powered Operation:

The carriage can be power feed longitudinally at various feed rates selected at the quick change gearbox.



CAUTION: Before engaging power feed, make sure the carriage locking bolt has been loosened sufficiently to allow the carriage to move freely.

The locking bolt is indicated with the arrow in (fig. 41).

1. Establish the required feed rate at the quick change gear box.
2. Determine the direction of feed using the feed direction selection knob (12) located at the headstock.
3. Pull feed axis selector (30) to the "OUT" position (the third line) for longitudinal power feed (fig. 33).
4. Engage feed: Move feed engage handle (35) to the "DOWN" position.
5. To stop: Raise feed engage lever (35) to the disengaged "UP" position.



figure 41

Cross6 Traverse Slide

The cross slide (41) shown in (fig. 42) can also be operated either manually or under power.

Manual Operation:

1. Place feed axis selector (30) in neutral (the second line position).
2. Turn cross traverse handle (40) in desired direction. Distance moved can be read on the micrometer dial.



Powered Operation:

1. Establish the desired feed rate at the quick change gear box.



Note: Cross feeds equal half of the longitudinal values.

2. Determine the direction of feed using the feed direction selection knob (12) located at the headstock.
3. Push feed axis selector (30) to the “IN” position (the first line) (fig. 33).
4. Engage feed: Move feed engage handle (35) to the “DOWN” position.
5. To stop: Raise feed engage lever (35) to the disengaged “UP” position.




figure 42

Compound Rest

The compound rest (25) can only be operated manually. It is mounted on a swivel base that enables it to be mounted at any desired angle after loosening four socket head bolts.



IMPORTANT: DO NOT operate compound rest unless lock screws have been released.



Lock
Screw

figure 43



WARNING: Attempting heavy cuts while the compound rest is extended beyond the end of the base slide-ways can result in **SERIOUS OPERATOR INJURY**.

Half Nut

The half nut is exactly as the term implies; “a nut separated in two pieces” lengthwise. The two half nut pieces are mounted to the apron body in such a way that they can be mechanically separated or brought around the lead screw threads (engaged – disengaged) When the lead screw is rotating, engaging the half nut will cause the apron / carriage to move at the rate determined by the gear ratio set at the quick change gear box. This will then move the tool at the proper rate to cut threads.




figure 44



A positive lockout device is provided to prevent the accidental engagement of two opposing feeds simultaneously. (THE FEED ENGAGE LEVER CANNOT BE ENGAGED WHEN THE HALF NUT IS ENGAGED) Lead screw and half nut life is dependent on three basic conditions.

1. The lead screw and half nut must be clean (no grit or chips)
2. The lead screw and half nut must be properly lubricated.
3. The lead screw and half nut must be properly adjusted to engage evenly and smoothly.

Lead Screw

The 1-3/8" (35mm) diameter lead screw is designed to provide accurate threading capability and long service life. It is protected from overloading by a shear pin. It should be further protected from unnecessary wear by being disengaged from the thread dial indicator when not in use. It is imperative that the lead screw be clean and properly lubricated while threading. In order to obtain maximum accuracy, it is necessary to keep all end play out of the lead screw and the half nut. The lead screw is mounted in adjustable ball thrust bearings so that a "NO FLOAT" condition can be maintained.

Changing Gears for Thread Selection

In order to cut threads and set longitudinal feed and crossfeed rates as listed in the chart (fig. 31) you may need to make a few gear changes.

1. DISCONNECT POWER TO MACHINE.
2. Take off the gear cover (located on the left side of the lathe) by removing the two knobs.
3. Remove a socket head screw, a flat washer, and a spacer to replace either gear "a or c" with another gear (fig. 46).




Note: *DO NOT* place anything hard between the gears to prevent rotation or you could break the teeth.

4. Loosen the pivot nut to rotate the bracket of gear "b". By loosening the nut on the backside of gear "b" you will be able to slide the gear in the bracket slot.
5. After the gears are changed out, make sure they mesh properly before re-tightening.



figure 45



TEST RUN

⚠ CAUTION: Always wear proper eye protection with side shields, safety footwear, and leather gloves to protect from burrs and sharp edges.

1. Before proceeding with a test run, check that the machine is securely mounted in place and that you have read and understand the Operator Safety Instructions at the beginning of this manual.
2. Make sure the machine is properly grounded and the FWD/REV handle is in neutral.
3. Inspect the lathe bed and rest of the machine for any tools and loose parts. Check that all guarding is in place, and that nothing is obstructing the movement of the chuck.
4. Check that the gearbox and carriage sight glasses show adequate oil levels.
5. Check the tension of the (3) V-belts located under the gear cover. You should be able to depress the belts about 1/2" (12.7mm) with normal finger pressure. If they are too tight you could damage the shaft bearing.
6. Select the slowest spindle speed (30 RPM) and let the machine run at that speed for 20 minutes. If everything seems to be functioning normally, increase the spindle speed a step at a time until you reach the maximum speed of 2000 RPM. Figure 28 shows the handles and dial indicating the various speeds. Run each speed change for approximately 5 minutes. Make sure motor has completely stopped before changing speeds.



MACHINE ADJUSTMENTS



WARNING: Make sure the electrical disconnect is OFF before working on the machine.

Always follow proper safety precautions when working on or around any machinery.

Spindle Bearing Adjustment

The massive alloy steel spindle is supported on three high precision bearings. Two closely coupled tapered roller bearings offer maximum axial and radial load capabilities and a precision deep groove ball bearing supports the outboard end.

If after prolonged usage it becomes necessary to tighten the spindle bearings, follow the procedure below:

1. Remove the headstock cover.
2. Position the High / Low gear shift lever (15) to NEUTRAL. (Spindle will be free to rotate)
3. Loosen the “gear positioning nut” (#2) (fig. 47) at least one full turn. Requires first loosening the lock screw on castellated nut so nut can turn.
4. Tighten “Bearing Adjustment” (#3) using spanner wrench. DO NOT OVER-TIGHTEN. Spindle should be snug, but free to rotate by hand. End play (float) should not exceed .0002” / .0003” (.0051 / .0076mm) maximum.
5. Re-tighten gear positioning nut (#2) (fig. 47) to prevent side float of spindle gears. When this nut is fully tightened, find the locking screw (#1) on the castellated nut and tighten to prevent it from working loose.
6. Replace the headstock cover and again check spindle rotation by hand.
7. Place High / Low gear shift lever (15) in LOW position. Check spindle rotation by using the spindle jog button (1) (fig 27). If all seems ok, select a low to medium speed, turn the lathe ON, and allow the spindle to run in a “No Load” condition for 20 -30 minutes. With power OFF, check the spindle nose bearing temperature with your hand. If there is a significant heat build-up, recheck the bearing adjustment and correct if necessary. DO NOT allow the bearing to overheat.





figure 47



Lead Screw Adjustment

Adjustment is made at the tailstock end mounting bracket, but only if end float or side play exists.

1. Disengage lead screw by placing feed selection knob (7) in the "T" position as shown at right.
2. Remove the end dust cover from the mounting bracket.
3. Loosen the setscrew in the round locking nut.
4. Adjust the locking nut (while rotating the lead screw by hand to avoid over-tightening or binding.) The leadscrew should rotate freely and have no more than 0.0004" (0.01mm) of end play.
5. Re-tighten set screw on round locking nut.
6. Replace the lead screw dust cover.



Set screw




figure 48

Half Nut Adjustment

To maintain the original smooth and accurate operation of the half nut, an adjustable gib strip is provided.

1. Remove the thread dial indicator (27) (one bolt-see arrow).
2. Loosen the four lock nuts of the gib adjusting screws.
3. Adjust the four gib adjusting screws evenly; center two screws first, until a smooth motion is felt while working the half nut engagement lever.
4. When lever motion is smooth, re-tighten lock nuts.
5. Observe actual half nut engagement with the lead screw to see that no misalignment is occurring.
6. Replace the thread dial indicator (27).



figure 49



Lathe Alignment

1. Position the test bar between the dead centers (one in the main spindle taper and one in the tailstock taper).
2. Determine the direction and amount of misalignment with a dial indicator mounted on the saddle. The indicator pointer should be against the side of the test bar as it traverses from end to end on the test bar.




figure 50

3. To correct any side to side error release the tailstock clamp lever (A).
4. Using the two adjustment screws on either side of the tailstock base and the scale, lineup the tailstock to the headstock.
5. Tighten the clamp lever and re-check the alignment until perfect.




figure 52




figure 51



V-Belt Removal and Adjustment



Note: Always replace belts as a matched set of four.

V-belts will stretch through usage. Check the tension of the belts every three months. More often if the lathe is used daily.

1. To access the drive belts, remove the top gear cover, the lower end plate, and the lower back plate from the head stock end of the lathe (fig. 57 & fig. 58).
2. Remove the hex nut and washers as indicated by the arrow in (fig. 58).
3. Carefully raise the motor bracket up to release tension on the belts so they can be removed. (Note that the brake assembly also raises with the motor)
4. Place the new belts onto the four groove pulley and let the motor down gently.
5. Replace the washers and the hex nut and tighten the motor bracket down securely. After tightening, push the center of each belt. When properly tensioned the amount of deflection should be approximately 0.75" (19mm).



Note: If you change the position of the motor mounting bracket due to belt stretching or belt replacement, it may be necessary to re-adjust the foot pedal brake and the micro limit switch.



figure 57



figure 58



Foot Brake Adjustment

Adjustment for wear on the brake shoe (which is mounted inside the motor pulley) is made by the adjusting nut (A) on the end of the brake cable.

1. Hold the screw end (B) of the cable with your right hand and use your left hand to depress the oscillating arm (C).
2. Then turn the adjusting nut (A) counterclockwise (ccw) as necessary with the hand that previously held the screw end.
3. Turn the adjusting nut in half turn increments: i.e. $\frac{1}{2}$, 1, $1\frac{1}{2}$, 2, $2\frac{1}{2}$ etc. in order to get the curve of the adjusting nut in mesh with the connecting pin.
4. Release the oscillating arm and make sure the adjusting nut and the connecting pin are in mesh.




figure 59

The brake pedal limit switch (shown at right) may need to be re-adjusted after adjusting the brake band tension.

1. Loosen the jam nut on the switch.
2. Raise or lower the switch for best contact with the brake actuator bar and re-tighten the jam nut.



Note: The function of the limit switch is to cut out the motor drive when the brake pedal is operated. The switch plunger should be depressed when the pedal is in the free position. As soon as the pedal is stepped on the switch plunger should be released to cut out the motor drive.



Saddle Adjustment

Prolonged / extensive use may require that the carriage saddle) gibs be re-adjusted in order to restore original rigidity and accuracy.

Front: Adjustments are made from the retaining sleeves #2) located on the top face of the saddle at both left and right front wings.

1. Loosen locking bolts (#1) slightly.
2. Turn the slotted head sleeve (retaining sleeve #2) counterclockwise (ccw).
3. Re-clamp the locking bolt (#1). Repeat on opposite saddle wing.

Check for proper adjustment by traversing saddle back and forth with the apron hand wheel. If too tight or too loose, repeat procedure steps 1, 2, & 3 above until correct. A 30° turn at the sleeve equals 0.004" (0.1mm) take-up in the strip.




figure 60

Rear: Adjustments are made by means of the taper gib strip under the rear side of the saddle.

1. Loosen jam screw (#3) (fig. 60) at the tailstock end.
2. Tighten adjusting screw at the headstock end until the correct adjustment is achieved.
3. Re-tighten jam screw (#3).



Note: Tightening the jam screw will tend to loosen the adjusting screw slightly. Repeat steps 2 & 3 above if required.



Cross feed Screw / Nut Backlash Adjustment

If the cross feed screw and nut assembly become worn to the extent that accuracy is diminished appreciably, they should both be replaced. If some wear has occurred, you can reduce the effect of the wear by adjusting the backlash.



IMPORTANT: Normal wear tends to occur near the center travel position on the screw. Therefore, to avoid binding you should make the adjustments with the nut in one extreme or the other where the wear is at a minimum.

1. Turn the cross feed handwheel to move the far enough in or out to expose the cover plate.
2. Remove the countersunk socket head screw and cover located in the middle of the cross slide.
3. Adjust the socket screws in very small increments (1° – 2° at a time) and test the crossfeed handwheel for backlash.
4. Check the amount of back-lash on the cross feed dial. A dial indicator can be used to determine actual slide movement.
5. When the backlash is set. Install the cover plate and secure in place with the countersunk socket head screw.
6. Install and tighten the set screw to lock the adjustment screw. DO NOT overtighten the set screw and bend the cover plate.



figure 61





Tapered Gib Adjustment

Both the cross slide and the compound rest are equipped with tapered-fully adjustable gibs.

1. Position the slide (lengthwise) on the dovetail way so that there is no “overhang” of the way.
2. Back off the gib locking screw at the rear end of the slide.
3. Adjust the front gib screw until the slide is snug. Re-tighten the gib locking screw at the rear of the slide. **DO NOT OVER-TIGHTEN.**
4. Recheck the fit or feel of the slide and re-adjust if necessary.

Feed Rod Adjustment

The feed rod and feed gears are protected from overload by an adjustable tension cone clutch located in the apron.




figure 62

Turn adjusting knob clockwise (cw) to increase driving power.




figure 63



LUBRICATION AND MAINTENANCE



WARNING: Make sure the electrical disconnect is OFF before working on the machine.

Maintenance should be performed on a regular basis by qualified personnel.

Always follow proper safety precautions when working on or around any machinery.

- Check daily for any unsafe conditions and fix immediately.
- Check that all nuts and bolts are properly tightened.
- On a weekly basis clean the machine and the area around it.
- Lubricate threaded components and sliding devices.
- Apply rust inhibitive lubricant to all non-painted surfaces.



Note: Proper maintenance can increase the life expectancy of your machine.

Daily Maintenance

- Do a general cleaning by removing dust and metal chips from the machine.
- Top off the coolant tank. (80% of full tank capacity)
- Clean drain screen.
- Check that any guarding, shields, and emergency stop are in good working order.
- Inspect brake pedal and brake switch for proper operation.
- Wipe down and re-oil slideways.

Weekly Maintenance

- Thoroughly clean the machine including the coolant tank.
- Check sight glasses for gear oil levels (add oil as needed)

3 Month Maintenance

- After initial 3 months replace the headstock, gearbox, and apron oil and then every six months after that.



Oil Disposal

Used oil products must be disposed of in a proper manner following your local regulations.

Accessing and Cleaning the Coolant System

The coolant tank is located at the back of the lathe and is an integral part of the frame. See (fig. 65)

- Remove the top access cover screen for access to the reservoir.
- To access the motor and pump remove the rear panel as in (fig. 64)
- Suction the coolant from the tank, and wash out any dirt and debris. (Check for anything that might be obstructing the pump inlet.)
- Refill the tank with coolant solution. (80% of full tank capacity)
- Replace both access covers.

Oils for Lubricating Coolant

Any 10:1 (water to coolant) solution will work, however we recommend Baileigh B-Cool 20:1 (water to coolant) biodegradable metal cutting fluid. It has excellent cooling and heat transfer characteristics, is non-flammable, and extends tool and machine life. Each gallon of concentrate makes 21 gallons of coolant.



figure 64



figure 65



Headstock

To fill the head stock, first take off the end gear cover. Remove the plug from the street elbow as indicated with the arrow in (fig. 66).

Fill with Shell Tellus #32 oil, approximately 1-1/2 gallon (6 liters) or until the level in the sight glass is at the halfway mark.

The first oil change should be after 200 hours. Thereafter about every 6 months.

To drain the oil, connect a hose or tube to the valve shown at right. Turn the handle 90° clockwise (cw) to open the valve.



Drain Valve

Quick Change Gear Box

To fill the Gear Box, first take off the end gear cover. Remove the oil fill cap as shown in (fig. 67).

Fill with Shell Tellus #68 oil, approx. 1 1/4 gallon (5 liters) or until the level in the sight glass is at the halfway mark. Change oil every 6 months.

The reservoir is an oil bath (dip)



figure 66




figure 67



Compound Rest, Cross Slide, Feed Screw, & Nut

Lubricate indicated fittings (fig. 68) with 2 – 3 drops daily, or as needed, with a Shell Tellus 32 oil or equivalent.




figure 68

Lead screw, Feed Rod, and Half Nut

Lubricate surfaces daily with brush or cloth.
Lead screw must be cleaned and threads lightly oiled.
Remove cap on lead screw bracket to fill with Shell Tellus #32 oil.
To replace oil, remove the drain plug as shown in (fig. 69).




figure 69



Apron

The apron is lubricated from an internal reservoir of oil. Ensure that the sight gauge shows oil at the halfway mark.

To fill the apron, remove the fill cap. Add 1/2 gallon (approx. 2 liters) of Shell Tellus #68 oil.

The drain plug is located at the bottom of the apron (fig. 70).

Sight Glass





figure 70

Bed Ways, Saddle, and Cross Slide

Before operation, push the one-shot pump (1 – 3) times, three times a day under normal usage.

The oil comes from the apron reservoir.

The oil flow is controlled with the lube flow adjustor.



Lube Flow
Adjustor



figure 71

Quick Change Gears

Inspect and grease the gear teeth weekly.

The gears must not be allowed to run dry.

Re-attach gear cover after lubricating.



figure 72



Tail Stock

Oil the tailstock daily at the three oil fittings located at the top of the tailstock (see fig. 73).
Lubricate with 2 – 3 drops of light lubricating oil.

Storing Machine for Extended Period of Time

If the Lathe is to be inactive for a long period of time, prepare the machine as follows:

- Detach the plug from the electrical supply panel.
- Remove the chuck, steady rest, follow rest, tool post, and tail stock. Cover with a rust protectant.
- Empty and clean the coolant tank.
- Clean and grease the machine so no bare metal is left unprotected.
- Cover the machine




figure 73

BAILEIGH INDUSTRIAL, INC. 1625 DUFEEK DRIVE MANITOWOC, WI 54220

PHONE: 920. 684. 4990 FAX: 920. 684. 3944

www.baileigh.com

BAILEIGH INDUSTRIAL, INC. 1455 S. CAMPUS AVENUE ONTARIO, CA 91761

PHONE: 920. 684. 4990 FAX: 920. 684. 3944

BAILEIGH INDUSTRIAL LTD. UNIT 1 FULLWOOD CLOSE

ALDERMANS GREEN INDUSTRIAL ESTATE

COVENTRY, CV2 2SS UNITED KINGDOM

PHONE: +44 (0)24 7661 9267 FAX: +44 (0)24 7661 9276

WWW.BAILEIGHINDUSTRIAL.CO.UK

BAILEIGH INDUSTRIAL GMBH HOFENER STRAßE 64

70736 FELLBACH

DEUTCHSLAND

WWW.BAILEIGHINDUSTRIAL.DE