

170184.0916/f

de	Zimmereikerventräse	Originalbetriebsanleitung	5
en	Carpentry bird's mouth cutter	Original operating instructions	15
fr	Fraiseuse de charpente	Traduction de la notice d'emploi originale	25
it	Fresatrice intagli per carpenteria	Istruzioni per l'uso originali	35
nl	Kerffrees	Originele gebruiksaanwijzing	45
es	Fresadora de ranuras en V para carpinteros	Manual de instrucciones original	55
fi	Ammattilaisen viistourajyrin	Alkuperäiskäyttöohje	65
sv	Snickerispårfräs	Originalbruksanvisning	74
da	Tømmerkærvfræser	Original driftsvejledning	83



ACHTUNG!

Diese Betriebsanleitung enthält Hinweise, die für das sichere Arbeiten mit dieser Maschine wichtig sind. Lesen Sie deshalb unbedingt diese Betriebsanleitung.

WARNING!

These operating instructions contain important information on safe working practices for this machine. It is therefore essential that you read these operating instructions carefully.

ATTENTION !

Cette notice d'emploi contenant des indications importantes pour la sécurité du travail avec cette machine, veuillez donc la lire impérativement.

ATTENZIONE!

Le presenti istruzioni per l'uso contengono avvertenze importanti per lavorare con sicurezza con questa macchina. Per questo motivo è assolutamente necessario leggere le presenti istruzioni per l'uso con la dovuta accuratezza.

ATTENTIE!

Deze gebruiksaanwijzing omvat instructies die voor het veilige werken met deze machine belangrijk zijn. Lees vandaar in ieder geval deze gebruiksaanwijzing.

¡ATENCIÓN!

Lea atentamente este manual de instrucciones, que contiene la información necesaria para garantizar la seguridad en el trabajo con esta máquina.

HUOMIO!

Tämä käyttöohje sisältää ohjeita, jotka ovat tärkeitä koneen turvallisen käytön kannalta. Lue käyttöohje sen vuoksi huolellisesti!

OBSERVERA!

Denna bruksanvisning innehåller anvisningar, viktiga för säkert arbete med denna maskin. Läs därför denna bruksanvisning noga!

GIV AGT!

Denne driftsvejledning indeholder vigtige henvisninger om sikkerheden ved brug af maskinen. Læs driftsvejledningen omhyggeligt.

D - EG Konformitätserklärung

Wir bescheinigen hiermit, dass die Maschine ZK 115 Ec den angeführten EU-Richtlinien entspricht. Bei Konstruktion und Bau wurden die gelisteten Normen angewendet.

Bevollmächtigter für die Zusammenstellung der technischen Unterlagen: Mafell AG

GB - EC Declaration of Conformity

We herewith confirm that the machine ZK 115 Ec complies with the EU directives quoted. The standards listed were used for design and construction.

Empowered person for the configuration of the technical documents: Mafell AG

F - Déclaration CE de conformité

Nous déclarons par la présente que la machine ZK 115 Ec est conforme aux directives CE applicables comme suit. Lors de la construction, les règlements suivants ont été utilisés.

Plénipotentiaires pour l'assemblage des documentations techniques: Mafell AG

I - Dichiarazione di conformità CE

Con la presente certifichiamo che la macchina ZK 115 Ec è conforme alle seguenti direttive CE applicabili. Nella progettazione e la costruzione sono state applicate le seguenti norme.

Responsabile per la composizione della documentazione tecnica: Mafell AG

NL - EG conformiteitsverklaring

Wij bevestigen hiermede dat de machine ZK 115 Ec aan de vermelde EU-richtlijnen beantwoord. Bij constructie en bouw werden de vermelde normen toegepast.

Gemachtigde voor de samenstelling van de technische documenten: Mafell AG

E - Declaración de conformidad CE

Con la presente se certifica que la máquina ZK 115 Ec cumple las directivas europeas mencionadas, las cuales forman la base tanto del diseño constructivo como de los procesos de fabricación.

Apoderado legal para la compilación de la documentación técnica: Mafell AG

FIN - EY-vaatimustenmukaisuusvakuutus

Vakuutamme täten, että kone ZK 115 Ec vastaa mainittujen EU-direktiivien vaatimuksia. Sen suunnittelussa ja valmistuksessa on sovellettu luettelossa ilmoitettuja standardeja.

Teknisten asiakirjojen laatimiseen valtuutettu henkilö: Mafell AG

S - EG Konformitetsförklaring

Vi intygar härmed att maskinen ZK 115 Ec uppfyller angivna EU direktiv. De angivna normerna användes vid konstruktion och tillverkning.

Befullmäktigad för sammanställningen av den tekniska dokumentationen: Mafell AG

DK - EU overensstemmelseserklæring

Vi attesterer hermed, at maskinen ZK 115 Ec opfylder de angivene EU-direktiver. Konstruktion og bygning er udført iht. de angivene standarder.

Person, der er befuldmægtiget til at sammenstille det tekniske materiale: Mafell AG



2006/42/EG

2014/30/EU

2011/65/EU

EN 60745, EN 55014-1, EN 55014-2, EN 61000-3, EN 12100 T1, EN 12100 T2, EN 1037, EN 847-1

ZK 115 Ec

Art.-Nr. 925001, 925020, 925021, 925025


Mafell AG

D - 78727 Oberndorf, den 28.07.2016



Krauss




i. V. Dr. Lauckner




MAF01156/a




MAF01156/a




MAF01156/a



MAF01156/a



MAF01156/a



MAF01156/a

Table of Contents

1	Signs and symbols	16
2	Product information	16
2.1	Manufacturer's data	16
2.2	Machine identification	16
2.3	Technical data	17
2.4	Noise emission specifications	17
2.5	Vibration specifications	17
2.6	Scope of supply	18
2.7	Safety devices	18
2.8	Use according to intended purpose	18
2.9	Residual risks	18
3	Safety instructions	18
4	Setting / Adjustment	20
4.1	Mains connection	20
4.2	Tool change	20
4.3	Insert change	20
5	Operation	21
5.1	Initial operation	21
5.2	Switching on and off	21
5.3	Cutting bird's mouths	21
5.4	Cutting oblates, grooves and cones	22
6	Service and maintenance	23
6.1	Machine	23
6.2	Tools	23
6.3	Storage	23
7	Troubleshooting	23
8	Special accessories	24
9	Exploded drawing and spare parts list	24

1 Signs and symbols



This symbol appears at places where you will find instructions for your own safety.

Non-compliance with these instructions may result in very serious injuries.



This symbol indicates a potentially hazardous situation.

If this situation is not avoided, the product or objects in its vicinity may get damaged.



This symbol indicates tips for the user and other useful information.

2 Product information


for machines with the item numbers 925001, 925020, 925021, 952022 oder 925025.

2.1 Manufacturer's data

MAFELL AG, Postfach 1180, D-78720 Oberndorf / Neckar, Phone +49 (0)7423/812-0, Fax +49 (0)7423/812-218

2.2 Machine identification

All details required for machine identification are available on the attached rating plate.



Protection class II



CE symbol to document compliance with the basic safety and health requirements according to Appendix I of the Machinery Directive.



For EU countries only

Do not dispose of electric tools together with household waste material!

In accordance with the European directive 2002/96/EC on waste electrical and electronic equipment and transposition into national law, obsolete electrical tools must be collected separately and recycled in an environmentally-compatible manner.



To reduce the risk of injury, please read the operating instructions.

2.3 Technical data

Universal motor, radio and TV interference suppressed	230 V~, 50 Hz	120 V~, 60 Hz
Power input (nominal load)	3000 W	2500 W
Current at nominal load	15,5 A	23,5 A
Speed of the output shaft when idle	4050 rpm	
Speed of the output shaft with nominal load	4050 rpm	
Can be pivoted from	0 – 60°	
Depth adjustment	0 - 83.5 mm (0- 3 29/100 in.)	

Working tool

for bird's mouths:	Cutter head Ø 150 x 115 mm (5 29/32 x 4 17/32 in.)	n _{max.} = 5000 rpm
for flattening:	Cutter head Ø 236 x 50 mm (9 29/100 x 1 97/100 in.)	n _{max.} = 5000 rpm
	Cutter head Ø 190 x 80 mm (7 31/64 x 3 5/32 in.)	n _{max.} = 5000 rpm

Weight	Machine with stop without cutter head and power cord	21,1 kg (46.5 lbs)
	Cutter head Ø 150 x 115 mm	3.0 kg (6.6 lbs)
	Cutter head Ø 236 x 50 mm	3.5 kg (7.7 lbs)
	Cutter head Ø 190 x 80 mm	5.9 kg (13 lbs)
Cutting speed with nominal load:	Cutter head Ø 150 x 115 mm	31.8 m/s (104 ft/sec.)
	Cutter head Ø 236 x 50 mm	50.0 m/s (164 ft/sec.)
	Cutter head Ø 190 x 80 mm	40.3 m/s (112 ft/sec.)

2.4 Noise emission specifications

Noise emission values determined according to EN 60745-1:

	Sound power level	Workplace-related emission value
Idling	108 dB (A)	97 dB (A)
Machining	109 dB (A)	98 dB (A)

The noise measurements were made with the standard cutter head included in delivery.

Workpiece: Spruce 140 x 140 x 2000 mm; Cutting depth: 20 mm; Guide without stop

The values stated do not take into consideration any possible series variances and are not suitable for determining the rating levels, as these fluctuate in dependence on the time in service, the respective type of machining and the environmental influences. The noise rating level can therefore only be determined on an individual basis at the machine user's position.

2.5 Vibration specifications

The typical hand-arm vibration is 4.0 m/s².

2.6 Scope of supply

Carpentry bird's mouth cutter ZK 115 Ec complete with:

- 1 parallel stop
- 1 bird's mouth cutter head Ø 150 x 115 mm (5 29/32 x 4 17/32 in.)
- 1 parallel stop
- 1 hex screwdriver
- 1 screwdriver Torx T 15
- 1 operating manual
- 1 folder "Safety Instructions"

2.7 Safety devices



Danger

These devices are required for the machine's safe operation and may not be removed or rendered inoperative.

The machine is equipped with the following safety devices:

- Upper stationary saw guard
- Lower retractable saw guard
- Upper retractable saw guard
- Large base plate
- Handles
- Index mechanism and brake

2.8 Use according to intended purpose

The MAFELL ZK 115 Ec carpentry bird's mouth cutter is designed exclusively for working with wood.

For manual feeding use only tools that bear the **MAN** and, if applicable, the **BG test** label.

The dimensioning of the cutting and flattening heads used must correspond to the tools listed in this operating manual.

The tool was manufactured in accordance with the European norm EN 847-1.

Any other use than described above is not permissible. The manufacturer cannot be held liable for any damage arising from such other use.

So as to use the machine as intended, comply with the operating, maintenance and repair instructions specified by Mafell.

2.9 Residual risks



Danger

Even if used in accordance with its intended purpose and despite conforming with the safety instructions, residual risks caused by the intended use will always remain.

- Touching the cutter head in the area of the start-up opening.
- Touching the part of the cutter head that protrudes below the workpiece when cutting.
- Machine backlash if the blade gets stuck in the workpiece.
- Breakage and hurling out of the tool or parts of the tool.
- Touching live parts with the housing open and the mains plug not removed.
- Hearing can be impaired when working for long periods without ear protectors.
- Emission of hazardous wood dust when operating the machine for longer periods of time without extraction.

3 Safety instructions



Danger

Always observe the following safety instructions and the safety regulations applicable in the respective country of use!

- Never work without the protective equipment required for the work to be undertaken and never modify anything on the machine that could impair safety.
- Children and adolescents must not operate this machine. This rule does not apply to young persons receiving training and being supervised by an expert.
- Before working with the machine, always check to ensure that the protective and safety devices are firmly in place and undamaged, that they work faultlessly and that the the moving protective hood works without getting stuck.
- Consider environmental influences. Do not expose the machine to rain and avoid working in damp and wet areas as well as near combustible liquids and gasses.
- When operating the machine outdoors, use of an earth-leakage circuit-breaker is recommended.
- Do not carry the machine by its cable and do not use the cable to pull the plug out of the socket outlet.
- Pay attention that the cable is protected against oil and heat and is not pulled across sharp edges.
- Damaged cables or plugs must be immediately replaced.
- Avoid sharp bends in the cable. Especially when transporting and storing the machine, do not wind the cable around the machine.
- Use only cutter heads with the specifications indicated in this operating manual.
- Store the machine in a dry, locked place outside the reach of children.
- Do not work on workpieces which are too small or too large for the capability of the machine.
- Install and fasten the cutter head properly. Use sharp cutters and taper taps; dull cutters increase the risk of kickout. Immediately replace damaged cutters and taper taps and fasten them so that they cannot become loose operation.
- The moving protective hood must not be blocked when open.
- The switch may not be wedged.
- Before switching on the machine, always check whether the cutter head is tightened and whether the wrench and pin have been removed.
- If possible ensure that the workpiece is secured from slippage, e.g. with tension clamps.
- Hold firmly onto the machine before switching it on.
- Begin cutting the workpiece only when the cutter head reaches its full speed.
- Examine the workpiece for foreign objects. Do not cut into metal parts, e.g. nails.
- Never reach under the workpiece while cutting (risk of injury!).
- When cutting always have the connecting cable behind the machine.
- An even forward feed when cutting extends the service life of the cutting bit and the machine. Do not cut backwards or by dipping.
- Remove the machine from the workpiece only when the cutter head is at a standstill.
- Never touch the cutter head or reach into the chip ejector while the machine is running. Always switch off the machine before making adjustments and ensure that the cutter head has come to a standstill.

Instructions on the use of personal protective equipment:

- Always wear ear protectors during work.
- Always wear a dust mask during work.
- Always wear protective goggles during work.

Instructions on operation:

- Provide for an unobstructed and slip-proof location with adequate lighting.
- Unplug the power cord before changing tools, making adjustments or rectifying faults (including the removal of jammed chips).

Instructions on service and maintenance:

- Regularly cleaning the machine, especially the adjusting devices and guides, constitutes an important safety factor.

- Only original MAFELL spare parts and accessories may be used. Otherwise the manufacturer will not accept any warranty claims and cannot be held liable.

4 Setting / Adjustment

4.1 Mains connection

Prior to commissioning make sure that the mains voltage complies with the operating voltage stated on the machine's rating plate.

4.2 Tool change



Danger

Always pull the power plug before changing tools.

The maximum permissible speed (indicated on the tool) must not be exceeded!

The operating speed must not exceed the maximum speed indicated on the tool.

Ensure the correct direction of rotation!

Clamp the tool so that it cannot become loose during operation.

The blades must touch neither each other nor clamping pieces.

Ensure that the machine is clean before changing tools. Clamping surfaces must be clean.

- Lock the tool with pin 31 (fig. 1+2).
- Use the hexagon screwdriver 29 to unscrew the cylinder head screw anticlockwise, remove front flange 27 and cutter head.
- Clean chips and dusts off the spindle and clamping surfaces and put the tool on. When doing so ensure that both drive pins on the spindle engage both bore holes on the tool.
- Insert the cylinder head screw with flange and tighten firmly with the hexagonal screwdriver.
- Remove the pin and hexagonal screwdriver.



Danger

Idle speed of the output shaft = 4050 rpm, therefore install only cutter heads with $n \geq 5000$ rpm .

4.3 Insert change



Danger

Always pull the power plug before making changes or adjustments.

Install and remove the cutters in accordance with instructions in the operating manual. Utmost caution is mandatory!

Ensure clean clamping surfaces.

Observe the specified tightening torques! The clamping screws must be tightened only with the tools of the same dimensions included in delivery. No striking tools, levers, extensions or other tools may be used.

All blades must always be fitted in order to prevent imbalance.

The cutter or flattening head must be fitted with replaceable hard metal cutting inserts. Time-consuming sharpening is unnecessary as the hard metal cutting inserts need to be only turned or replaced when the blades are dull.

- Remove the tool from the machine (see section 4.2).
- Loosen the screwed on hard metal cutting inserts with the spanner included in delivery, turn 90 degrees and tighten again° (4Nm) or, after turning three times, replace with new cutting inserts.
- Clean all parts and the blade chamber in the cutter head.



Aluminium tools may only be deresinified with solvents which do not corrode the aluminium.

- Re-install the tool (see section 3.2).

5 Operation

5.1 Initial operation

Personnel entrusted to work with the machine must be made aware of the operating instructions, calling particular attention to the chapter "Safety instructions".

It is mandatory to check whether all safety devices are attached and functional. This applies especially to the ease of movement of the protective hood.

5.2 Switching on and off



Danger

Before switching the machine on ensure that the cutter head can move freely and that the moving protective hood is closed.

Lead the connecting cable away to the rear.

Take hold of the machine by the handles.

Switch the machine on only when the cutter head is not in contact with the workpiece.

- **Switching on:** First unlock the switch lock by pressing the locking lever 12 (fig. 3). Then actuate the shift lever 13 while pressing the locking lever. As this is a switch without locking device, the machine will only run for as long as this gearshift lever is pressed.

The built-in electronic system provides for jerk-free acceleration when the machine is switched on and under load readjusts the speed to the fixed setting.

This electronic system also controls the motor upon overload, e.g. the cutter head stays still. The machine must then be unloaded until the cutter head has reached its full speed. Then continue to cut at a lower feed rate.

Switching off: Release the switch lever 13 to switch the machine off. The built-in automatic break limits the run-down time of the cutter head to approx. 5 s. The switch lock takes effect automatically and secures the bird's mouth cutter from inadvertently being switched on again.

5.3 Cutting bird's mouths

5.3.1 Mark bird's mouth

Angle and mark the two-sided bird's mouth mark at the intersection. Pull the crevice A – B (fig. 4) over the rafter.

5.3.2 Setting bird's mouth cutter

The following settings must be made before using the machine:

- **Set the bird's mouth angle "α":**
The cutter head can be pivoted from 0 – 60°. Release the clamping lever 8 (fig. 5) and set the angle value (e.g. 30°) on the angle scale. Tighten the clamping lever; The clamping position of the lever can be set by pulling it out in a vertical direction.
- **Set the depth indicator:**
The cutter depth indicator depends on the set bird's mouth angle "α". The depth indicator 4 can therefore be set from 0 – 60° and must always be set to the same angle value "α" as angle scale 6. Loosen the handle knob 9. Move the depth indicator 4 on the left side of setting scale 2 (marked "cutter head Ø 150 x 115") to the desired angle value "α" (the upper edge is the reading line) and the tighten the handle knob again.
- **Set the cutter depth to 0:**
Unscrew the wing screw 10 (fig. 5). Turn the handle 1 until the depth indicator 4 on the depth scale 5 is at zero. Tighten the wing screw 10 (fig. 5).



The corner of the cutter of the pivoted cutter head must be positioned at the same level as the base panel support.

- **Set the mark indicator:**
The mark indicator 16 (fig. 3) shows the position of the corner of the blade at the horizontal level. It must therefore always be set to the same angle value "α" as the angle scale 6 (fig. 5). Loosen the knurled knob 17 (fig. 3). Set the mark indicator 16 with the outer right edge over the mark scale 15 in the area of the marking "Set cutter head Ø 150 x 115» to angle value 'α". Tighten the knurled knob 17.



The angle scale 6 (fig. 5), depth indicator 4 and mark indicator 16 (fig. 3) must always be set to the same value "α".

- Parallel stop:**
 The parallel stop 18 (fig. 3) can be set after loosening the wing screws 19, and it can be used on the left or right side.
- Set the machine to the mark:**
 Open the moving protective hood by pressing the lever 23 (fig. 3) and set the machine onto the wood in such a way that the end guard 37 (fig. 6) swivels back. The bird's mouth angle, depth indicator (cutter depth 0 mm) and mark indicator must be set in advance. With respect to the space available, align the guide rails 34 (fig. 6) parallel left or right with spacing to the mark A - B (fig. 4) and fasten.

Spacing between the mark and rail approx.:

to the right 10 cm (3 15/16 in.)/30°
 15 cm (5 15/16 in.)/45°
 20 cm (7 7/8 in.)/60°

to the left 32 cm (12 9/16 in.)/30°
 30 cm (11 3/16 in.)/45°
 27 cm (10 5/8 in.)/60°

Tighten adapter 33 (fig. 6) on the parallel stop 18. Set the machine with the adapter on the guide rail and align it to the mark indicator on mark A - B (fig. 4) by moving it to the side in the parallel stop guides. Tighten the wing screws 19 (fig. 3). Check the mark on the rear mark scale 7 (fig. 5).

5.3.3 Cutting bird's mouth

- Unscrew the wing screw 10 (fig. 5). Remove the machine from the guide rail. Set cutter depth "T" (fig. 4) by turning the handle 1 (fig. 5) to the desired dimension in accordance with depth scale 5.
- Tighten the wing screw 10 (fig. 5) again. Set the machine with the adapter on the guide rail so that the cutter head with the protective hood is exposed. Switch on the machine. Open the moving protective hood by pressing the lever 23


(fig. 3) and cut with a uniform feed rate. The ejected chips can be deflected by setting the chip deflector 24. Guide the machine using both handles 11 and 21.



When done using the machine ensure that the moving protective hood is closed again.

5.3.4 Milling dimensions

Cutter head	Ø 150 x 115 (5 29/32 x 4 17/32 in.)					Ø 236 x 50 (9 29/100 x 1 97/100 in.)	Ø 190 x 80 (7 31/64 x 3 5/32 in.)
α	0	15	30	45	60	0	0
"α"							
Depth "D" (mm)	0 - 27 (1 1/16)	0 - 29.7 (1 11/64)	0 - 57.5 (2 17/64)	0 - 77.9 (3 1/8)	0 - 75 (2 61/64)	0 - 70 (2 3/8)	0 - 47 (1 27/32)
Width "W" (mm)	115 (4 17/32)						80 (1 9/16)
X (mm)		115 (4 17/32)	115 (4 17/32)	110 (4 13/32)	86.6 (3 13/32)		
Y (mm)		30.8 (1 7/32)	66.4 (2 5/8)	110 (4 13/32)	150 (5 29/32)		



MAF00952

5.4 Cutting oblates, grooves and cones

- Set angle scale 6 (fig. 5) and mark indicator 16 (fig. 3) to 0. Depending on the cutter head use, set the depth indicator 4 (fig. 5) to the left or right half of the setting scale 2 (with a cutter head of Ø 236 or 190 mm to the corresponding markings on the right, with a cutter head of Ø 150 mm to the left). The cutter width, which at first comprises the width of cutter head, can be increased by moving the parallel stop laterally 18 (fig. 3).

6 Service and maintenance



Danger

Pull the power plug during all service work.

MAFELL machines are designed to be low in maintenance.

The ball bearings used are greased for life. When the machine has been in operation for a longer period of time, we recommend to hand the machine in at an authorised MAFELL customer service shop for inspection.

Only use our special grease, order No. 049040 (1 kg tin) for all greasing points.

6.1 Machine

The machine must be regularly cleaned off deposited dust. The ventilation openings on the motor should be cleaned with a vacuum cleaner.

The free movement of the moving protective hood must be ensured. If it does not close by itself after it is opened, the machine must be delivered to an authorised MAFELL customer service workshop.

7 Troubleshooting



Danger

Determining the causes for existing defects and eliminating these always requires increased attention and caution. Pull the mains plug beforehand!

Some of the most frequent defects and their causes are listed in the following chart. In case of other defects, contact your dealer or the MAFELL customer service.

Defect	Cause	Elimination
Machine cannot be switched on	No mains voltage	Check power supply
	Mains fuse defective	Replace fuse
	Carbon brushes worn	Take the machine to a MAFELL customer service shop
Machine switches off automatically during idling or stops during cutting	Mains failure	Check mains back-up fuses
	Machine overloaded	Reduce feed speed

6.2 Tools

The cutter heads used on the machine should be regularly deresinified, as clean tools improve improve the cutting quality.

Deresinify them by placing them in petroleum or a commercially available deresinification agent for 24 hours.



Aluminium tools may only be deresinified with solvents which do not corrode the aluminium.

Promptly replace damaged clamping screws and cutting elements.

The design must not be modified with progressive tools during servicing.

6.3 Storage

If the machine is not used for a longer period of time, it has to be carefully cleaned. Spray bright metal parts with a rust inhibitor.

Store the machine only in dry rooms and protect it from the effects of weather.

8 Special accessories

- | | |
|---|------------------|
| - Guide rail length 3 m (2 parts with connector) | Order No. 037037 |
| - Guide rail length 3 m (1 part) | Order No. 200672 |
| - Guide rail extension length 1.5 m | Order No. 036553 |
| - Adapter pair for parallel stop | Order No. 037195 |
| - Complete bird's mouth cutter head Ø 150 x 60 mm | Order No. 091415 |
| - Complete bird's mouth cutter head Ø 190 x 80 mm | Order No. 091417 |
| - Complete flattening head Ø 236 x 50 mm | Order No. 203659 |

9 Exploded drawing and spare parts list

The corresponding information in respect of spare parts can be found on our homepage: www.mafell.com