


NOVA[™] Comet II Midi Lathe Bed Extension Accessory Instructions




SKU: 47001

For safety reasons please carefully read and understand these instructions.

The NOVA[™] Comet II Midi Lathe Bed Extension Accessory is designed to fit and be used only with the NOVA[™] Comet II Wood Lathe. Use of this Bed Extension Accessory on other lathes could cause a malfunction and risk of serious injury. If you are unsure of the use or application of this accessory, contact the technical manager of Teknatool International or your reseller. Please read the manual that came with your NOVA[™] Comet II Wood Lathe before use and carefully follow the safety instructions before operating.

Thank you for purchasing the NOVA[™] Comet II Bed Extension Accessory, this unit will allow you to greatly increase your turning capacity allowing you to turn long items, adds 24.6"/625mm per accessory unit.



Parts List:

Part	Quantity	Code	Description
1	1	46015	Bed
2	4	C10035	Hex Capscrew M10x35
3	4	SW10	10mm Spring Washer
4	4	FW10	10mm Flat Washer
5	2	46007	Rubber Feet
6	1	AK8	8mm Allen key


Assembly instructions:

Each cast-iron Bed Extension adds 24.6"/625mm to the lathes length.

- 1. Clean the joining ends of both bed sections with a petroleum-based solvent. Make sure there are no dents or burrs on either of the mating surfaces. Remove burrs and high spots with a smooth file.
- 2. Place the two mating faces together and install the Four M10 cap screws. Note: only install finger tight at this time.

Warning!

Do not use a metal hammer to pound on the Bed Extension. This may damage the bed, affect accuracy and tailstock action. In addition, it may prevent you from adding another Bed Extension.



- 3. Move the tailstock until it is on top of the area where the Bed Extension face meets the Lathe Bed face (see illustration). The Bed Extension may need to be manipulated up, down or sideways in order for the tailstock to fit.
- 4. With the Lathe Bed and Bed Extension in alignment, tighten the Tailstock Locking Handle down in its current position.
- 5. Tighten the four M10 cap screws that were previously installed
- 6. Check to ensure that the Tailstock moves freely over the mating joint and also over the full length of the addon Bed Extension. If there is ridge between the two mating surfaces, repeat steps 1-5 again

Teknatool Two Year Limited Warranty

This Teknatool product is backed by a warranty from the date of purchase. Teknatool International Ltd will repair or replace, at its expense and option, this Teknatool product which in normal use has proven to be defective in workmanship or material, provided that the customer returns the product prepaid to an authorized Teknatool service center with proof of purchase of the product within TWO YEARS and provides Teknatool will reasonable opportunity to verify the alleged defect by inspection. Teknatool will pay return product by most cost effective surface transport to customer. Any special freight services above this will be at customer cost. Teknatool will not be responsible for any asserted defect, which has resulted from normal wear, misuse, abuse, repair or alteration made by anyone other than an authorized service facility or representative. Under no circumstances will Teknatool International Ltd. be liable for incidental, special, indirect, and consequential damages or expenses, including loss of profits or loss of operations. This warranty is Teknatool International Ltd sole warranty. There are no other warranties, whether written or verbal, whether expressed or implied by law, trade, custom, or otherwise, whether of merchantability, fitness for purpose, or otherwise, except for remedies available to customers under the Consumer Guarantees Act or other legislation.

OVERSEAS CUSTOMERS: Our Teknatool Distributors and agents will issue their own warranty to cover this product. Terms may vary from those stated above; please check with your dealer. In North America warranty covers Continental USA only. For Alaska, Hawaii and other areas, warranty covers replacement of parts only and excludes transport costs.

Register your Warranty with Teknatool faster online Visit our website <u>www.teknatool.com</u> to register your warranty today

TEKNATOOL INTERNATIONAL LIMITED

Designed in New Zealand, Made in China

7D Dallan Place, Albany, Auckland, New Zealand 0632 Phone: 649-477-5600 Email: <u>sales@teknatool.com</u> Website: www.teknatool.com