



JBS-12

WOODWORKING BANDSAW

100001021M

~230V, 50Hz

PARTS LIST

JPW (TOOL) AG

Tämperlistrasse 5

CH-8117 Fällanden

Switzerland

Phone +41 44 806 47 48

Fax +41 44 806 47 58

www.jettools.com



M-100001021M

2015-04-01

This detailed exploded view diagram illustrates the assembly of a vehicle chassis and suspension system. The components are meticulously numbered for identification:

- Chassis and Body Panels:** Includes the main chassis frame (1), side panels (12-18), and various interior and exterior trim pieces (e.g., 23, 26, 29, 30, 33, 38, 40, 42, 44, 46, 48, 50, 51, 53, 54, 55, 56, 57, 58, 60, 64, 66, 67, 70, 71, 72, 73, 74, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 114, 115, 116, 117, 118, 119, 120, 123, 124, 125, 126, 130, 134, 135, 136, 137, 140, 141, 142, 143, 144, 145, 146, 147, 148, 149, 150, 151, 152, 153, 154, 155, 156, 157, 158, 159, 160, 161, 162, 163, 164, 165, 166, 167, 168, 169, 170, 171, 172, 173, 174, 175, 176, 177, 178, 179, 180, 181, 182, 183, 184, 185, 186, 187, 188, 189, 190, 191, 192, 193, 194, 195, 196, 197, 198, 199, 200, 201, 202, 203, 204, 205, 206, 207, 208, 209, 210, 211, 212, 213, 214, 215, 216, 217, 218, 219, 220, 221, 222, 223, 224, 225, 226, 227, 228, 229, 230, 231, 232, 233, 234, 235, 236, 237, 238, 239, 240, 241, 242, 243, 244, 245, 246, 247, 248, 249, 250, 251, 252, 253, 254, 255, 256, 257, 258, 259, 260, 261, 262, 263, 264, 265, 266, 267, 268, 269, 270, 271, 272, 273, 274, 275, 276, 277, 278, 279, 280, 281, 282, 283, 284, 285, 286, 287, 288, 289, 290, 291, 292, 293, 294, 295, 296, 297, 298, 299, 300, 301, 302, 303, 304, 305, 306, 307, 308, 309, 310, 311, 312, 313, 314, 315, 316, 317, 318, 319, 320, 321, 322, 323, 324, 325, 326, 327, 328, 329, 330, 331, 332, 333, 334, 335, 336, 337, 338, 339, 340, 341, 342, 343, 344, 345, 346, 347, 348, 349, 350, 351, 352, 353, 354, 355, 356, 357, 358, 359, 360, 361, 362, 363, 364, 365, 366, 367, 368, 369, 370, 371, 372, 373, 374, 375, 376, 377, 378, 379, 380, 381, 382, 383, 384, 385, 386, 387, 388, 389, 390, 391, 392, 393, 394, 395, 396, 397, 398, 399, 400, 401, 402, 403, 404, 405, 406, 407, 408, 409, 410, 411, 412, 413, 414, 415, 416, 417, 418, 419, 420, 421, 422, 423, 424, 425, 426, 427, 428, 429, 430, 431, 432, 433, 434, 435, 436, 437, 438, 439, 440, 441, 442, 443, 444, 445, 446, 447, 448, 449, 450, 451, 452, 453, 454, 455, 456, 457, 458, 459, 460, 461, 462, 463, 464, 465, 466, 467, 468, 469, 470, 471, 472, 473, 474, 475, 476, 477, 478, 479, 480, 481, 482, 483, 484, 485, 486, 487, 488, 489, 490, 491, 492, 493, 494, 495, 496, 497, 498, 499, 500, 501, 502, 503, 504, 505, 506, 507, 508, 509, 510, 511, 512, 513, 514, 515, 516, 517, 518, 519, 520, 521, 522, 523, 524, 525, 526, 527, 528, 529, 530, 531, 532, 533, 534, 535, 536, 537, 538, 539, 540, 541, 542, 543, 544, 545, 546, 547, 548, 549, 550, 551, 552, 553, 554, 555, 556, 557, 558, 559, 560, 561, 562, 563, 564, 565, 566, 567, 568, 569, 570, 571, 572, 573, 574, 575, 576, 577, 578, 579, 580, 581, 582, 583, 584, 585, 586, 587, 588, 589, 590, 591, 592, 593, 594, 595, 596, 597, 598, 599, 600, 601, 602, 603, 604, 605, 606, 607, 608, 609, 610, 611, 612, 613, 614, 615, 616, 617, 618, 619, 620, 621, 622, 623, 624, 625, 626, 627, 628, 629, 630, 631, 632, 633, 634, 635, 636, 637, 638, 639, 640, 641, 642, 643, 644, 645, 646, 647, 648, 649, 650, 651, 652, 653, 654, 655, 656, 657, 658, 659, 660, 661, 662, 663, 664, 665, 666, 667, 668, 669, 670, 671, 672, 673, 674, 675, 676, 677, 678, 679, 680, 681, 682, 683, 684, 685, 686, 687, 688, 689, 690, 691, 692, 693, 694, 695, 696, 697, 698, 699, 700, 701, 702, 703, 704, 705, 706, 707, 708, 709, 710, 711, 712, 713, 714, 715, 716, 717, 718, 719, 720, 721, 722, 723, 724, 725, 726, 727, 728, 729, 730, 731, 732, 733, 734, 735, 736, 737, 738, 739, 740, 741, 742, 743, 744, 745, 746, 747, 748, 749, 750, 751, 752, 753, 754, 755, 756, 757, 758, 759, 760, 761, 762, 763, 764, 765, 766, 767, 768, 769, 770, 771, 772, 773, 774, 775, 776, 777, 778, 779, 780, 781, 782, 783, 784, 785, 786, 787, 788, 789, 790, 791, 792, 793, 794, 795, 796, 797, 798, 799, 800, 801, 802, 803, 804, 805, 806, 807, 808, 809, 810, 811, 812, 813, 814, 815, 816, 817, 818, 819, 820, 821, 822, 823, 824, 825, 826, 827, 828, 829, 830, 831, 832, 833, 834, 835, 836, 837, 838, 839, 840, 841, 842, 843, 844, 845, 846, 847, 848, 849, 850, 851, 852, 853, 854, 855, 856, 857, 858, 859, 860, 861, 862, 863, 864, 865, 866, 867, 868, 8

Parts List For JBS-12 Woodworking Bandsaw

Pos.	Art. Nr.	Description	Beschreibung
1	JBS12-001	Circlip ring 17x1	Sicherungsring 17x1
2	JBS12-002	Ball bearing 6203	Rillenkugellager 6203
3	JBS12-003	Upper band saw wheel assembly	Baugruppe oberes Bandsägenrad
4	JBS12-004	Upper bearing shaft	Obere Lagerwelle
5	JBS12-005	Wheel carrier bracket	Radträgerbügel
6	JBS12-006	Spring washer M16	Federscheibe M16
7	JBS12-007	Hexagonal nut -M16x1.5	Sechskantmutter -M16x1.5
8	JBS12-008	Special Screw for tension	Spezialschraube für Spannung
9	JBS12-009	Starlock ring 10mm	Starlock Sicherungsring 10mm
10	JBS12-010	Cylindrical pin 11x100	Zylindrischer Stift 11x100
11	JBS12-011	Tension bracket	Spannungsbügel
12	JBS12-012	Slotted inset	Geschlitzter Einsatz
13	JBS12-013	Saddle washer	Schlittenscheibe
14	JBS12-014	Lock housing	Verriegelungsgehäuse
15	JBS12-015	Nylon washer	Nylonscheibe
16	JBS12-016	Hexagonal nut M22x1.5	Sechskantmutter M22x1.5
17	JBS12-017	Tongue lock	Zungenverriegelung
18	JBS12-018	Serrated lock washer 6mm	Gezahnte Verriegelungsscheibe 6mm
19	JBS12-019	Hexagonal bolt -M6x10	Sechskantschraube -M6x10
20	JBS12-020	Leaf spring	Blattfeder
21	JBS12-021	Door-upper assembly	Tür - obere Baueinheit
22	JBS12-022	Circlip ring 40	Sicherungsring 40
23	JBS12-023	Lamello plug	Lamello Stecker
24	JBS12-024	Blade tension knob	Blattspannungsknopf
25	JBS12-025	Blade tensioner	Blattspanner
26	JBS12-026	Flat washer 8 mm	Flache Scheibe 8 mm
27	JBS12-027	Hexagonal head screw M8x16	Sechskantkopfschraube M8x16
28	JBS12-028	Blade tracking knob	Blattnachführungsknopf
29	JBS12-029	Wing nut M8	Flügelmutter M8
30	JBS12-030	Door Switch assembly	Tür Endschalter komplett
30-1	JBS12-030-1	Pan head taping screw 3.5x20	Flachkopfbandschraube 3.5x20
30-2	JBS12-030-2	Flat washer 4mm	Scheibe 4mm
30-3	JBS12-030-3	Door Switch Box A	Schaltergehäuse Box A
30-4	JBS12-030-4	Door Switch	Endschalter
30-5	JBS12-030-5	Door Switch Box B	Schaltergehäuse Box B
31	JBS12-031	Tension bracket frame	Spannungsbügelrahmen
32	JBS12-032	Flange nut M8 galvanised	Flanschmutter M8 galvanisiert
33	JBS12-033	Frame for Bandsaw	Bandsäge-Rahmen

Parts List For JBS-12 Woodworking Bandsaw

Pos.	Art. Nr.	Description	Beschreibung
34	JBS12-034	Spacer bush	Distanzhülse
35	JBS12-035	Pan head tapping screw 4.8x16	Flachkopfbandschraube 4.8x16
36	JBS12-036	Serrated lock washer 5 mm	Gezahnnte Schraubensicherung 5 mm
37	JBS12-037	Plate	Platte
38	JBS12-038	Carriage bolt M8x20	Flachrundschraube mit Nase M8x20
39	JBS12-039	Bolt guide	Schraubenführung
40	JBS12-040	Hexagonal bolt -M6x20	Sechskantschraube - M6x20
41	JBS12-041	Clinch Bolt	Nietbolzen
42	JBS12-042	Guide bracket	Führungsbügel
43	JBS12-043	Serrated lock washer 6 mm	Gezahnnte Schraubensicherung 6 mm
44	JBS12-044	Hexagonal nut M6	Sechskantmutter M6
45	JBS12-045	Saw blade guard assembly	Sägeblattschutz Baueinheit
46	JBS12-046	Slide	Schlitten
47	JBS12-047	Screw M4x12	Schraube M4x12
48	JBS12-048	Guide adjust screw M6x16	Führungsjustierschraube
49	JBS12-049	Grooved ball bearing 608	Rillenkugellager 608
50	JBS12-050	Flat washer 6 mm	Flache Scheibe 6 mm
51	JBS12-051	3-roller guide assembly	3-Rollenführung Baueinheit
52	JBS12-052	Hexagonal nut M6	Sechskantmutter M6
53	JBS12-053	Bolt guide, small	Schraubenführung, klein
54	JBS12-054	Screw socket set M6x12	Schraubenaufnahmesatz M6x12
55	JBS12-055	Guide shaft	Führungswelle
56	JBS12-056	Upper guide mount	Obere Führungsaufnahme
57	JBS12-057	Flat washer 8 mm	Flache Scheibe 8 mm
58	JBS12-058	Hexagonal nut M8, nylonstop	Sicherungsmutter M8
59	JBS12-059	Hexagonal bolt -M6x20	Sechskantschraube M6x20
60	JBS12-060	Bearing mount cylinder w/cap	Lageraufnahmezylinder mit Abdeckung
61	JBS12-061	Hexagonal nut M8	Sechskantmutter M8
62	JBS12-062	Clamp	Klemme
63	JBS12-063	Pan head Screw M5x10	Linsenkopfschraube M5x10
64	JBS12-064	Bearing mount cylinder	Lageraufnahmezylinder
65	JBS12-065	Flange nut M8	Flanschmutter M8
66	JBS12-066	Washer	Scheibe
67	JBS12-067	Wire jacket	Kabeldurchführung
68	JBS12-068	Saw blade 2240x13x0,5mm-4TPI	Sägeblatt 2240x13x0,5mm-4Z/"
69	JBS12-069	Door-lower assembly	Tür - untere Baueinheit
70	JBS12-070	Hexagonal nut M4, nylonstop	Sicherungsmutter M4

Parts List For JBS-12 Woodworking Bandsaw

Pos.	Art. Nr.	Description	Beschreibung
71	JBS12-071	Flat washer 4 mm	Flache Scheibe 4 mm
72	JBS12-072	Saw blade guard	Sägeschutz unten
73	JBS12-073	Hexagonal screw -M4x12	Sechskantschraube - M4x12
74	JBS12-074	On/Off magnetic switch 1~230V	Ein/Aus Magnetschalter 1~230V
75	JBS12-075	Carriage bolt M8x100	Flachrundschraube mit Nase M8x100
76	JBS12-076	Brush	Bürste
77	JBS12-077	Spacer bush 8x50	Distanzbuchse 8x50
78	JBS12-078	Lower band saw wheel assembly	Baugruppe unteres Bandsägenrad
79	JBS12-079	Grooved ball bearing 6001	Genutetes Kugellager 6001
80	JBS12-080	Tension wheel	Spannrad
81	JBS12-081	Circlip ring 12x1	Sicherungsring 12x1
82	JBS12-082	Circlip ring 28	Sicherungsring 28
83	JBS12-083	Sliding shaft	Schiebewelle
84	JBS12-084	Set Screw M6x12	Gewindestift M6x12
85	JBS12-085	Hexagonal nut -M20x1.5	Sechskantmutter - M20x1.5
86	JBS12-086	Lower bearing shaft	Untere Lagerwelle
87	JBS12-087	Poly-v-belt	Rippenkeilriemen
88	JBS12-088	Motor belt pulley	Motorriemenscheibe
90	JBS12-090	Hexagonal screw -M6x16	Sechskantschraube -M6x16
91	JBS12-091	Spring washer 6 mm	Federscheibe 6 mm
92	JBS12-092	Set collar 10 mm	Stellring 10 mm
93	JBS12-093	Set Screw M5x8	Gewindestift M5x8
94	JBS12-094	Disk washer 20x10.2x0.8	Scheibe 20x10.2x0.8
95	JBS12-095	Crank	Kurbel
96	JBS12-096	Suction connector Rd 100	Saugstutzen Dm 100
97	JBS12-097	Washer 6mm	Scheibe 6mm
98	JBS12-098	Hexagonal nut M6	Sechskantmutter M6
99	JBS12-099	Hexagonal screw -M6x20	Sechskantschraube M6x20
100	JBS12-100	Hexagonal flat nut-M6	Sechskantflachmutter - M6
101	JBS12-101	Crank handle	Kurbelhandgriff
102	JBS12-102	Cap screw M6x55	Kopfschraube M6x55
103	JBS12-103	Motor P2=0.55kW, 1~230V, 50Hz	Motor P2=0.55kW, 1~230V, 50Hz
103-1	JBS12-103-1	Motor Terminal Box	Motor Klemmenkasten
103-2	JBS12-103-2	Capacitor	Kondensator
103-3	JBS12-103-3	Motor Fan	Lüfterrad
103-4	JBS12-103-4	Motor Fan Cover	Lüfterrad-deckel
104	JBS12-104	Pin guide set	Siftführungs-satz


Parts List For JBS-12 Woodworking Bandsaw

Pos.	Art. Nr.	Description	Beschreibung
105	JBS12-105	Lower guide support	Untere Führungsauflage
106	JBS12-106	Pointer	Zeiger
107	JBS12-107	Machine Screw ST3.5x9	Blechschraube ST3.5x9
108	JBS12-108	Tilt Degree Scale	Schwenkskala
109	JBS12-109	Rip fence carrier	Parallelanschlag-Träger
110	JBS12-110	Miter Gauge Assembly	Gehrungsanschlag komplett
110-1	JBS12-110-1	Pan Head Machine Screw	Blechschraube
110-2	JBS12-110-2	Fence Plate A	Endkappe A
110-3	JBS12-110-3	Guide Base	Gehrungsanschlag-Träger
110-4	JBS12-110-4	Clinch Bolt	Nietbolzen
110-5	JBS12-110-5	Ruler	Skala
110-6	JBS12-110-6	Handle	Griff
110-7	JBS12-110-7	Pointer	Zeiger
110-8	JBS12-110-8	Pointer Base	Zeiger Träger
110-9	JBS12-110-9	Pin	Stift
110-10	JBS12-110-10	Screw M3x16	Schraube M3x16
110-11	JBS12-110-11	Bolt	Stehbolzen
110-12	JBS12-110-12	Washer 6	Scheibe 6
110-13	JBS12-110-13	Support Strip	T-Profil
110-14	JBS12-110-14	Shaft Screw M6	Gewindestift M6
110-15	JBS12-110-15	Lock Knob	Klemmgriff
110-16	JBS12-110-16	Carriage bolt M6x30	Flachrundschraube M6x30
110-17	JBS12-110-17	Guide Fence	Gehrungsanschlag-Aluprofil
110-18	JBS12-110-18	Fence Plate B	Endkappe B
112	JBS12-112	Knurled thumb screw M6x25 galvanised	Hohe Rändelschraube M6x25 galvanisiert
113	JBS12-113	Knurled nut M6	Rändelmutter M6
114	JBS12-114	Washer flat 6 mm	Scheibe flach 6 mm
115	JBS12-115	Carriage bolt M6x40	Flachrundschraube mit Nase M6x40
116	JBS12-116	Fence extrusion	Parallelanschlag-Aluprofil
117	JBS12-117	Bolt guide	Schraubenführung
118	JBS12-118	Carriage bolt M8x50	Flachrundschraube mit Nase M8x50
119	JBS12-119	Table	Tisch
120	JBS12-120	Table insert	Tischeinlage
123	JBS12-123	Scale-metric	Skala - metrisch
124	JBS12-124	Rip fence carrier extrusion	Anschlagführung
125	JBS12-125	Hexagonal nut M6	Sechskantmutter M6
126	JBS12-126	Power Cord 230V for JBS-12	

Parts List For JBS-12 Woodworking Bandsaw

Pos.	Art. Nr.	Description	Beschreibung
130	JBS12-130	Wing nut M8	Flügelmutter M8
134	JBS12-134	Glide piece	Gleitstück
135	JBS12-135	Table trunion upper	Obere Tischswippe
136	JBS12-136	Serrated lock washer 8 mm	Gezähnte Schraubensicherung 8 mm
137	JBS12-137	Hexagonal screw M8x20	Sechskantschraube M8x20
140	JBS12-140	Table trunion lower	Untere Tischswippe
200	JBS12-200	Band saw tyre 315x2.5x20	Rollenauflage 315x2.5x20

Bandsaw Stand



Pos.	Art. Nr.	Description	Beschreibung
301	JBS12-301	Hex. Nut M 6	Sechskantmutter M6
302	JBS12-302	Washer 6	Scheibe 6
303	JBS12-303	Hexagonal screw –M6x40	Sechskantschraube M6x40
304	JBS12-304	Hex. Nut M8	Sechskantmutter M8
305	JBS12-305	Hexagonal screw –M8x16	Sechskantschraube M8x16
306	JBS12-306	Support Plate A	Querstrebe A
307	JBS12-307	Support Plate B	Querstrebe B
308	JBS12-308	Stand Leg	Standfüßein
309	JBS12-309	Rubber Foot	Gummiteller
310	JBS12-310	Support Plate C	Querstrebe C
311	JBS12-311	Support Plate D	Querstrebe D

Wiring Diagram for JBS-12 Woodworking Band Saw

100001021M

1~230V, 50Hz

	colour of strands	Litzenfarben	cordons
BK	black	schwarz	noir
BU	blue	blau	bleu
BN	brown	braun	brun
GNYE	green-yellow	grün-gelb	vert-jaune

	meaning of symbol	Bedeutung	interprétation
M	motor	Motor	moteur
S	switch	Schalter	interrupteur
C	condenser	Kondensator	condensateur
LS	limit switch	Endschalter	micro

