






*Woodworking machinery at its best!*







## W510 ROLLER STAND

### ASSEMBLY INSTRUCTIONS

<p>Using the 5mm Hex Key provided, locate the hex head bolt through the hole in one of the foot tubes.</p> <p>Whilst holding the bolt in position with the key, remove the cylindrical nut taking care not to allow the screw to drop out of the foot tube.</p> <p>Slide the cylindrical nut into the holes in one of the stand legs and attach the foot tube.</p> <p>Repeat for the other stand leg and foot tube.</p>	
<p>Attach the Roller cradle to the square section using the two M6 x 35mm bolts, washers and nyloc nuts provided.</p> <p>A 10mm spanner will be required to hold the nut.</p>	
<p>Screw the Height Locking Handle into the threaded hole at the top of the Stand Leg.</p> <p>Use this handle to adjust the height of the roller as required.</p>	

# W510B FITTING INSTRUCTIONS

This is an optional accessory that converts the single function roller stand into a 3 function stand:  
The bearing line allows the workpiece to be easily moved in all directions, therefore most suitable for handling sheet material.  
The flip-up length stop is most commonly used with mitre saws where repeat cuts are required of the same length.

<p>To fit the bearing line for the first time, press in the spring-loaded shaft on the end of the roller and remove the roller from the cradle.</p>		
<p>Using a cross head screwdriver. Fit the small screw, with the hexagonal nut to the outside, on both ends of the cradle.</p>		
<p>Re-fit the roller into the cradle by pressing the spring-loaded shaft on one end. Hook one end of the bearing line over the fixed shaft on the roller, then press the spring-loaded shaft and fit the bearing line, so that the spring loaded shaft fits into the elongated hole.</p>		
<p>The roller stand now has 3 configurations. When fitted as shown here, the bearing line can be used. To use the roller, lift the bearing line slightly and allow it to pivot to one side.</p>		
<p>To use the length stop, lift the bearing line and pivot around until the length stop is in the position shown here.</p>	